

**ZIRKOR302 E**  
**Oxygen Analyzer**  
**with Ejector**



**Installation**  
**Commissioning and Operation**  
**Maintenance**



<b>1</b>	<b>General.....</b>	<b>4</b>
1.1	Purpose of This Document.....	4
1.2	Operating Personnel .....	4
1.3	Other Documents .....	4
<b>2</b>	<b>Basic Safety Information .....</b>	<b>5</b>
2.1	Obligations and Liability .....	5
2.2	Safety Symbols .....	6
2.3	Intended Use .....	6
2.4	Incorrect Usage .....	7
2.5	Informal Safety Measures .....	7
2.6	Danger from Electrical Power .....	8
2.7	Hazardous Areas.....	8
2.8	Removal from Service .....	8
2.9	Alterations to the Construction of Devices .....	8
<b>3</b>	<b>General Description .....</b>	<b>9</b>
3.1	Theoretical Fundamentals, Measuring Principle.....	9
3.2	General View .....	18
3.3	Probe ChapterView .....	24
3.4	Gas Extraction Device (GED) .....	25
3.5	Protective Pipe with Aluminum Core.....	27
3.6	Conformity .....	27
<b>4</b>	<b>Installation .....</b>	<b>28</b>
4.1	Prerequisites .....	28
4.2	Counterflange Assembly (Optional Accessory) .....	29
4.3	Installing the Gas Extraction Device (GED) and the Protective Pipe for the GED .....	30
4.4	Electrical and Pneumatic Connections.....	31
4.5	System Settings in Accordance with System Composition (Reduced to Case Studies) .....	34
4.6	Installing the Gas Extraction Device and Pre-Filter Heater (Optional).....	35
4.7	Installing the Protective Pipe for High-Dust Applications .....	44
<b>5</b>	<b>Operation and Display Controls .....</b>	<b>46</b>
5.1	Multi-Function Key.....	46
5.2	LED Display.....	47
5.3	Monitor Output / DIP Switch.....	48
5.4	Remote Display Software.....	48
5.5	Display/Control Unit.....	49
5.6	Parameter Groups.....	55
<b>6</b>	<b>Operation .....</b>	<b>56</b>
6.1	Activating Measurement Mode.....	56
6.2	Operating and Status Messages.....	58
6.3	Practical Notes .....	59
6.4	Removal from Service .....	61
<b>7</b>	<b>Warnings and Faults .....</b>	<b>62</b>
7.1	Fault History .....	62
7.2	Display via Rows of LEDs on the Processor Board .....	62
7.3	Indication via Display and Operation Unit / Remote Display Software .....	64
7.4	Faults.....	65
7.5	Warnings .....	67

# Table of Contents

---

<b>8</b>	<b>Service and Maintenance</b> .....	<b>69</b>
8.1	Recommendations for practical application.....	69
8.2	Checking and Calibrating the Probe.....	70
8.3	Check with Test Gas .....	71
8.4	Software Update to 5V006 with Flash-Update-Software V1.2 .....	73
8.5	Removing the GED and Checking Penetrability .....	76
8.6	Removing the Probe Body.....	78
8.7	Checking the Measuring Cell Heaters.....	79
8.8	Replacing the Measuring Cell and Measuring Cell Heater .....	79
8.9	Cleaning and Replacing the Ejector (incl. Heater) .....	81
8.10	Checking the PT 100 Temperature Sensor.....	82
8.11	Replacing the Measuring Chamber .....	83
8.12	Replacement of the pressure sensors.....	87
8.13	Replacement of the analog output card .....	88
8.14	Replacement of the base electronic .....	88
<b>9</b>	<b>Disposal</b> .....	<b>89</b>
<b>10</b>	<b>Optional Accessories</b> .....	<b>90</b>
10.1	LSB-Module with 4 Analog Outputs Voltage, alternatively Current.....	90
10.2	LSB-Module with 4 Analog Inputs .....	93
10.3	LSB-Module with 4 Digital Outputs.....	95
10.4	LSB-Module with 4 Digital Inputs .....	100
10.5	Internal Connection of LSB Modules (Max. 2 Modules).....	105
10.6	External Connection of LSB-Module .....	107
10.7	Activating of LSB-Modules .....	108
10.8	Compressed Air Unit to Supply the LAMBDA TRANSMITTER E .....	110
10.9	Gas Extraction Kit with Heater for Gas Extraction Device .....	112
10.10	Gas Extraction Kit with Gas Extraction Device and Filter Heater.....	112
10.11	Protective Pipe for High-Dust Applications.....	113
10.12	Ceramic Gas Extraction Device .....	114
10.13	Counterflange .....	114
10.14	Optional Second RS422 Interface, Type K6029318 .....	115
<b>11</b>	<b>Spare Parts and Consumables</b> .....	<b>121</b>
11.1	Consumables:.....	121
11.2	Spare Parts:.....	122
<b>12</b>	<b>Appendix</b> .....	<b>125</b>
12.1	Technical Specifications .....	125
12.2	Connection Diagram.....	128
12.3	Dimensions .....	129
12.4	Base Electronics.....	130
12.5	Plug-in Jumpers.....	132
12.6	Probe Record Pass (Front).....	135

# 1 General

## 1.1 Purpose of This Document

---

These operating instructions provide operators with information about:

- Operation
- Safety instructions
- Maintenance
- Troubleshooting

Although other documents (e.g. Product Information) may provide additional information, they must not be regarded as a substitute for these operating instructions.

## 1.2 Operating Personnel

---

For certain activities (electrical installation, for example), specialist knowledge is required. Such activities must only be carried out by suitably qualified personnel.

Those responsible for personal safety must make sure that:

- All work on the device components is carried out by qualified personnel only.
- They always have access to the operating instructions supplied with the device as well as the associated order documentation when carrying out work and observe this documentation to avoid hazards and damage.

Faults must be analyzed by qualified personnel. Measures must be taken to prevent consequential damage, personal injury, and damage to the system.

Qualified personnel

These persons must be qualified by virtue of their expertise (training, education, experience) or understanding of the relevant standards, specifications, accident prevention regulations, and properties of the system. It is crucial that these persons be able to identify and avoid potential hazards in good time.

Technical experts are those persons defined in DIN VDE 0105, IEC 364, or directly equivalent standards, such as DIN 0832.

User groups

Two user groups have been defined for the LAMBDA TRANSMITTER E:

- Manufacturer's service technicians and trained customer personnel:  
Qualified technicians/engineers who have an in-depth knowledge of the device.
- Operators, in-house installation engineers:  
Technicians for instrumentation and control technology, electrical engineering and electronics, who have a basic knowledge of the device.

## 1.3 Other Documents

---

For accessories and special applications, consult the documentation supplied.

## 2 Basic Safety Information

These operating instructions contain the most important information regarding the safe operation of the LAMBDA TRANSMITTER E . Always read them before starting work. Warnings must be observed at all times.

### 2.1 Obligations and Liability

---

Observe notes in these operating instructions	Before you can operate the device safely and properly, you must be familiar with the basic safety precautions and regulations. These operating instructions (in particular the safety precautions) must be observed by everyone who uses the LAMBDA TRANSMITTER E and connected components. In addition, the general and local accident prevention rules and regulations must be observed.
Hazards when using the O <sub>2</sub> ANALYZER	<p>The LAMBDA TRANSMITTER E is constructed in accordance with the current state of the art and recognized safety regulations. Measures must nonetheless be taken to prevent injury to the operator or a third person and to prevent the LAMBDA TRANSMITTER E or other objects from being damaged. The LAMBDA TRANSMITTER E must only be used:</p> <p>For its intended purpose When it is in good working order. Faults that could compromise safety must be rectified immediately.</p>
Warranty and liability	<p>Our "General Terms of Sale and Delivery" always apply. These are available to the operator as soon as a contract has been concluded. Warranty and liability claims for personal injury or material damage shall be excluded if they are attributable to one or more of the following causes:</p> <ul style="list-style-type: none"><li>• The LAMBDA TRANSMITTER E and connected components have not been used for their intended purpose.</li><li>• The LAMBDA TRANSMITTER E and connected components have been installed, commissioned, operated, or serviced incorrectly.</li><li>• The LAMBDA TRANSMITTER E and connected components have been operated with safety and protective equipment that is either defective, incorrectly installed, or not in working order.</li><li>• The information in the operating instructions regarding the operation, maintenance, and installation of the LAMBDA TRANSMITTER E and connected components has not been observed.</li><li>• Unauthorized alterations to the construction of the LAMBDA TRANSMITTER E and connected components have been made.</li><li>• Components subject to servicing have not been checked properly.</li><li>• Repairs have been carried out incorrectly.</li><li>• The ingress of foreign bodies or an act of God has resulted in catastrophic damage.</li></ul>

### 2.2 Safety Symbols

---

The following designations and symbols for hazards, warnings, and information are used in these operating instructions:



**DANGER**

Indicates potential danger for personnel, particularly due to electrical equipment.



**WARNING**

Indicates potential danger for personnel due to incorrect handling of system components.



**IMPORTANT!**

Indicates a risk of damage to system components and potential functional impairments.



**NOTE**

Highlights information on the features of the system or system components and provides additional tips.

The operator must observe the legal accident prevention guidelines at all times and take all the appropriate measures to prevent personal injury and material damage.

### 2.3 Intended Use

---

The LAMBDA TRANSMITTER E continuous measuring system measures the O<sub>2</sub> concentration in non-combustible gases in the hyperstoichiometric range.

**Prerequisite**

All planning, mounting, installation, commissioning, maintenance, and repair work must be carried out by adequately trained personnel only and checked by experts.

You must make sure that:

**Correct Handling**

- The system is used in accordance with the technical data and specifications regarding usage, assembly, connection, ambient, and operating conditions (see the order documentation, user information, rating plates, and so on) and the documentation supplied.
- Users act in accordance with the local, system-specific conditions and with due consideration paid to operational hazards and specifications.
- All of the measures required to maintain the device (e.g. for transportation and storage, as well as maintenance and inspection requirements) are provided.

Intended use also includes:

- Observing all the information in the operating instructions.
- Carrying out all inspection and maintenance work.

### 2.4 Incorrect Usage

---

It is forbidden to use the device in any other way than described above. Incorrect usage can be hazardous.

If the measuring system is to be used in any other application in which its proper functioning cannot be ensured, consult the manufacturer beforehand.

### 2.5 Informal Safety Measures

---

The LAMBDA TRANSMITTER E must only be operated when all the safety equipment is in good working order.

The operator must take all the appropriate measures to prevent personal injury and material damage.

You must make sure that:

- The system is used in accordance with the technical data and specifications regarding usage, ambient, and operating conditions (see the order documentation, user information, rating plates, and so on) and the documentation supplied.
- Users act in accordance with the local, system-specific conditions and with due consideration paid to operational hazards and specifications.
- All of the measures required to maintain the device (e.g. for transportation and storage, as well as maintenance and inspection requirements) are provided.

If the system is used or handled incorrectly, this can pose a risk to health or cause material damage. To prevent damage, observe the safety precautions at all times.

If the LAMBDA TRANSMITTER E is used as a sensor in conjunction with a control system, the operator must ensure that a failure or malfunction cannot lead to operating conditions that cause damage or lead to other hazardous operating conditions.

To prevent malfunctions, which can cause personal injury or damage to the system either directly or indirectly, the operator must ensure that:

- The maintenance personnel can be alerted immediately and at any time.
- The maintenance personnel is qualified to respond to malfunctions on the LAMBDA TRANSMITTER E and associated system malfunctions correctly.
- The defective equipment can be switched off immediately if necessary.
- Switching off equipment does not indirectly cause further malfunctions.

The LAMBDA TRANSMITTER E is a high-quality electronic measuring system. It must be handled with care when it is removed from service, transported, and stored.

### 2.6 Danger from Electrical Power

---



**DANGER**

The LAMBDA TRANSMITTER E system components are designed for use in industrial power installations. When working on power connections or on live components, make sure that the power supply is switched off. Before reconnecting the power supply, install any shock protection devices that may have been removed. The relevant safety regulations must be observed at all times.

### 2.7 Hazardous Areas

---

The LAMBDA TRANSMITTER E is installed directly in the gas-carrying duct above the counterflange. When the LAMBDA TRANSMITTER E is removed, corrosive and/or hot gases can – depending on the device and, in particular, if the duct is pressurized – escape from the duct. This gas can cause serious injury if appropriate protection measures are not taken.



**WARNING**

If the duct is pressurized and corrosive gases and/or temperatures in excess of 200°C (390°F) are present in the gas duct, gas can escape from the duct when the LAMBDA TRANSMITTER E is removed. For this reason, you must observe the following:

- Switch the system off before you open it. If this is not possible, wear protective clothing and a mask.
- Attach warning signs in the vicinity of the mounting location.
- Close the opening immediately. Cover flange plates (dummy flanges) are available as accessories.



**WARNING**

The flange and the tube of the LAMBDA TRANSMITTER E is very hot. Cooling down before removing or wear protective gloves.

### 2.8 Removal from Service

---



**IMPORTANT!**

The LAMBDA TRANSMITTER E must not be switched off once it has been installed nor when the plant is shut down. Residual gases can cause corrosion and damage system components.

If the device is stored outdoors, it must be protected from the elements. It must always be stored in a dry place and, if possible, in its original packaging.

When decommissioning the device, protect the cable ends and connectors against corrosion. Corroded connectors can cause the device to malfunction.

Whenever possible, transport the device in its original packaging.

### 2.9 Alterations to the Construction of Devices

---

No alterations must be made to the construction of or equipment fitted to the LAMBDA TRANSMITTER E without the prior approval of the manufacturer.



### 3 General Description

#### 3.1 Theoretical Fundamentals, Measuring Principle

The O<sub>2</sub> measuring cell essentially comprises a zirconium dioxide solid electrolyte tube, which is sealed at one end. The internal and external surface is coated with layers of precious metal as electrodes. The crystal lattice of the zirconium dioxide solid electrolyte, which is doped with yttrium oxide or other rare earth oxides, contains oxygen vacancies to enable oxygen ion conductivity that increases exponentially with the temperature. The solid-electrolyte cell, which can be heated by means of an internal electric heater, is surrounded by a quartz or ceramic cladding tube. A sample gas flow (500 ml/h; 0.13 gal/h) passes through the cladding tube by means of a flow-control capillary and an Ejectorextraction system.




Fig. 3-1:  
Measuring principle of the  
LAMBDA  
TRANSMITTER E

Changes in the sample gas flow (e.g. as a result of pressure variations upstream or downstream of the capillary) are recorded by means of a differential pressure measurement and corrected by the microprocessor.

To determine the oxygen concentration in the sample gas, a DC voltage of between 0.4 and 1.0 V is applied to the electrodes in the cell (at an operating temperature of >800 °C/1,470 °F); the oxygen ions flowing through the solid electrolytes are measured using a milliammeter. All the oxygen in the sample gas ionizes under the influence of the direct-current voltage at the negative outer electrode.

## General Description - Theoretical Fundamentals, Measuring Principle

The negative oxygen ion flow is transported to the positive internal electrode and is discharged to form molecular oxygen. A linear correlation exists between the ionic current, which is measured as the probe current signal, and both the oxygen concentration and sample gas quantity that passes through the cell in each time unit.

Calibrating this in line with a gas with a known oxygen concentration (preferably air with 20.96 vol. % O<sub>2</sub>) enables the sample gas flow rate to be determined. Variations in the sample gas flow rate are compensated by means of the differential pressure compensation.




Fig. 3-2:  
Structure and function of  
the LAMBDA  
TRANSMITTER E oxygen  
probe

This characteristic shows that it is not necessary to know the proportionality factor or the measuring gas quantity in order to measure the oxygen. It is sufficient to assign the oxygen concentration ( $O_2 = 21\%$ ) to the probe current measured with air  $I_{\text{air}}$  and then draw a straight line to the zero-point ( $I = 0; O_2 = 0$ ) through the calibration point derived in this way. In practice, this means that the probe can be easily aligned and adjusted by assigning  $\sim 21 \text{ Vol. \% O}_2$  to the measured air value (20.96).

If the cell is structured appropriately and a suitable voltage is applied, the linear characteristic of the probe depends solely on the sample gas quantity, which governs the gradient of the straight lines (see diagram).

The temperature of the solid electrolytes and the electrodes is not explicitly incorporated in the probe signal, although it does determine the internal resistance of the probe or its limit current and, in turn, the measurable oxygen concentration range.

The probe temperature does not need to be measured or regulated, but it must be ensured that it does not undershoot a defined critical value, which depends on the required measurement range. To measure oxygen concentrations of up to 21 vol. % (atmospheric oxygen) the minimum probe temperature is 800°C (1,470 °F), for example. The static probe characteristic  $I = f(O_2)$  in the diagram shows that the measurement accuracy is generally stable, regardless of the probe temperature and oxygen concentration.

Using a current-proportional probe voltage and by compensating pressure and temperature effects on the flow-control capillary, a measurement accuracy of more than  $\pm 0.2$  vol.% oxygen in flue gases of all common fuels can be achieved, even when measured values are not compensated.

Probe (measuring cell) ageing is compensated by measuring the internal cell resistance and, in turn, adjusting (increasing) the temperature of the measuring cell over a broad range, and therefore does not affect the measurement accuracy.

Long-term experience of operating the device under difficult conditions (e.g. incineration of industrial waste, waste incineration, bio/sewage gas, etc.) has shown that the measuring principle is extremely resistant to contamination provided that the LAMBDA TRANSMITTER E is used properly.

Cross-sensitivity with non-combustible gas components (e.g. H<sub>2</sub>O, N<sub>2</sub>, CO<sub>2</sub>, NO<sub>x</sub>, SO<sub>2</sub>, etc.) is not an issue. When oxygen is present, combustible gas components are burnt off on the platinum-coated surface of the sensor, which is approx. 800 °C (1,470 °F),.

Example:  $2CO + O_2 = 2CO_2$

This means that with 1 vol. % CO in the measuring gas, 0.5 vol. % oxygen too little is displayed. For this reason, this measuring principle is not suitable for measuring oxygen in combustible gases.



### NOTE

The amperometric measuring principle of the Lambda transmitter yields an almost linear sensor characteristic. This characteristic passes through zero and its gradient is determined by an Calibration point. When the measurement is taken in ambient air with an oxygen concentration of  $\psi_{cal} = 20.96$  vol. %, this point is normally derived by determining the probe current  $I_{cal}$  [mA]. .

With respect to the measured probe current  $I$ , the ideal oxygen concentration ( $\psi_{O_2}$ ) of any measuring gas is governed by the following formula:

$$\psi_{O_2,ideal} = \psi_{cal} \times I / I_{cal} \quad \text{Gl. (1)}$$

Depending on physical and design aspects, the LAMBDA TRANSMITTER E probe current depends not only on the oxygen content of the measuring gas, but also on the gas temperature (T), the differential pressure ( $\Delta p$ ), the absolute pressure upstream of the flow-control capillary, the average molecular weight ( $M_m$ ), and a function of the mean isentropic exponents ( $F(\Delta)$ ) of the measuring gas in relation to the Calibration conditions (index "cal"):

$$\psi_{O_2} = \psi_{O_2,ideal} \times p_{cal} / p \times (T/T_{cal})^{1/2} \times (M_m/M_{m,cal})^{1/2} \times F(\psi_{cal}) / F(\psi) \quad \text{Gl. (2)}$$

To compensate these fault effects, the GM 302 oxygen analyzer features the following measured value corrections:

- Temperature compensation
- Pressure compensation
- Flow Rate Compensation

See also chapter 3.1.5

### 3.1.1 Housing Versions

---

The LAMBDA TRANSMITTER E is supplied with one of two types of housing:

- Sheet-steel housing
- Cast-aluminum housing

The two types of housing have a different internal structure but identical function.

### 3.1.2 General Functional Description

---

The LAMBDA TRANSMITTER E is a versatile, microprocessor-based O<sub>2</sub> measuring device for taking direct measurements of the O<sub>2</sub> concentration of non-combustible gases in the hyperstoichiometric range ( $\lambda > 1$ ). The measuring method is based on the tried-and-tested ZrO<sub>2</sub> current measuring principle. The measured values are output via an analog output with 0/4 to 20 mA or 0 to 10 V. The device can be operated via a display/control unit, a PC in conjunction with the remote display software, or via a remote display connected to the LAMBDA TRANSMITTER E via the LSB bus.

### 3.1.3 Advantages of the LAMBDA TRANSMITTER E Measuring Principle

---


- Quasi-linear measurement signal with fixed zero-point
- Calibration with ambient air (no special measuring gases required)
- High measuring accuracy (better than 0.2 vol.% O<sub>2</sub> in the range 0 to 21 vol.% O<sub>2</sub>)
- Automatic probe checks and Calibration using compressed air
- No mechanical pumps
- Sensor element outside of the flue gas system (stack), no ignition source in the flue gas duct (TUEV confirmed)
- Test gas temperature of max. 950 °C (1,740 °F) with metal extraction and up to 1,600 °C (2,900 °F) with ceramic gas extraction device
- No gas preparation required, measurement directly in the humid flue gas
- A small measuring gas quantity (approx. 0.5 l/h; 0.13 gal/hr) means that the measuring gas temperature does not affect the measurement accuracy. The sensor system itself is located outside the flue gas system.
- Rapid response time of the entire system ( $T_{90}$ ) < 20 seconds with standard extraction (insertion depth: 500 mm/ 19.7 in)
- No reference gas required
- No temperature control required in the measuring cell
- Simple operation
- IP 66 (protection class) for ambient temp. of -20 °C to +55 °C (-4 to +130 °F)
- The ZrO<sub>2</sub> sensor, heater, and all gas-carrying components can be easily replaced by the end customer.
- Electrical contacting outside the flue gas
- Wide range of applications
- The measuring gas-side components are identical to those in the previous system.
- Maintenance free

## General Description - Theoretical Fundamentals, Measuring Principle

### 3.1.4 Influence of Air Humidity on the Calibration Value of 20.96 vol.% O<sub>2</sub>

The calibration procedure of the LAMBDA TRANSMITTER E takes place by using compressed air. In order to consider the relative humidity of the compressed air used for the calibration procedure a calibration offset (parameter 297) has to be set. The setting of the calibration offset parameter (P297) at works: -0.1 vol% of O<sub>2</sub>.

The influence of the rel. humidity of air in relation to the air temperature is shown in the following diagram.



Influence of air humidity on the O<sub>2</sub> calibration value of 20.96 vol.%

## 3.1.5 Flow Rate Compensation

The flow rate through the capillary depends on the average molecular weight/gas constants of the gas to be measured. With "normal" flue gases from oil, gas, and coal firing, the effect on the measurement accuracy is insignificant. The measurement error is within the specified measurement accuracy of  $\pm 0.2 \text{ vol. \% O}_2$

The following diagram shows the fault effect for different fuels. This arises from the correlation between the sample gas flow rate and the average molecular weight/gas constants of the flue gas. The diagram shows the typical ratio of  $\text{CO}_2$  to  $\text{H}_2\text{O}$  in the flue gas (calibration with dry air).




Fig. 3-3:  
Fault effect for different fuels



### NOTE

Fuel-specific flow rate compensation is deactivated by default. It can be activated via parameter 836.

Fuel-specific flow rate compensation

Fuel-specific compensation is set via parameter group 835 - 899.

Correction of measured values

Measured values are corrected via parameters 1280 to 1283. This is recommended in the following cases:

- High level of humidity ( $\text{H}_2\text{O}$ ) and low  $\text{CO}_2$  content (e.g. downstream of wet scrubber)
- High  $\text{CO}_2$  content and low  $\text{H}_2\text{O}$  content

## 3.1.6 Cold-Start Delay

The LAMBDA TRANSMITTER E features an intelligent cold-start delay function, which prevents flue gas from passing through a cold probe. The optimum time for switching on the measuring gas pump is governed by the temperature of the zirconium dioxide measuring cell, which is determined by measuring the internal cell resistance during the warm-up phase.

The cold-start delay is always activated after the power has been switched off. This can be interrupted at any time, provided that the measured temperature in the area of the capillary exceeds 260°C:

- Via the multi-function key
- Via the remote display software
- Via the display/control unit
- Via the remote control unit (in preparation)

During the cold-start delay, the system outputs either a substitute value or the "current measured value".

Factory setting: non substitute value.  
Set via parameters 361 and 362.




Fig. 3-4:  
Intelligent cold-start delay

### 3.1.7 Cold start Ri-table (Parameter 1984..1999)

---

During the cold start the internal resistance (Ri) is measured, in order to recognize the heating condition of the probe. The determined values are put in the cold start Ri-table. On the base of these values a diagnostic of the cold start process is possible, otherwise they have no function. With an restart the values are deleted and again filled by the following cold start. Not used values are set to „0“.

### 3.1.8 Ri-table (last Ri-value Parameter 1800...1898)

---

Last measured Ri-value and Ri-table belongs together. The internal resistance and the heating power in the course of probe aging are stored. In the first entry of this history (last measured Ri-value), the internal resistance determined with the last aging compensation is put down in each case as well as the heating power and the time (operation hours). In the remaining parameters entries are put down, as soon as the heating power was changed by the aging compensation.

After exchange of the sensor (Par. 104) this history will be deleted.

### 3.1.9 Aging compensation

---

The aging of the sensor is compensated by increasing of the heating power. The internal resistance of the ZrO<sub>2</sub>-sensor is measured and if necessary an aging compensation (increasing the heating power) is accomplished. This takes place after the 1. calibration after coldstart and then approx. 1x per week (every 10000 minutes). The measured internal resistance of the sensor (Ri) is registered into the table in Par.1805...1898. Thus the aging of the sensor can be supervised.



#### CAUTION!

After exchange of the sensor the heating power must be reset on the basic value. Set Parameter 104 on „Release“ and acknowledge with „Enter“. If the instruction is implemented, the parameter 104 jumps back to "0".

### 3.1.10 Calibration history (Parameter 1570...1791)

---

In the calibration history with each accomplishing automatic calibration a data set is stored. The data records are sorted, the last calibration is always put down in cal. history 1. If by the automatic calibration new data records are added, older data records are overwritten, simply the oldest data records are however not deleted, separate always temporally at closest placing overwritten, so that always a complete overview of the entire is presented. The parameters put down in the respective data record are self-describing. they correspond to the actual values of the parameters 74, 76, 54, 53, 51, 57, 18 and 5 available at the end of the calibration.

By means of Par. 119 the calibration history can be deleted.



### 3.1.11 Calibration drift history (Parameter 3600...3679)

---

In this history is stored the change of the O<sub>2</sub>-value of the last 40 automatic calibrations, together with the time (operation hours), so that e.g. the probe drift with a cyclic calibration every 24 hours for the last 40 days is available.

This history is sorted, the newest entry always stands at the beginning.

Examples for text + parameter in the display:

**\*\*Calibration Drift History\*\***

Operating Hours

Par. 3600: 7430 h

Calibration modified about

Par. 3601: -0,07 %

Operating Hours

Par. 3602: 7454 h

Calibration modified about

Par. 3603: +0,03 %

e.c. up to Par. 3679

Not used values are setted to „0“.

The values can be read out via the display or via the Remote-Display-Software.

The parameters can also be queried via a Profibus-interface, which is connected to LSB.

The output of the datas via CANopen-protocol is not be possible.

# General Description - General View

## 3.2 General View

Fig. 3-5:  
LAMBDA  
TRANSMITTER E





Fig. Obligations and Liability 3-6:  
LAMBDA TRANSMITTER  
E mounted on the flue gas  
duct (side view)



## 3.2.1 LAMBDA TRANSMITTER E in Sheet-Steel Housing




Fig. 3-7: Front view of electronics section



**DANGER**

Before opening the internal door (entry electronic section) disconnect line voltage !!

## General Description - General View




Fig. 3-9:  
Connection side






Fig. 3-10:  
Suitable cable connection



## General Description - General View

### 3.2.2 LAMBDA TRANSMITTER E in Cast-Aluminum Housing


Fig. 3-11:  
Front view of electronics  
section



**DANGER**

Before opening the internal door (entry electronic section) disconnect line voltage !!

Fig. 3-12:  
Internal view of electronics  
section



# General Description - General View

Fig. 3-13:  
Connection side





Fig. 3-14:  
Suitable cable  
connection



3.3 Probe ChapterView

Fig. 3-15:  
Probe chapter  
(side view)





Fig. 3-16:  
Probe chapter  
(connection side)






## 3.4 Gas Extraction Device (GED)

### 3.4.1 View of Gas Extraction Device

Fig. 3-17:  
Detailed view of gas  
extraction device



### 3.4.2 Test Gas Temperatures

Up to 700 °C (1,290 °F)	Standard		
	Capillary tube:	Material:	2.4851 (Alloy 601)
	Extraction attachment:	Material:	1.4762
	Sintered metal filter:	Material:	Hastelloy X
	Protective pipe:	Material:	1.4571 up to 700 °C (1,290 °F)
	Pre-filter:	Material:	Hastelloy X
Up to 950 °C (1,740 °F)	Inconell 600		
	Capillary tube:	Material:	2.4851 (Alloy 601)
	Extraction attachment:	Material:	1.4762
	Sintered metal filter:	Material:	Hastelloy X
	Protective pipe:	Material:	Inconell 600
	Pre-filter:	Material:	Hastelloy X
From 950 °C to 1,400 °C (1,740 °F) to (2,550 °F)	Ceramic		
	Ceramic gas extraction device		
	Capillary tube:	Material	Al <sub>2</sub> O <sub>3</sub>
	Protective pipe:	Material	Al <sub>2</sub> O <sub>3</sub>
	Pre-filter:	Material	Al <sub>2</sub> O <sub>3</sub>
	Filter mesh:		50 µm
Up to 1,600 °C (2,910 °F)	Available on request		
Below 180 °C (355 °F)	Please note:		
	The temperature across the entire length of the gas extraction device (capillary), including the sintered metal pre-filter, must be above the dew point (water/acid dew point). This means:		
	Highly sulfurous fuels (heavy-grade oil, coal):		above 180 °C (355 °F)
	Gas:		above 80 °C (175 °F)
	Light fuel oil:		above 120 °C (250 °F)
	If this cannot be ensured, the gas extraction device and, if necessary, the sintered metal pre-filter must be heated (see chapter 4.5).		

## General Description - Gas Extraction Device (GED)



### IMPORTANT!

In double-wall stacks, a heater for the gas extraction device is required. With flue gases that are 100% saturated (exhaust vapors), a sintered metal pre-filter must also be used.




Fig. 3-18:  
Installation planning aid,  
max. temperatures




Fig. 3-19:  
Using a gas extraction  
device and filter heater

### 3.4.3 Insertion Depth

- Max: 3 m (9.9 ft)
- Recommended: only as long as required (1/4 – 1/3 of the duct cross-section)

#### Worth Knowing:

The "core flow measurement", which is often required, is often not necessary. "Strands" are, in practice, very rare. Experience has shown that they occur under the following conditions:

- When gases of different temperatures collide (usually re-circulated air and flue gas).
- With gas velocities less than 1m/s (3.2 Ft/sec) (separation).

## General Description - Protective Pipe with Aluminum Core

---

If genuine "strands" occur, however, it is extremely difficult to find an extraction location above the insertion depth of the measuring gas sampler that is suitable for all operating conditions.



**IMPORTANT!**

With horizontal installation, it is recommended that the protective pipe for the gas extraction device be supported as of the following gas extraction device lengths.

Standard: above 1,000 mm (39.4 in)  
Ceramic protective pipe: above 1,000 mm (39.4 in)  
Protective pipe with heater for gas extraction device: above 1,000 mm (39.4 in)  
With additional filter heater: from 1,000 mm (39.4 in)

The protective pipe support is supplied for the appropriate insertion depth.

If the measuring point is subject to vibrations, support should be provided for the protective pipe for the gas extraction device with shorter gas extraction device lengths.

### 3.5 Protective Pipe with Aluminum Core

---

The protective pipe with an aluminum core ( standard ex immersion depth >500mm) distributes the heat of the measuring gas equally across the entire length of the gas extraction device. An electrical heater is not usually needed.

Protective pipe with aluminum core without heater: Type 6 57 R 3441...R 3444.



**IMPORTANT!**

With horizontal installation, it is recommended that the protective pipe for the gas extraction device be supported with lengths of > 1000 mm (3.9 in). The protective pipe support is supplied for the appropriate insertion depth.

If the measuring point is subject to vibrations, support should be provided for the protective pipe with shorter gas extraction device lengths.

Protective pipe support type 657R3520

### 3.6 Conformity

---

LAMBDA TRANSMITTER E

- Complies with the currently applicable VDE (Verein Deutscher Elektroingenieure) regulations.
- Fulfills the requirements of the Federal German Pollution Control Act (13<sup>th</sup> and 17<sup>th</sup> Implementing Ordinances) and the German Clean Air Act (TA-Luft).  
Proof No.1: 205 155 98 N2-EP GM302  
Proof No.2: 936 / 21203535 / B
- Complies with the "minimum requirements for emissions-related measuring devices" of the federal environment office in accordance with the guidelines for the performance testing, installation, calibration, and maintenance of systems for continuous emissions measurements.

## 4 Installation

### 4.1 Prerequisites

Before installation, the following points must be taken into account:

Measuring location

The measuring location must be easily accessible. The weight of the LAMBDA TRANSMITTER E is about 30kg.

Measuring gas temperature

Condensation must not be allowed to form at the water/acid dew point in the gas extraction device. The temperature along the entire length of the gas extraction device must, therefore, be above the dew point.

Guide values for temperature:

- Light hydrocarbons (e.g. natural gas, propane, butane, hydrogen, etc.) > 80 °C (176 °F)
- Light fuel oil > 120 °C (248 °F)
- Fuels (e.g. fuel oil S, coal, pyrolysis gases, etc.) in which high levels of SO<sub>2</sub>, HCL, or corrosive substances are likely to form. > 180 °C (355 °F)



#### IMPORTANT!

If the temperature anywhere on the gas extraction device is below the dew point, a heater is required for the gas extraction device (see chapter 3.4.2, Fig 3.18/19). In double-wall stacks, a heater for the gas extraction device is required. With flue gases that are 100% saturated (exhaust vapors), a sintered metal pre-filter must also be used.



#### NOTE

Corrosion on the gas extraction device indicates that the temperature is below the dew point. If the gas extraction device is blocked, this is a sure sign that the temperature has fallen below the dew point. The desired temperature control value should never be set higher than required. The greater the heat output, the shorter the service life of the heater.

Type of gas extraction device

Usage limits for the gas extraction device material:

- Standard stainless steel (material 1.4571): Up to 700 °C (1,290 °F)
- Inconel: Up to 950 °C (1,740 °F)
- Ceramic: Up to 1,400 °C (2,552 °F)
- Versions up to 1,600 °C (2,910 °F) on request

Dust content

When a high dust content or abrasive flue gas constituents are present, an extra protective pipe (for high-dust applications) must be used for the gas extraction device. See chapter 10.11.

Length of gas extraction device

The length of the gas extraction device (GED) should always be kept to a minimum. The probe should be attached as close as possible to the measuring point (duct).

## 4.2 Counterflange Assembly (Optional Accessory)

1. Plan the mounting position.  
It can be mounted in any position between  $-20^\circ$  of the vertical axis to the horizontal axis.  
Connection side below.




Fig. 4-1:  
Mounting position

2. Flame-cut a hole with a diameter of 125 mm (5 in) in the flue gas duct.



### WARNING

When you create the apertures, parts that fall into the duct may cause damage. For this reason, a wire must be used to secure parts that are to be cut away. Appropriate measures must be taken to protect against hot, explosive, or poisonous flue gases that may escape.

3. Align the counterflange (see diagram) and weld it securely to the measuring point.  
The two threaded holes (M8) must face up/down.

Isolation waterproof and thermic




Fig. 4-2:  
Align the counterflange with  
the measuring point and  
weld on.

4. Seal the aperture with a dummy flange
5. **The neck must be isolated waterproof and thermic.**




### CAUTION!

If the neck is not be isolated, maybe you will be get dep point falling. This can falsify the measured value.


**4.3 Installing the Gas Extraction Device (GED) and the Protective Pipe for the GED**

Fig. 4-3:  
Installing the gas extraction device and protective pipe for the gas extraction device (work steps specified)



**IMPORTANT!**  
All glands and threads must be treated with anti-seize paste (type 650 R 1090).

1. Remove the protective cap from the measuring gas inlet.
2. Mount the gas extraction device (**a**) and carefully secure (max. 6 Nm.).
3. Screw in the absolute pressure capillary (**b**) by hand.
4. Install the protective pipe (**f**) with the sintered metal filter (**d**) on the probe installation fitting.
5. Align the baffle plate (**c**) in such a way that it protects the filter (**d**) against contamination. The filter should be located in the "wake region".



Direction of measuring gas flow

Tighten the nut on the pre-filter.



**IMPORTANT!**  
The sintered metal filter is very fragile. Once installed, Calibration cannot be carried out without the filter.

6. Attach the aperture securing mechanism (**e**) for the protective pipe (**f**) for the GED.

## 4.4 Electrical and Pneumatic Connections



**CAUTION!**

**Observe the line voltage !!!**

Factory default is AC230V.

For changing over to AC115V see chapter 12.4.1



**IMPORTANT!**

The LAMBDA TRANSMITTER E must only be operated when the ambient temperature is between -20 °C and +55 °C (-4 °F and 130 °F).




Fig. 4-4:  
Pneumatic connection



Fig. 4-5:  
Connections at the sheet-steel housing



Fig. 4-6:  
Connections at the cast-aluminum housing




Fig. 4-7:  
Compressed air unit



Fig. 4-8:  
Compressor unit

### Prescribed hose cross-sections

Distance of 6 x 1 mm (0.04 in) to 2 m (6.6 ft) between the pressure control valve and the LAMBDA TRANSMITTER E, 10 x 1 mm between the compressor unit and LAMBDA TRANSMITTER E. A reducer to 6 x 1 mm is supplied. If distances are larger, the cross-sections must be adjusted accordingly. Alternatively, PA or PTFE hose may be used depending on the system-specific conditions.

PUN hose - 6 x 1 mm (0.04 in), type 657 P 0547



#### IMPORTANT!

Two separate pressure control valves must always be provided for the Ejectorpump and calibration. The two proportional valve control loops would otherwise affect each other, which could critically impair automatic calibration and, in turn, the function and measurement accuracy too.



#### NOTE

If the device is installed in a location that is difficult to access, it is recommended that the probe chapter be installed separately from the electronics chapter (see chapter 8.6 "Removing the Probe Body").



#### NOTE

When installing the LAMBDA TRANSMITTER E on the counterflange at temperatures above 200 °C (392 °F), a second seal (type 657 R 3542) is recommended for heat



isolation.

## Installation - System Settings in Accordance with System Composition (Reduced to Case Studies)

### 4.5 System Settings in Accordance with System Composition (Reduced to Case Studies)

System Composition						System Settings in the Transmitter				on power supply unit for GED heater
Case	MEV heater	Filter heater	RS422-GM31 connection	EVU 31	LSB module(s)	Optional 2nd RS422 (10.12)	Par 121	Par 3895	Par 402	DIP switch SW1 (4.6.5)
1	0	0	0	0	0	no	no heater	LSB	default	ON
2	0	0	0	0	1	no	no heater	LSB	default	ON
3	0	0	0	1	0	no	no heater	CAN	default	OFF
4	0	0	1	0	0	no	no heater	LSB	default	ON
5	1	0	0	0	0	no	MEV heater	LSB	default	ON
6	1	0	0	0	1	no	MEV heater	LSB	default	ON
7	1	0	0	1	0	no	MEV heater	CAN	default	OFF
8	1	0	1	0	0	yes	MEV heater	LSB	default	ON
9	1	1	0	0	0	no	MEV/filter heater	LSB	default	ON
10	1	1	0	0	1	no	MEV/filter heater	LSB	default	ON
11	1	1	0	1	0	no	MEV/filter heater	CAN	default	OFF
12	1	1	1	0	0	yes	MEV/filter heater	LSB	default	ON

- The variants with ONLY a filter heater have been omitted (inapplicable).
- RS422 on board: can be switched between RS422 and CAN/LSB (using the jumper setting, see chapter 12.5.1). Used with the gas extraction device/filter heater ('LSB') OR for LSB modules ('LSB') OR for the RS422 GM31 connection ('RS422').
- Second optional RS232 interface: if the RS422 GM31 connection is used and the first RS422 interface is assigned to the gas extraction device/filter heater ('LSB') OR LSB modules ('LSB').
- Evaluation unit and the RS422 GM31 connection are mutually exclusive.
- Evaluation unit requires the CAN bus.
- LSB modules require the LSB bus.
- Evaluation unit and LSB modules are mutually exclusive.
- Parameter 121: no heater/gas extraction device heater/gas extraction device/filter heater
- Parameter 3895: when operated with Evaluation unit on CAN/when operated WITHOUT Evaluation unit on LSB
- Parameter 402: default temperature for gas extraction device heater: can remain at default setting (250 °C/482 °F)
- Parameter 058: "Measured temperature value from gas extraction device heater": measured value only. Not variable.

## 4.6 Installing the Gas Extraction Device and Pre-Filter Heater (Optional)




Fig. 4-9:  
Components of the gas extraction device and pre-filter heater  
Connection cable length: 2 m (extension connectors not supplied, see 4.6.8)

- |  |  |
|--|--|
| <b>a</b> Gas extraction device with sampling filter  | <b>h</b> Securing mechanism for protective pipe (incl. 2 splints)  |
| <b>b</b> Absolute pressure capillary   | <b>i</b> CU seal for protective pipe   |
| <b>c</b> Protective pipe with heater for gas extraction device                               | <b>j</b> Cutting ring (2x)   |
| <b>d</b> Heater for filter attachment  | <b>k</b> Screw caps (2x)   |
| <b>e</b> Threaded connector ends through which the connection cables are fed                 | <b>l</b> Baffle plate with filter attachment 20µm  |
| <b>f</b> Connection flange for gas extraction device heater (incl. 2 M8 x 35 securing bolts) | <b>m</b> Protective pipe support   |
| <b>g</b> DN80PN6 flange seal<br>Type 657R3542  | <b>n</b> Cable box for gas extraction device and pre-filter heater (power pack), incl. feeder and 5m LSB/CAN-line for connection to LT-E |




Fig. 4-10:  
Installing the gas extraction device and pre-filter heater

## Installation - Installing the Gas Extraction Device and Pre-Filter Heater (Optional)

---



**IMPORTANT!**

All glands and threads must be treated with anti-seize paste (type 650 R 1090).

## Installation - Installing the Gas Extraction Device and Pre-Filter Heater (Optional)

---

1. Attach the connection flange (f) on the LAMBDA TRANSMITTER E .  
Use the M8 x 35 screws provided.  
Place flange seal DN80 (type 657 R 3540) (g) between the flanges.
2. Mount the gas extraction device (a) on the probe and secure (max. 6 Nm.).
3. Attach the absolute pressure capillary (b).
4. Push the screw caps (k) and the cutting ring (j) over the connection cable for the heater for the gas extraction device.
5. Route the connection cables with the screw cap and cutting ring through the threaded connector end (c) on the flange (affix the insulating hose at the end with insulating tape).
6. Insert the CU seal (i) in the probe. Mount the protective pipe with the heater (c) for the gas extraction device on the probe and secure. The filter should be located in the "wake region".
7. Tighten the second screw cap (k) on the connection flange (f).
8. Align the baffle plate with the filter attachment (l) in such a way that it protects the filter against the flow in the duct (see chapter4.3).
9. Tighten the nut on the pre-filter.



### IMPORTANT!

The sintered metal filter is very fragile. Once installed, Calibration cannot be carried out without the filter.

10. Install the aperture securing mechanism for the protective pipe (h) and secure using the two splints provided.
11. Push the screw caps (k) and the cutting ring (j) over the connection cable for the pre-filter heater (d).
12. Route the connection cable for the pre-filter heater (d) through the second threaded connector end (e) on the connection flange (f).
13. Place the pre-filter heater (d) on the filter attachment (l).
14. Tighten the second screw cap (k) on the connection flange (f).
15. If the insertion depth is greater than 1,000 mm (39.4 in), the support (m) supplied in the set must also be attached.
16. Install the LAMBDA TRANSMITTER E on the counterflange using the flange seal (657 R 3542).  
See "Installing the LAMBDA TRANSMITTER E".
17. Establish the electrical connections for the gas extraction device and pre-filter heater on the power pack (type 657 R 3160).
18. Connect the power pack (chapter4.6) and LAMBDA TRANSMITTER E using a 7-pin connector.
19. When the LAMBDA TRANSMITTER E and the power pack are switched on, the gas extraction device and pre-filter heater are recognized automatically.



### IMPORTANT!

The heater must be in contact with the filter to ensure good heat transmission.

## Installation - Installing the Gas Extraction Device and Pre-Filter Heater (Optional)

### 4.6.1 Power Pack for the Gas Extraction Device and Pre-Filter Heater



**CAUTION!**

**Observe the line voltage !!!**

Factory default is AC230V.

For changing over to AC115V see chapter 4.6.4

A separate power pack is required to electrically heat the gas extraction device and the sintered metal pre-filter.

Note: this is supplied in the "gas extraction kit with heater for gas extraction device" and "gas extraction kit with gas extraction device and filter heater".

Version: Wall-mounted housing IP 65

Features: Configurable heat output using LAMBDA TRANSMITTER E

Interface: LSB or CANopen for data connection to  
LAMBDA TRANSMITTER E




Fig. 4-11:  
Power pack for electrically  
heating the gas extraction  
device and sintered metal  
pre-filter

# Installation - Installing the Gas Extraction Device and Pre-Filter Heater (Optional)

## 4.6.2 Power Pack Connections

4-pin power connection:  
230 V AC / 50-60 Hz, or  
115 V AC / 50-60 Hz  
(disconnect transformer,  
replac F1, see 4.6.3)

7-pin LSB/CAN connection to  
LAMBDA TRANSMITTER E .  
7-pin LSB/CAN connection to  
other devices with a LSB/CAN  
terminal

1 - L  
2 - N  
3 -  
4 - PE


1 - NC  
2 - CAN GND  
3 - CAN low  
4 - CAN high  
5 - GND from EVU  
6 - +24 V from EVU  
7 - PE

Power consumption:  
gas extraction device  
only: max. 400 VA, gas  
extraction device and pre-  
filter: max. 500 VA

Fig. 4-12:  
Connection side


M20 cable bushing passages for pre-filter heater.  
M20 cable bushing passages for gas extraction device heater with PT100.

Fig. 4-13:  
Suitable cable  
connection



## Installation - Installing the Gas Extraction Device and Pre-Filter Heater (Optional)

### 4.6.3 Electronics Board of the Power Pack



### 4.6.4 Switching over the line voltage from AC230V to AC115V (if required)

- 1.) Changing main fuse F1  
New value 6,3A slow-blow
- 2.) Remove bypass connector X2
- 3.) Switch over trafo connector from X1 to X2



## Installation - Installing the Gas Extraction Device and Pre-Filter Heater (Optional)

### 4.6.5 Function of the LEDs on the Power Pack Board:

Interface LEDs 2 and 4

green = receive, yellow = send.

When operating normally, the gas extraction device heater sends a short data packet every two seconds, (i.e. the yellow LED flashes briefly every two seconds); the green LED flickers irregularly as it shows all bus activity.

Three green LEDs are located between the PT100 terminal and the heater terminals. From left to right:

LED 5 (green, on the left): shows operating voltage, permanently lit.

LED 1 (green, center): shows whether the gas extraction device heater is switched on or off.

LED 3 (green, on the right): shows whether the filter heater is switched on or off.

If a defect is detected on one or both heaters (normally a defective heater or fuse), the corresponding LED flashes very rapidly (approx. every 0.2 sec instead of every second). A current of approx. 0.6 A must be flowing through the filter heater and 1.3 A through the gas extraction device heater to trigger monitoring.

### 4.6.6 Assignment of DIP-switches on the board of the power pack


SW 1 OFF	CAN
SW 1 ON	LSB (software version 4V24a or more recent)

SW2 (only relevant for standalone versions)	
SW 2 OFF	Gas extraction device + filter heater
SW 2 ON	Gas extraction device heater only

SW9 to SW12 determine the default required temperature of the GED-heater, if communication is not taking place (standalone). Otherwise, the temperature set in P402, is used for controlling.				
SW9	SW10	SW11	SW12	Required temperature
0	0	0	0	200 °C (392 °F)
0	0	0	1	100 °C (212 °F)
0	0	1	0	120 °C (248 °F)
0	0	1	1	140 °C (284 °F)
0	1	0	0	160 °C (320 °F)
0	1	0	1	180 °C (356 °F)
0	1	1	0	190 °C (374 °F)
0	1	1	1	200 °C (392 °F)
1	0	0	0	210 °C (410 °F)
1	0	0	1	220 °C (428 °F)
1	0	1	0	230 °C (446 °F)
1	0	1	1	240 °C (464 °F)
1	1	0	0	260 °C (500 °F)
1	1	0	1	280 °C (536 °F)
1	1	1	0	300 °C (572 °F)
1	1	1	1	OFF

## Installation - Installing the Gas Extraction Device and Pre-Filter Heater (Optional)

### 4.6.7 Electrical Connection to LAMBDA TRANSMITTER E



### 4.6.8 Setting the LAMBDA TRANSMITTER E and the Power Pack (See also Chapter 4.5)

Check DIP switch 1 on the power pack electronics board and the parameter setting in LAMBDA TRANSMITTER E .

Set DIP switch 1 on the power pack electronics board:

- To “ON” during operation without an evaluation unit (LSB operation)
- To “OFF” during operation with an evaluation unit (CANopen operation)

Set the parameters (service level) in LAMBDA TRANSMITTER E as follows:

- Parameter 121: “gas extraction device heater“ or “gas extraction device and pre-filter heater”
- Parameter 402: “required gas extraction device temperature 250 °C (482 °F)”
- Parameter 3895 when operating without evaluation unit set to: “LSB”
- Parameter 3895 when operating with evaluation unit set to: “CANopen”

Reading parameter (measured value):

- Parameter 058: gas extraction device temperature “xx °C”



#### NOTE

If control via CANopen or LSB fails, the temperature setting for DIP switches SW9 to SW12 are still used (chapter 4.6.5).

## Installation - Installing the Gas Extraction Device and Pre-Filter Heater (Optional)

### 4.6.9 Cable Connectors for Extending Gas Extraction Device and Pre-Filter Heater

2-pole (for pre filter heater):



Length 100mm  
External diameter 24mm  
Conductor 2,5 sqmm  
Diameter cond. min 5mm, max 12,5mm,  
Item no. 657R3167

5-pole (for GED heater with Pt100):


Length 150mm  
External diameter 35mm  
Conductor 2,5 sqmm  
Diameter cond. min 10mm, max 19mm,  
Item no. 657R3168

Type of protection IP67

Range of temperature -20°C...+66°C




### 4.6.10 Dimension Drawing of the Power Pack



**4.7 Installing the Protective Pipe for High-Dust Applications**

Fig. 4-14:  
Components of the model  
for high-dust applications



- a** Counterflange
- b** Flange seal for counterflange
- c** Protective pipe for gas extraction device for high-dust applications
- d** Adapter flange for heater for MEVprotective pipe
- e** Grub screw
- f** M8 x 25 hexagon socket screws with spring washer for securing the adapter flange to the counterflange
- g** Flange seal for adapter flange
- h** Seal set







Fig. 4-15:  
Installing the model for  
high-dust applications



**IMPORTANT!**  
All glands and threads must be treated with anti-seize paste (type 650 R 1090).

## Installation - Installing the Protective Pipe for High-Dust Applications

---

1. Push the flange seal (b) over the threaded rods of the counterflange. The counterflange must already be welded onto the flue gas duct.
2. Screw the protective pipe for high-dust applications (c) into the adapter flange (d).
3. Align the protective pipe for high-dust applications (c) with the flow direction of the flue gas and secure it using the grub screw (e).
4. Push the adapter flange (d) with the protective pipe for high-dust applications (c) over the threaded rods of the counterflange and secure it using the two M8 x 25 hexagon-socket screws with the spring washer (f).
5. Place the flange seal for the adapter flange (g) between the threaded rods of the counterflange (a).
6. Attach the seal set (h) to the probe unit on the LAMBDA TRANSMITTER E . Make sure that you do this in the correct order:
  - h1: Pressure disk
  - h2: Graphite seal for high-dust applications
  - h1: Pressure disk
  - h3: Disk springs
7. Remove the baffle plate from the filter attachment.
8. Install the gas extraction device and the protective pipe for the gas extraction device.  
See chapter 4.3 "Installing the Gas Extraction Device and the Protective Pipe GED on the LAMBDA TRANSMITTER E".
9. Install the LAMBDA TRANSMITTER E on the adapter flange.  
See chapter 4.2 "Installing the LAMBDA TRANSMITTER E".



**NOTE:**

A protective pipe support cannot be installed when a protective pipe for high-dust applications is used.

## 5 Operation and Display Controls

### 5.1 Multi-Function Key

All the basic functions can be executed by means of the multi-function key and maintenance switch.

















Fig. 5-1:  
Operation and display unit  
on the processor board

Function:	Key T2 operation:
Toggle the displayed warning/fault	Briefly
Reset the displayed warning/fault	3 sec*
Quick start of measuring gas pump; interruption of cold start	3 sec/6 sec**
* Some warnings/faults cannot be reset if the fault is still present or the routine is still running.	
** If more than one warning/fault is present, the key must be pressed for 6 seconds.	
The mode „Maintenance“ can be activated via , maintenance switch S1, the display or via the Remote-Display-Software. The mode „Maintenance“ will also be enabled, if a higher release level via a password is activated (can be set in Par.974, default = “factory“).	


### 5.2 LED Display

---

Legende: LED  ist aus  blinkt  leuchtet


LED 1	Maintenance
	 Normal operation
	 Maintenance mode active
LED 2	—
LED 3	—
LED 4	Heater monitoring
	 Heater control active
	 Heater with fixed voltage
LED 5	Operation mode display
	 Calibration
	 Measurement
LED 6	Operation display
	 Operation
LED 12	Warning/fault display
	 No warning/fault
	 At least 1 fault is present
	 At least 1 warning is present

## 5.3 Monitor Output / DIP Switch



The following measured values can be queried via terminals 31 and 32:

- Measured O<sub>2</sub> value
- Probe voltage
- Probe current



Measurement	Conversion	DIP switch	SW2	SW1
Measured O <sub>2</sub> value	0 - 2.5 V -> 0 - 25% O <sub>2</sub>		off	off
Probe voltage	0 - 1.4 V -> 0 - 1,400 mV		off	on
Probe current	0 - 1 V ->      0 - 1,000 mA		on	off


## 5.4 Remote Display Software




- For operation of the LAMBDA TRANSMITTER E via RS232 interface
- To backup and restore the data set
- Instructions are provided in the software.



5.5 Display/Control Unit



Brightness and contrast



Limit values


Li 4 ↑ The limit value is exceeded  
 Li 4 ↓ The limit value is undershot

**i** NOTE  
 The limit values (Li 1 to Li 4) are only displayed if the limit value monitoring function has been activated.


Menu keys

- meas: Measurement
- cal : Calibration
- par: Parameter setup
- diag: Diagnostic

5.5.1 "Meas" Menu Functions





5.5.2 "Cal" Menu Functions




5.5.3 "Par" Menu Functions

par







## 5.5.4 "Diag" Menu Functions

**diag**

Warnings and faults



**ENTER**

Confirmation of error  
 Note: Not all alarms/faults can be confirmed.  
 Carry out troubleshooting

**diag1**

+ P + V



**exit**



Return to previous menu

**exit**



Reset limit value alarm!  
 Prerequisite: Reset mode  $\text{Ö}$  manual  $\text{Ö}$   $\text{Ö}$  acknowledge  $\text{Ö}$  is selected

**exit**



Back to previous menu

**maint**



Switch on /off maintenance mode  
 Maintenance switch S1 must be set on  $\text{Ö}$   $\text{Ö}$

**remote**



Establish connection with other LT devices via LSB

**hist**



Display of fault/alarm history



**exit**



Back to previous menu

**<<<<**



Switch to entries made recently

**>>>>**



Switch to older entries



Via „Trigger“ in par.118 the fault history can be deleted.



# 6 Operation

## 6.1 Activating Measurement Mode



### CAUTION!

#### Observe the line voltage !!!

Factory default is AC230V.

For changing over to AC115V see chapter 12.4.1

Switch on the LAMBDA TRANSMITTER E .



### NOTE

If the factory settings have not been changed, the measurement is checked automatically and adjusted if necessary (cyclical calibration) after the "cold start", again after two hours, and then every 24 hours. Manual intervention is not normally necessary.

The point at which the cyclical calibration should start can be set in par. 061.

If the cold start is interrupted, the calibration must be triggered manually and should be repeated after 2 hours of operation.

Each calibration will be listed in a history (par. 1570...1791). The history can be deleted via par.119. See also chapter 3.1.10.

Typical values during initial commissioning after calibration with compressed air (20.96 vol. % O<sub>2</sub>):

- Probe current (uncompensated): 500 ± 50 mA
- Differential pressure via the capillary: 20 - 30 mbar (0.3 – 0.43 psi)
- Temperature of capillary: 300 - 500 °C (572 – 932 °F)
- Pressure increase during Calibration (read via parameter 50): 1 - 5 mbar (0.015 – 0.07 psi)
- Heat output of measuring cell (read via parameter 54): 75 Watt
- Internal resistance (R<sub>i</sub>) of ZrO<sub>2</sub> measuring cell (read via parameter 53): < 1Ω

For warranty reasons, the enclosed Probe Record Card (chapter 12.6) must be maintained during commissioning and kept with the LAMBDA TRANSMITTER E .



### IMPORTANT!

The cold start cannot be interrupted until the temperature on the capillary is > 260 °C (500 °F).



## Operation - Activating Measurement Mode

---

### 6.1.1 Output of the „Zero/Span“ values

---

The output of the “Zero/Span” values can be activated via parameter 240 “ON/OFF”

Output via:

- Analoge output 1, terminals 42 / 43.
- Digital output 4 at the LSB-Module (optionally)

### Function

---

The output of the „Zero/Span“ values, effects after ending of each complete calibration. It doesn't make any difference if the calibration is released manually, via digital input or via the internal timer.

First will be issued the Zero value for 15 sec., afterwards the Span value.

Additional to the output of the „Zero/Span“ values, closes the contact of output 4 at the optionally LSB digital output module.

Additionally, the values can be issued before calibration. For this purpose P241 must be set to “ON”.



#### NOTE

If calibration is released via the internal timer, it makes first a check-up. If the actual O<sub>2</sub> value on air is inside the range of 21% O<sub>2</sub> +/-0,2% (P 250), it will be carried out no calibration, by reason of reduction of the routine. Also will be issued no Zero/Span values.

If the Zero/Span values will be required via a digital input, will be always be carried out the value of the last complete calibration.

Will be set P 250 (Check-up tolerance) to „0“, will be always carried out a complete calibration.

### Parameter

---

- P 240: „Zero/Span output after calibration“  
„ON“ (default OFF)  
Output of the „Zero/Span“ values
- P 241: „Additional output check value to Zero/Span output“  
„ON“ (default OFF)  
Additional output of the „Zero/Span“ values before calibration
- P 242: 1...60sec. (default 15 sec. for each value)  
Output timer of the Zero- and Span values
- P 1052:  
Must be set to „not measure“.
- P 1061: „Zero/Span“  
Relay output 4 activated,  
for signal „Zero/Span output“ via LSB modul (optionally)
- P 1201: „Zero/Span output“  
Recall of the „Zero/Span“ values via digital input 4  
from the LSB input module (optionally).

### 6.2 Operating and Status Messages

#### 6.2.1 List of operating statuses:

Operating notes	State notes	Description
Cold start		Once the device has been switched on, it remains in the "cold start" status until the probe is operational.
Mesure		The device is in "measure" mode and supplies a valid measured O <sub>2</sub> value (provided that no fault is present).
Calibration auto		The normal automatic adjustment is accomplished
	Check up	Air or measuring gas is fed to the probe and the measured value is output as standard. In this mode, an EPA check can be carried out externally, for example. Note that the measured value is only valid if no fault is present.
	1. calibration	The standard automatic adjustment or the first calibration before aging compensation is carried out.
	aging-compensation.	The internal resistance of the ZrO <sub>2</sub> measuring cell is measured and, if necessary, ageing compensation is carried out. (every 10000 min., the measured Ri is registered into the table in par.1805...1898).
	2. calibration	An optional second automatic calibration is carried out after aging compensation.
	Wait for measure	Whenever the device is switched to or from measurement mode, the device remains in the "wait for measurement" status for a short period (a few minutes) to ensure that the measuring cell is filled with the gas to be measured once measurement mode has been activated.
Manual calibration		The device is in "manual calibration " mode. Air is fed to the probe and the calibration value can be changed manually via the remote control unit.
Maintenance		In addition to the above-mentioned operating statuses, the device is in "maintenance" mode. Maintenance mode can be activated via the maintenance switch, the display, or via the remote display software. Maintenance mode is also automatically activated when a higher release level is activated by means of a password. (can be set in par.974, default="factory").
Warning		One or more warnings lines up
Fault		One or more faults lines up

### 6.3 Practical Notes

#### 6.3.1 Smoothing for 'Jumping' Display Values

The display can be smoothed if values 'jump'. Smoothing is specified by: parameter 360 for measured O<sub>2</sub> value ("operational" release level).



**NOTE**

- A high degree of smoothing causes the measurement signal to slow down.
- Condensate in the gas extraction device can cause measured values to fluctuate.

Water droplets form at the capillary tube. If a water droplet enters the probe, it evaporates. When this occurs, the display falls towards 0 vol. % O<sub>2</sub>. When conditions are stable (measuring gas temperature), this occurs at almost regular intervals.




Fig. 6-1:  
'Jumping' display values

#### 6.3.2 Measurement in Flue Gases with a High Water Content (Downstream of Wet Scrubber)

Flow rate compensation is recommended in highly unbalanced flue gases with a high moisture and low CO<sub>2</sub> content (see chapter 3.1.5 "Flow Rate Compensation").  
Parameter group 1280 to 1283 – "customer" or "service" release level.

#### 6.3.3 Measurement in Humid and Highly Contaminated Flue Gas



- The gas extraction tube (capillary tube) must be kept above the water/acid dew point along its entire length. Min. temperature: 180 °C (356 °F).
- If the measuring gas temperature is lower, the gas extraction device must be heated.

6.3.4 Wet/Dry Measurement, Deviations, Conversion Table



NOTE

The LAMBDA TRANSMITTER E carries out measurements directly in the humid flue gases (wet measurement). When extractive devices are used, flue gases are removed and prepared. "Dry measurements" are normally used here, since the humidity has been extracted from the flue gas. As a result, O<sub>2</sub> measurement values vary (see diagrams below).



Conversion table for concentration values of O<sub>2</sub> (dry) and O<sub>2</sub> (wet)

O <sub>2</sub> concentration range	Constant C gas/CH <sub>4</sub>	Constant C oil/(CH <sub>2</sub> ) <sub>x</sub>
0 - 6 % O <sub>2</sub>	1.18	1.115
6 -12 % O <sub>2</sub>	1.12	1.08
0 -12 % O <sub>2</sub>	1.15	1.10

### 6.4 Removal from Service

#### 6.4.1 Brief Service Interruption

---

If the system is out of service for a short period, you are advised to allow measurement to continue.

#### 6.4.2 Long Service Interruption

---

If the system is out of service for longer than 10 weeks or if measurement is deactivated, you are advised to remove the Lambda transmitter. This prevents the flow-control capillary from corroding and becoming blocked.



**NOTE**

Once removed and disconnected from the power supply, the LAMBDA TRANSMITTER E can be stored for an unlimited period. The zirconium dioxide measuring element is only subject to wear during operation (when it is at the operating temperature).


## 7 Warnings and Faults

### 7.1 Fault History

The fault history can only be called up via Display and Operation unit or via the remote display software, refer to 7.3 Faults.

### 7.2 Display via Rows of LEDs on the Processor Board

#### 7.2.1 Calling Up and Resetting Faults and Warnings (See Also Chapter 5.1)



- Display the next fault/warning: Press multi-function key T1 once.
- Reset a fault: Press multi-function key T1 for 3 sec/fault.

#### 7.2.2 Faults via LED codes

Legend: LED is off flashes lights up

























































































































































































































7	8	9	10	11	12	Fault
						No fault
						Cell damaged
						Flow throughput to low, probe current < 200 mA <sup>(1)</sup>
						Difference pressure too low
						Defective probe heater
						Probe broken wire
						Wrong current input of solenoid valves
						Proportional valve ejector
						I probe too high
						Dynamic is missing
						Dirty pre-filter
						Error analog output
						Error parameters
						Delta-p cal. too low
						Proportional-valve cal.
						Delta-p ejector too high

<sup>(1)</sup> Check parameter 51: the probe current from the last calibration is stored here.

## Warnings and Faults - Display via Rows of LEDs on the Processor Board

### 7.2.3 Warnings via LED codes

Legend: LED  is off  flashes  lights up

7	8	9	10	11	12	Warning
						No warning
						Defective heating control
						Dirty pre-filter
						Flow throughput too low, probe current < 260 mA <sup>(1)</sup>
						O <sub>2</sub> cell aged – replace
						Delta-p low
						Defective MEV*-heating
						Defective pre-filter heating
						Cal. gas flow throughput too low, increase!
						P (abs) too high/ too low
						Probe temperature too high / too low
						Defective ejector heating
						Delta-p ejector high
						Defective MEV* temperature-measuring
						Not used
						Probe current limitation
						Line voltage too high/ too low
						Pressure compressed air too low
						No constant probe current while calibration
						Not used
						Not used
						Not used
						Not used
						Not used
						Not used
						Not used
						Not used
						Not used
						Not used
						Not used
						Dynamic is missing
						Dynamic test activated
						Cell exchanged? If yes activate P. 104
						Housing temperature too high
						Cal. not possible, delta-p too low
						Offset differential pressure too high


\*GED = Gas Extraction Device (MEV = German abbrev.)

<sup>(1)</sup> Check parameter 51: the probe current from the last calibration is stored here.

7.3 Indication via Display and Operation Unit / Remote Display Software

**diag**

Warnings and faults




**ENTER**

Confirmation of error  
 Note: Not all alarms/faults can be confirmed.  
 Carry out troubleshooting

**diag1**

+ P + V



**exit**



Return to previous menu

**exit**



Reset limit value alarm!  
 Prerequisite: Reset mode **0** manual **0** or **0** acknowledge **0** is selected

**exit**



Back to previous menu

**maint**



Switch on /off maintenance mode  
 Maintenance switch S1 must be set on **0** **off**

**remote**



Establish connection with other LT devices via LSB

**hist**



Display of fault/alarm history



**exit**



Back to previous menu

**<<<<**



Switch to entries made recently

**>>>>**



Switch to older entries



**NOTE**

Triggering the parameter 118 deletes the fault history again.



## Warnings and Faults - Faults

### 7.4 Faults







<b>Faults</b>	<b>Possible cause</b>	<b>Solution</b>	<b>Section</b>
<b>Cell damaged</b>	<ul style="list-style-type: none"> <li>Measuring cell severely aged</li> </ul>	<ul style="list-style-type: none"> <li>Replace measuring cell</li> </ul>	8.8
<b>Flow throughput too low, probe current &lt; 200mA</b>	<ul style="list-style-type: none"> <li>Pre-pressure for ejector &lt; 2 bar (29 psi)</li> </ul>	<ul style="list-style-type: none"> <li>Check pre-pressure</li> </ul>	4.4
	<ul style="list-style-type: none"> <li>Extraction attachment contaminated</li> </ul>	<ul style="list-style-type: none"> <li>Clean/replace</li> </ul>	8.5
	<ul style="list-style-type: none"> <li>Capillary blocked</li> </ul>	<ul style="list-style-type: none"> <li>Clean/replace</li> </ul>	8.9
	<ul style="list-style-type: none"> <li>Ejector or proportional valve defective/blocked</li> </ul>	<ul style="list-style-type: none"> <li>Clean/replace</li> </ul>	8.5.1
<b>Difference pressure too low</b>	<ul style="list-style-type: none"> <li>Pre-pressure for ejector &lt; 2 bar (29 psi)</li> </ul>	<ul style="list-style-type: none"> <li>Check pre-pressure</li> </ul>	4.4
	<ul style="list-style-type: none"> <li>Leaks in hose/hose connect.</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> </ul>	8.9
	<ul style="list-style-type: none"> <li>Ejector proportional valve defective/blocked</li> </ul>	<ul style="list-style-type: none"> <li>Clean/replace</li> </ul>	
	<ul style="list-style-type: none"> <li>Loose throttle screw on capillary</li> </ul>	<ul style="list-style-type: none"> <li>Check and, if necessary, secure/replace</li> </ul>	8.5.1
	<ul style="list-style-type: none"> <li>Difference pressure sensor out of the socket or sensor defective</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> </ul>	8.12
	<ul style="list-style-type: none"> <li>Capillary (GED) flow too high</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> </ul>	8.5
<b>Defective probe heater</b>	<ul style="list-style-type: none"> <li>Fuse F16, F17</li> </ul>	<ul style="list-style-type: none"> <li>Check fuses</li> </ul>	12.4
	<ul style="list-style-type: none"> <li>Heater defective</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> </ul>	8.7/8.8
<b>Probe broken wire</b>	<ul style="list-style-type: none"> <li>Fuse F208 defective</li> </ul>	<ul style="list-style-type: none"> <li>Replace fuse</li> </ul>	12.4
	<ul style="list-style-type: none"> <li>CO peak &gt; 10,000 ppm</li> </ul>		
	<ul style="list-style-type: none"> <li>Supply cable breakage</li> </ul>	<ul style="list-style-type: none"> <li>Check connection cable</li> </ul>	8.8
	<ul style="list-style-type: none"> <li>Measuring cell defective</li> </ul>	<ul style="list-style-type: none"> <li>Replace measuring cell</li> </ul>	8.8
	<ul style="list-style-type: none"> <li>Base electronics defective</li> </ul>	<ul style="list-style-type: none"> <li>Replace base electronics</li> </ul>	12.4
<b>Wrong current input of solenoid valves</b>	<ul style="list-style-type: none"> <li>Solenoid coil defective</li> </ul>	<ul style="list-style-type: none"> <li>Check Ri appr.35 <math>\Omega</math>/ replace</li> </ul>	12.4
	<ul style="list-style-type: none"> <li>Fuse F11</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> </ul>	
<b>Proportional-valve ejector</b>	<ul style="list-style-type: none"> <li>Proportional valve defective</li> </ul>	<ul style="list-style-type: none"> <li>Replace</li> </ul>	

## Warnings and Faults - Faults

<b>I-probe too high</b>	<ul style="list-style-type: none"> <li>Gas extract. device not secure</li> <li>Measuring chamber broken</li> <li>ZrO<sub>2</sub> measuring cell broken</li> <li>Throttle screw loose</li> <li>Capillary (GED) flow too high</li> <li>Short-circuit between pin 94 and 97 on probe plug</li> <li>Difference pressure sensor out of the socket or sensor defective</li> </ul>	<ul style="list-style-type: none"> <li>Secure gas extraction device</li> <li>Replace measuring chamber</li> <li>Replace measuring cell</li> <li>Check and, if necessary, secure throttle screw</li> <li>Check/replace</li> <li>Check plug assignments</li> <li>Check/replace</li> </ul>	<p>8.5</p> <p>8.11</p> <p>8.8</p> <p>8.5.1</p> <p>8.5</p> <p>12.4</p> <p>8.12</p>
<b>Dirty pre-filter</b>	<ul style="list-style-type: none"> <li>Deposits on filter</li> </ul>	<ul style="list-style-type: none"> <li>Clean/replace filter</li> </ul>	8.5.3
<b>Error analog output</b>	<ul style="list-style-type: none"> <li>Analog output module defective</li> <li>Unassigned outputs are activated.</li> </ul>	<ul style="list-style-type: none"> <li>Replace</li> <li>Parameters 540, 550, and 560 must be switched off</li> </ul>	<p>8.13</p> <p>5.5.3</p>
<b>Error parameters</b>	<ul style="list-style-type: none"> <li>The stored parameters are incorrect The device may be using default settings</li> </ul>	<ul style="list-style-type: none"> <li>Consult manufacturer</li> </ul>	
<b>Delta-p cal. too low</b>	<ul style="list-style-type: none"> <li>Calibration unit (P valve, S valve) defective</li> <li>No pre-filter (broken off)</li> <li>Pre-pressure compressed air for calibration: 2 bar (29 psi)</li> <li>Difference pressure sensor out of the socket or sensor defective</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> <li>Check/replace</li> <li>Check</li> <li>Check/replace</li> </ul>	<p>3.2</p> <p>8.5.3</p> <p>8.12</p>
<b>Proportional-valve calibration</b>	<ul style="list-style-type: none"> <li>Proportional valve defective</li> </ul>	<ul style="list-style-type: none"> <li>Replace</li> </ul>	
<b>Delta-p ejector too high</b>	<p>Will be released, when difference pressure by capillary is too high</p> <ul style="list-style-type: none"> <li>Capillary or gas extraction device has closed or become blocked</li> <li>Electronics for Ejectoractivation defective</li> </ul>	<ul style="list-style-type: none"> <li>Remove the gas extraction device, loosen the throttle screw and clean both items</li> <li>Replace base electronics</li> </ul>	<p>8.5.</p> <p>8.14</p>

### 7.4.1 Internal Electronics Fault

Legend: LED  is off  flashes  lights up

7 8 9 10 11 12	     	Electronics fault (rapid flashing)
----------------	---	------------------------------------

If an internal fault occurs, you must consult the manufacturer. For the address of the manufacturer, see "General Notes".

## Warnings and Faults - Warnings

### 7.5 Warnings

Warnings	Possible cause	Solution	Section
<b>Defective heating control</b>	<ul style="list-style-type: none"> <li>Fuse F16</li> <li>Electronics defective</li> </ul>	<ul style="list-style-type: none"> <li>Replace fuse</li> <li>Replace base electronics</li> </ul>	12.4 8.14
<b>Dirty pre-filter</b>	<ul style="list-style-type: none"> <li>Deposits on filter</li> </ul>	<ul style="list-style-type: none"> <li>Clean/replace filter</li> </ul>	8.5.3
<b>Flow throughput too low, probe current &lt; 260 mA</b>	<ul style="list-style-type: none"> <li>Extraction attachment contaminated</li> <li>Ejector or proportional valve defective/blocked</li> <li>Capillary blocked</li> </ul>	<ul style="list-style-type: none"> <li>Clean/replace</li> <li>Replace</li> <li>Clean/replace</li> </ul>	8.5.2 3.2 8.5.1
<b>O<sub>2</sub> cell aged → replace</b>	<ul style="list-style-type: none"> <li>O<sub>2</sub> measuring cell worn out</li> </ul>	<ul style="list-style-type: none"> <li>Replace measuring cell</li> </ul>	8.8
<b>Delta-p ejector low</b>	<ul style="list-style-type: none"> <li>Pre-pressure for ejector &lt; 2 bar (29 psi)</li> <li>Extraction device blocked</li> <li>Ejector or proportional valve defective/blocked</li> <li>Leaks in hose/hose connection</li> <li>Loose throttle screw on capillary</li> <li>Difference pressure sensor out of the socket or sensor defective</li> </ul>	<ul style="list-style-type: none"> <li>Check</li> <li>Clean/replace</li> <li>Check/replace</li> <li>Check/replace</li> <li>Check and, if necessary, secure/replace</li> <li>Check/replace</li> </ul>	8.9 8.5.1 8.12
<b>Defective MEV (GED)-heating</b>	<ul style="list-style-type: none"> <li>Heater incorrectly connected</li> <li>Heater burnt out or short-circuit</li> </ul>	<ul style="list-style-type: none"> <li>Check electrical connections and fuse</li> <li>Measure internal heater resistance, replace</li> </ul>	4.6
<b>Defective pre-filter heating</b>	<ul style="list-style-type: none"> <li>Heater incorrectly connected</li> <li>Heater burnt out or short-circuit</li> </ul>	<ul style="list-style-type: none"> <li>Check electrical connections and fuse</li> <li>Measure internal heater resistance, replace</li> </ul>	4.6
<b>Cal. Gas flow throughput too low, increase !</b>	<ul style="list-style-type: none"> <li>Calibration unit (P valve, M valve) defective</li> <li>No pre-filter (broken off)</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> <li>Check/replace</li> </ul>	3.3 8.5.3
<b>P (abs) too high/too low</b>	<ul style="list-style-type: none"> <li>Absolute pressure out of the socket or sensor defective</li> <li>Incorrect setting (factory setting: max. permissible pressure: 1100 mbar (16 psi) min. permissible pressure: 700 mbar (10.2 psi))</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> <li>Correct setting Consult manufacturer</li> </ul>	8.12
<b>Probe temperature too high/too low</b>	<ul style="list-style-type: none"> <li>Temperature exceeds limit value of 550 °C (1,022 °F)</li> <li>PT100 temperature sensor defective</li> <li>Wire breakage in PT100 temperature sensor</li> <li>Electronics defective</li> </ul>	<ul style="list-style-type: none"> <li>Probe must be moved back to prevent damage</li> <li>Check and, if necessary, replace PT100 sensor</li> <li>Check connections (plug), cable</li> <li>Replace base electronics</li> </ul>	8.10.1 12.4 8.14
<b>Defective ejector heating</b>	<ul style="list-style-type: none"> <li>Fuse F10</li> <li>Cable incorrectly connected</li> <li>Heater burnt out</li> </ul>	<ul style="list-style-type: none"> <li>Check/replace</li> <li>Check</li> <li>Check/replace</li> </ul>	12.4 8.9

## Warnings and Faults - Warnings

<b>Delta-p ejector high</b>	<ul style="list-style-type: none"> <li>• Capillary or gas extraction device has closed</li> <li>• Electronics for ejectorcontrol defective</li> <li>• Ejector or prop-valve defective</li> </ul>	<ul style="list-style-type: none"> <li>• Remove the gas extraction device, loosen the throttle screw and clean both items</li> <li>• Replace base electronics</li> <li>• Replace</li> </ul>	8.5.1 8.14
<b>Defective MEV-temperature measuring (for gas extraction device)</b>	<ul style="list-style-type: none"> <li>• PT100 defective, cable incorrectly connected</li> <li>• Heater electronics defective</li> </ul>	<ul style="list-style-type: none"> <li>• Check/replace gas extraction device heater</li> <li>• Check/replace</li> </ul>	4.6
<b>Probe current limitation</b>	<ul style="list-style-type: none"> <li>• The flow rate through the capillary may be too high</li> <li>• Measuring chamber broken</li> <li>• Base electronics defective</li> <li>• Difference pressure sensor out of the socket or sensor defectiv</li> </ul>	<ul style="list-style-type: none"> <li>• Check</li> <li>• Check/replace</li> <li>• Check/replace</li> <li>• Check/replace</li> </ul>	8.5.1 8.11 8.14 8.12
<b>Line voltage too high/too low</b>	<ul style="list-style-type: none"> <li>• Incorrect power supply</li> <li>• Electrical connection incorrect</li> <li>• Mains plugs on motherboard not secure</li> </ul>	<ul style="list-style-type: none"> <li>• Check the power supply</li> <li>• Check electrical connection</li> <li>• Ensure that mains plugs are secure</li> </ul>	12.4 12.4
<b>Pressure compressed air too low</b>	<ul style="list-style-type: none"> <li>• Supply cable may be blocked</li> <li>• Calibration unit defective</li> <li>• No pre-filter (broken off)</li> <li>• Pre-pressure too low</li> </ul>	<ul style="list-style-type: none"> <li>• Check/clean</li> <li>• Check/replace</li> <li>• Check/replace</li> <li>• Check that pressure is 2 bar (29 psi)</li> </ul>	3.2 3.2 8.2.3 4.4
<b>No constnat probe current while calibration</b>	<ul style="list-style-type: none"> <li>• High pressure fluctuations at measuring point</li> <li>• Sintered pre-filter broken off</li> <li>• Leak in gas supply</li> <li>• Measuring chamber broken</li> </ul>	<ul style="list-style-type: none"> <li>• Check pressure increase and increase smoothing, par. 360</li> <li>• Replace sintered pre-filter</li> <li>• Check seals, glands</li> <li>• Check/replace</li> </ul>	5.5.3 8.5.3 8.5.10
<b>Probe exchanged ?</b>	<ul style="list-style-type: none"> <li>• Has the measuring cell been replaced?</li> </ul>	<ul style="list-style-type: none"> <li>• If so, activate parameter 104.</li> </ul>	5.5.3
<b>Internal device temperature too high</b>	<ul style="list-style-type: none"> <li>• The internal temperature is greater than 75 °C (167 °F).</li> </ul>	<ul style="list-style-type: none"> <li>• Check the solenoid valve</li> <li>• Check air calibration pre-pressure: 2 bar (29 psi)</li> <li>• Switch-on temperature adjusted in par. 354 (default = 40 °C/104 °F)</li> <li>• If electronics temperature is implausible (par. 055), adjust it in par. 3769</li> </ul>	3.2 4.4
<b>Offset differential pressure too high</b>	<ul style="list-style-type: none"> <li>• Difference pressure sensor out of the socket or sensor defectiv</li> </ul>	<ul style="list-style-type: none"> <li>• Check/replace</li> </ul>	8.12

### 8 Service and Maintenance

The LAMBDA TRANSMITTER E is virtually maintenance free. Required maintenance work is displayed via the display/control unit:

- Clean the flow-control capillary / replace the entire gas extraction device.
- Clean the extraction attachment at the tip of the gas extraction device / replace the filter.
- Clean/replace the filter attachment if the warning "pre-filter contaminated" is displayed.



#### WARNING

The flange and the tube of the LAMBDA TRANSMITTER E is very hot.  
Cooling down before removing or wear protective gloves.

#### 8.1 Recommendations for practical application

##### 8.1.1 Operations in maintenance interval of 4 weeks (compendium from TÜV inspection report)

---

The operations in maintenance interval is limited to the visual check of the measuring device. Due to the automatic functional test and readjusting in an interval of 24 hours or more briefly, can be done in principle without a regular task of test gas. The examination and the calibration, if necessary, take place with ambient air. See also chapter 8.2. In individual cases the correctness of the calibration can be examined by the task of test gases on zero and reference point. Due to the measurement principle becomes the examination of the zero point no nitrogen, but a test gas with <2 Vol.-% O<sub>2</sub>. In all other respects the instructions of the manufacturer are to be considered.

##### 8.1.2 Functional test and calibration (compendium from TÜV inspection report)

---

For the execution of the functional test and/or before the calibration after guideline DIN EN 14181 the following procedure is suggested:

- Visual check of the complete measuring device
- Control of the tightness by task of zero and test gas for the calibration inlet of the probe.
- Examine the linearity with zero and test gas
- Examine the zero point and reference point drift in the maintenance interval (Control of the long-run drift after a basic calibration)
- Determine the dead and response time
- Examine the data flow (analog, status signals) to the evaluation system.

Further details to the functional test and calibration are in the guideline DIN EN 14181 (September 2004), and/or VDI 3950 to take sheet 1 (July 1994).

### 8.2 Checking and Calibrating the Probe



#### NOTE

The calibration procedure takes place by using compressed air (constant pre-pressure 2 bar-29psi). In order to consider the relative humidity of the air used for the calibration procedure a calibration offset (parameter 297) has to be set. The setting of the calibration offset parameter (P297) works:  $-0.1 \text{ vol\% of O}_2$ .

That means:

It is calibrated not on 21% O<sub>2</sub>, but on 20,9% O<sub>2</sub>.

With extreme site conditions (the tropics, desert, etc.) the calibration offset is to be adjusted. See chapter 3.1.4.

The probe is checked and/or calibrated automatically in 1 to 10,000 hour cycles. Parameter 270 ("customer" release level). Factory setting is 24 hours. Parameter 61: Reverse counter for cyclic calibration in minutes, can be set manually, in order to set the time for start of the cyclic calibration.

Manual adjustment can be activated as follows:

- Display/control unit (optional)
- Via the PC in conjunction with the remote display software
- Via the remote control unit (optional)



#### NOTE

The calibration is protected with a password. Which release level is to be used, can be set in par.260:

OFF → No password is necessary

CUSTOMER → Customer's password is necessary (factory setting)

SERVICE → Service password is necessary

MAINTENANCE → Maintenance mode is necessary

CUSTOMER + MAINTENANCE → Customer's pw + Maintenance mode is necessary

SERVICE + MAINTENANCE → Service password + Maintenance mode is necessary

A counter can be activated to ensure that calibration is only carried out on every 12<sup>th</sup> calibration command (parameter 272). This is recommended if other measuring devices that require more frequent calibration are operated via the control unit.

During calibration, the following output values can be selected (parameters 282 and 283):

- Current measured value
- Substitute value
- Last measured value



#### NOTE

A check routine is carried out before cyclic and automatic calibration. If the actual O<sub>2</sub> value deviates only slightly from the expected setpoint, no calibration is carried out. The tolerance can be set via parameter 250 ("customer" release level). The factory setting is  $\pm 0.3 \text{ vol. \% O}_2$ .

If calibration is triggered manually, it is always carried out.

When the check begins, the displayed measured values are not plausible.

Once calibration has been triggered, air is blown through the protective pipe to the sampling point. The gas quantity is controlled automatically by means of the proportional valve in such a way that the pre-filter is pressurized at between 2 and 5 mbar. This prevents flue gases from reaching the sampling point in the protective pipe, thereby ensuring that only calibration gas is present at the measuring gas sampling point.

The pressure in the filter is measured by means of an absolute pressure sensor and the measured value is compensated within defined limits ( $\pm 50$  mbar/0.73 psi). If the filter becomes contaminated, the gas flow is reduced via the proportional valve. If the flow rate is too low while the pressure is increasing quickly, the warning "dirty pre-filter" is output.

Due to its size, the filter is relatively resistant to contamination. If only a small part of the surface remains clean, this is sufficient for the measuring gas quantity of approx. 0.5 l/h (0.017 qft/hr) required for the measurement.

Each calibration will be listed in a history (par.1570...1791). The .calibration history can be deleted via parameter 119. (See also chapter 3.1.10)

### 8.3 Check with Test Gas

---



**NOTE**

Pre-pressure 2 bar - 29psi !

The measuring gases used must not contain any combustible gas constituents (e.g. carbon monoxide (CO)). Combustible gas constituents are oxidized (incinerated) on the platinum electrode of the zirconium dioxide measuring cell, which is approx. 800 °C (1,472 °F), and reduce the oxygen to be measured.

#### 8.3.1 Procedure

---

A manual check can be triggered as follows:

- Display/control unit (optional)
- Via the PC in conjunction with the remote display software
- Via the remote control unit (optional)



**NOTE**

The calibration is protected with a password. Which release level is to be used , can be set in par.260:

OFF → No password is necessary

CUSTOMER → Customer's password is necessary (factory setting)

SERVICE → Service password is necessary

MAINTENANCE → Maintenance mode is necessary

CUSTOMER + MAINTENANCE → Customer's pw + Maintenance mode is necessary

SERVICE + MAINTENANCE → Service password + Maintenance mode is necessary




**NOTE**


The "manual calibration" is limited to 15 minutes. Once this time has elapsed, the device switches back automatically to measuring mode.

## Service and Maintenance - Check with Test Gas

1. Connect test gas with a constant pre-pressure from 2 bar – 29 psi at the calibration gas inlet.
2. Open the calibration menu with the key “cal”, enter your password, and start the calibration with the order “Start manual calibration” → ENTER



3. Manual probe calibration → „change value by arrow-keys“ (if necessary).




4. End of calibration → press OK → „End of calibration, back to mesure“ → ENTER
5. After end of calibration, disconnect the test gas and connect the compressed air again (constant pre-pressure 2 bar).




### 8.4 Software Update to 5V006 with Flash-Update-Software V1.2


- Switch OFF LAMBDA TRANSMITTER E.
- Set plug-in jumper BR10 in LAMBDA TRANSMITTER E on processor board into position „P“ (enables programming mode).
- Connect PC at RS232-interface from LAMBDA TRANSMITTER E.




- Switch ON LAMBDA TRANSMITTER E (no display).
- Start LT Flash-Update-Software (LTFlashUpdate V1.2.exe).
- Select COM-Port and „CONNECT“ to LAMBDA TRANSMITTER E.




- Datas are reading out and a backup file will be created.



- Continue with „NEXT“.
- Select directory for bachup file and save it.



- Continue with „NEXT“.
- Select dirctory with update file and open it. The file for update must be named so that it begins with "update".



- Update will be transmit in LAMBDA TRANSMITTER E.
- After successfully programming end with „END“.



- Switch OFF LAMBDA TRANSMITTER E.
- Reset plug-in jumper BR10 in LAMBDA TRANSMITTER E on processor board into position „N“.
- Switch ON LAMBDA TRANSMITTER E.
- Check the software version via „PAR“-key on the display (5V006)
- The software update is now at the end.

In these version 1.2 of the Flash-Update-Software the following parameters are taken over from the old device:

P.48 PW probe heating

P.51 Value of calibration

P.57 Flow rate

P.70 bis 81 All counters and times

P.121 MEV / pre filter heating ON/OFF

P.358 Cabinet cooling power on time

P.386 Nomial value of differential pressure

P.392 bis 395 Limits for differential pressure

P.400 bis 409 Setting of MEV heating

P.411 Offset differential pressure sensor

P.970 up to 973 Setting display, language and contrast

P.1480 up to 1483 Serial number

P.1500 up to 1564 Measuring place name, probe number, etc

P.1570 up to 1799 History of calibration

P.1800 up to 1899 History of Ri

P.3600 up to 3679 History of dirt

P.3750 up to 3769 Temperature statistics

P.3800 up to 3899 Setting LSB

P.30030 up to 30064 Internal parameters of time

### 8.5 Removing the GED and Checking Penetrability




Fig. 8-1:  
Removing the gas  
extraction device (work  
steps specified)

1. Remove the locking element **(e)** for the protective pipe **(f)** by removing the lower safety splint.
2. Unscrew the protective pipe **(f)** and carefully push forwards to remove.
3. Unscrew in the absolute pressure capillary **(b)** by hand.
4. Unscrew the gas extraction device **(a)** and carefully push forwards to remove.



**IMPORTANT!**

The tip of the gas extraction device, which projects into the probe, is very hot!

5. Check the penetrability of the gas extraction device.  
Place one side into a tumbler and blow compressed air through it.  
If the gas extraction device is blocked, it must be replaced. The capillary can also be unblocked by heating it to a very high temperature and by using a wire. See the description below. If this procedure does not work, the gas extraction device must be replaced. See chapter 11 for order numbers.
6. To install the device, carry out the above steps in reverse order.

### 8.5.1 Unblocking the Capillary by Heating to a Very High Temperature:




Fig. 8-2:  
Unblocking the capillary by  
heating to a very high  
temperature

1. Remove the throttle screw at the end of the capillary (probe side).
2. Unscrew the extraction attachment (measuring gas side).
3. Heat the capillary tube using a welding torch.
4. Thread the wire through the capillary tube.
5. Install the gas extraction device.
6. Check the flow rate.  
If the flow rate is too high, the entire gas extraction device must be replaced.

### 8.5.2 Cleaning the Extraction Attachment with Sintered Metal Filter




Fig. 8-3:  
Removing the extraction  
attachment

1. Remove the extraction attachment.  
If the sintered metal filter cannot be removed, it must be drilled out and replaced.  
Replacement filters are available in packs of 10 (order no. type 6 55 R 2803,  
extraction attachment (complete) order no. type 655R0028).
2. Clean the extraction attachment and sintered metal filter.
3. Install the extraction attachment.

### 8.5.3 "Dirty pre-filter"

The penetrability of the pre-filter is checked by monitoring the pressure increase during calibration. If the pressure in the filter increases by more than the threshold value (parameter 276, factory setting 50 mbar), an warning is output. When the warning "sintered metal pre-filter contaminated" is present, the probe must be removed and the pre-filter cleaned or replaced.



#### NOTE


The differential pressure before and during calibration is displayed. The pressure increase during the last calibration can be read via parameter 50.

### 8.6 Removing the Probe Body

To remove the probe body, the following tools are required:

- 0.5 x 3.5 screwdriver
- Size 13 combination wrench
- Combination pliers

Fig. 8-4:  
Probe chapter(connection  
side), LAMBDA  
TRANSMITTER E  
connection to probe body



1. Unplug the mains plug and leave the LAMBDA TRANSMITTER E to cool down for 30 mins.
2. Open the housing and the mounting plate with the display/control unit.
3. Remove connectors X15 and X16 from the motherboard.
4. Remove the wires from the connector.
5. Remove all three hoses from the probe body. To do so, press down the blue connectors. Both hoses on the extraction device must be loosened at the glands and removed.
6. Remove the thermal cover plate by pulling the pins. Combination pliers can be used here.
7. Separate the LAMBDA TRANSMITTER E from the probe body at the neck of the housing and carefully remove. To do so, remove the 4 nuts (M8 / width across flats 13).  
The probe body has now been separated. The measuring cell, temperature sensor, and extraction device can be replaced (see the following section).
8. To install, carry out the above steps in reverse order.
9. **Reset the heater control to the base value.**
10. To do so, set parameter 104 to "Trigger" and acknowledge with "Enter". Once the command has been executed, parameter 104 returns to "0".



#### NOTE

When the probe body is being installed, the flat gasket on the housing (order no. type 657R3541) must be replaced. Seals are provided with the replacement sets.

## 8.7 Checking the Measuring Cell Heaters

1. Check fuses F16 and F17 (see chapter 12.4).  
If the fuses are OK, continue to step 2.
2. Unplug the connector.
3. Measure the resistance between pins 92 and 93 on connector X16 (see "Technical Specifications").  
The resistance must be between 8  $\Omega$  and 11  $\Omega$ .
  - If the resistance is towards  $\infty$ , the heater is defective and must be replaced (order no. type 657R3203).
  - If the resistance is within the permissible range, the electronics are defective and the base electronics must be replaced.

## 8.8 Replacing the Measuring Cell and Measuring Cell Heater

Required tools: 1.5 and 2.5 hexagon-socket spanners




Fig. 8-5:  
Sensor unit




Fig. 8-6:  
Measuring cell with heater

## Service and Maintenance - Replacing the Measuring Cell and Measuring Cell Heater

---



**NOTE**

Be extremely careful when replacing the measuring cell or the measuring cell heater because both components are ceramic and are, therefore, **EXTREMELY FRAGILE!**



## Service and Maintenance - Cleaning and Replacing the Ejector (incl. Heater)

1. Remove the probe body (see chapter 8.6).
2. Remove the sensor unit with sensor and heater. To do so, remove the 6 hexagon-socket screws (2.5 hexagon-socket spanner) on the sensor flange.
3. Carefully remove the sensor unit.
4. Remove the sensor contact (1.5 hexagon-socket spanner).
5. Carefully remove the sensor by pushing it forwards.
6. Remove and replace the sensor contact.
7. To install, carry out the above steps in reverse order.



### NOTE

When installing the sensor unit in the probe body, do not forget the two Teflon seals (see picture).

During installation, make sure that the sensor does not come into direct contact with the metal sleeve.

8. **Reset the heater control to the base value.**  
To do so, set parameter 104 to "Trigger" and acknowledge with "Enter".  
Once the command has been executed, parameter 104 returns to "0".

Order no. for measuring cell replacement set: type 655 R 3201

## 8.9 Cleaning and Replacing the Ejector (incl. Heater)




Fig. 8-7:  
Probe chapter (connection side)

Required tools: Size 14 spanner

1. Remove the probe body (see above).
2. Remove the ejector and heater using the size 14 spanner.
3. To install, carry out the above steps in reverse order.  
During installation, do not forget the aluminum seals.

Ejector (complete) order no: type 657 R 3202



### NOTE

Blocked gas paths in the ejector can be unblocked with boiling water.

### 8.10 Checking the PT 100 Temperature Sensor




Fig. 8-8:  
PT100 table

1. Remove connector X15 (see chapter 12.4).
2. Measure the resistance between pins 24 and 26 on connector X15.  
At room temperature, this should be approx. 110 Ω (see graph). If this is not the case, the PT100 is defective and must be replaced.

#### 8.10.1 Replacing the PT100 Temperature Sensor




Fig. 8-9:  
Probe chapter (connection side)

Required tools: Size 8 spanner

Remove the probe body (see chapter 8.6).

Remove the PT100 temperature sensor using the size 8 spanner.

To install, carry out the above steps in reverse order.

Order no. for replacement temperature sensor: type 657 R 3205

## 8.11 Replacing the Measuring Chamber




Fig. 8-10:  
Components of the probe  
section

Required tools:

- Screwdriver: 0.5 x 3.5
- Spanners (5.5 mm, 8 mm, 10 mm, 13 mm, 14 mm, 24 mm)
- Combination pliers
- Hexagon socket spanners (1.5 mm, 3 mm, 4 mm)

**8.11.1 Removing the Measuring Chamber**







Fig. 8-11:  
Removing the measuring chamber (work steps specified) (part 1)





Fig. 8-12:  
Removing the measuring chamber (work steps specified) (part 2)

## Service and Maintenance - Replacing the Measuring Chamber

---

1. Remove the protective pipe for the gas extraction device, the gas extraction device, and the absolute pressure capillary.
2. Remove the probe body (see chapter 8.6).
3. For the remainder of the removal procedure, clamp the probe body in the vice.
4. Remove the measuring cell and heater (see chapter 8.8).
5. Remove the PT100 temperature sensor (see chapter 8.10).
6. Remove the 6 hexagon-socket-screws of the protective pipe intake (a).
7. Remove the protective pipe intake (a) and the metal O-ring (b).
8. Loosen the absolute pressure intake pipe (e) using the spanner and turn to the side.
9. Loosen the screw cap for the measuring gas adapter (c) using a spanner and remove the measuring gas adapter (c).
10. Remove both hose connections (l).
11. Remove the 6 hexagon-socket screws on the upper flange (j) by rotating them 90° (diagonally opposite sequence).
12. Remove the upper flange (j) with insulation seal and aluminum filler ring (i).
13. Use a blunt object to push the measuring chamber (h) out of the probe body.
14. Remove the graphite seal on the inside (d) of the measuring chamber.

Order no. for measuring-chamber repair kit: type 657R3206

## 8.11.2 Installing the Measuring Chamber





Fig. 8-13:  
Installing the measuring  
chamber (work steps  
specified)

1. Insert the new graphite seal (d) in the probe body.
2. Insert the disk springs (f) in the probe body with the curved side facing the measuring chamber flange.
3. Insert the new measuring chamber with the new aluminum filler ring (g).
4. Place the upper flange (j) with insulation seal and aluminum filler ring (i) on the measuring chamber.
5. Secure the 6 hexagon-socket screws on the upper flange (j) by rotating them 90° (in diagonally opposite sequence).
6. Install both hose connections (l).
7. Insert the measuring gas adapter (c) and secure the screw caps (17 Nm). Tighten with a different spanner.  
The flat side of the measuring gas adapter (c) must face the absolute pressure intake pipe.
8. Align the absolute pressure intake pipe (e) and secure with a spanner.
9. Insert a new metal O-ring (b) and insert the protective pipe intake (a).
10. Secure the 6 hexagon-socket screws on the protective pipe intake (a) by rotating them 90° (in diagonally opposite sequence).
11. Install the PT100 temperature sensor (see chapter 8.10).
12. Install the measuring cell and heater (see chapter 8.8).
13. Install the probe body (see chapter 8.6).
14. Install the protective pipe for the gas extraction device, the gas extraction device, and the absolute pressure capillary.

### 8.12 Replacement of the pressure sensors


---



The pressure sensors are placed on the base electronic of the LAMBDA TRANSMITTER E. They are plug-in types and by a holding plate secured.

- Remove holding plate.
- Remove hose connection, maybe the hose clips must be cut.
- Remove pressure sensors.
- With the plug-on of the pressure sensors, attend to the correct seat in the socket.
- Plug-on hose connection (maybe use new hose clips).  
Hose clips are in the small accessories kit of the LAMBDA TRANSMITTER E (see spare parts)
- Attach the holding plate.


### 8.13 Replacement of the analog output card



The analog output card is placed on base electronic. It is plug-in type and by a retaining screw secured..

- Remove retaining screw
- Remove analog output card
- Plug-on the new card and secure
- See also chapter 12.5.2

### 8.14 Replacement of the base electronic



- Remove both pressure sensors (do not remove the hoses)
- Remove analog output card
- Unscrew the mounting of the processor card and remove processor card out of the 96-pole socket. Be careful.
- Remove all plug-in connectors
- Unscrew the 7 fastening bolts of the base electronic (use a pin type socket wrench size 5,5)
- Exchange base electronic
- To install, carry out the above steps in reverse order.



### 9 Disposal

The LAMBDA TRANSMITTER E was designed to minimize the impact on the environment. The individual modules can be easily separated and sent for recycling.

## 10 Optional Accessories

### 10.1 LSB-Module with 4 Analog Outputs Voltage, alternatively Current

#### 10.1.1 Functional Description

- Module voltage: 4 analog outputs 0 - 10 V DC
- Modul current: 4 analog outputs 0 - 20 mA
- Jumper plugs enable rapid wiring of several modules
- Can be used without programming


The LSB-modules are output modules with a wide range of applications. They are controlled by LSB (setting P3895) (see section 4.5). **These modules cannot be controlled by CAN.** The module is triggered by a variable address (1 - 99) and the status of outputs is transferred to the data bits. If an analog output module with the same address is used in the system, the voltage/current measured there will be reproduced at the corresponding output.

The 4 analog output values (1 to 4: P530 to P569) are output to the analog output module (activate using P3820). The address to be set is shown in parameter 3820. If voltage modules are used, 10 V is equal to 20 mA.



**NOTE**

Make sure that the address you set is not the same as that for another LSB module address!



#### 10.1.2 Setting the Parameters for analog output module (with Software Version 4V24 or More Recent)

Activation of analog output module	Analog output 1	Analog output 2	Analog output 3	Analog output 4
P3820 P3895 on LSB	P530-P539	P540-P549	P550-P559	P560-P569

```

*** LSB Bus ***
LSB analog output module
(analog output 1 4)
P.3820: 1.Modul(Adr.3)
    
```

## Optional Accessories - LSB-Module with 4 Analog Outputs Voltage, alternatively Current

---

### 10.1.3 Parameter 530 / 540 / 550 / 560

---

Here, enter the measured value that is to be output at the analog output. The following settings are possible for each output:

- Off
- Measured O<sub>2</sub> value
- Configurable measured value 1 - 6
- Probe temperature
- Probe absolute pressure
- Probe current
- Probe voltage
- Internal O<sub>2</sub> value

### 10.1.4 Parameter 531 / 541 / 551 / 561

---

Here, set the measurement range for each analog output. The following settings are possible:

- 0-20 mA / 0-10 V
- 4-20 mA
- 4-20 mA / error 0 mA
- 4-20 mA / error + maintenance 0 mA

### 10.1.5 Parameter 532 / 542 / 552 / 562

---

Here, set the start of the measurement range for each analog output.

- E.g. "0" for 0% O<sub>2</sub>

### 10.1.6 Parameter 533 / 543 / 553 / 563

---

Here, set the end of the measurement range for each analog output.

- E.g. "210" for 21% O<sub>2</sub>

### 10.1.7 Parameter 534 / 544 / 554 / 564

---

- Output value for each analog output in "mA"

```
*** Analog output 1 ***
P. 530: 02 Measuring value
P. 531: 4-20mA
P. 532: 0
P. 533: 210
P. 534: 20.000 mA
```

# Optional Accessories - LSB-Module with 4 Analog Outputs Voltage, alternatively Current

## 10.1.8 Technical Specifications

### Output Module

- Rated voltage UN 24 V DC
- Current consumption 50 mA
- Power consumption 1.2 W
- Operating voltage range 0.8 - 1.1 x UN
- Operating temp. range 0 °C to +55 °C (-4 °F to 130 °F)
- Storage temp. range -25 °C to +70 °C (-13 °F to 158 °F)
- Suppressor circuit Polarity reversal protection for operating voltage
- Function display Green LED for BUS activity and supply voltage
- Operation display Red LED for BUS error messages
- Article number voltage module 663R4025S (with connection cable)
- Article number current module 663R4029S (with connection cable)
- Article number of external power pack 663R4024

### Analog Outputs (Voltage)

- Output current (10 V DC) (Analog output) 5 mA
- Output voltage 0 - 10 V DC
- Measurement error/tolerance  $U = \{(N/32) \times 9.9165 \text{ mV} \pm 20 \text{ mV}\} \pm 1.1\%$   
U = output voltage in V  
N = numerical value (BUS)
- Response time (from receiving to sending) 15 ms (msec)
- Recovery time 550 ms (msec)

### Analog Outputs (Current)

- Output current 0-20 mA
- Accuracy 1%
- Load max. 300 Ohm
- Response time (from receiving to sending) 15 ms (msec)
- Recovery time 550 ms (msec)

### Housing

- Connection cross-chapterof device terminals • 2.5 mm<sup>2</sup> (0.038 in<sup>2</sup>)
- Connection cross-chapterof screwable plug-in terminals (BUS, power supply) • 1.5 mm<sup>2</sup> (0.023 in<sup>2</sup>)
- Weight • 95 g (0.2 lb)
- Housing dimensions (W x H x D) • 35 x 68 x 60 mm (1.4 x 2.7 x 2.4 in)

## 10.2 LSB-Module with 4 Analog Inputs

### 10.2.1 Functional Description

- 4 analog inputs
- Jumper plugs enable rapid wiring of several modules
- Can be used without programming

The LSB-modules are analog input modules with a wide range of applications. They are controlled by LSB (setting P3895) for installation on a DIN rail (see section 4.5). **These modules cannot be controlled by CAN.** The module is triggered by a variable address (1 - 99) and the status of inputs is transferred to the data bits. If the input status changes, a message is immediately sent to the LSB.

Inputs can be switched from voltage input to temperature measurement input. The following settings can be made for every input using a DIP switch:

- 0 - 10 V DC, Ni1000 (-50 to +150 °C/-58 to 300 °F)
  - Pt1000 (-50 to +150 °C/-58 to 300 °F)
  - Pt1000 (0 to +400 °C/-4 to 752 °F)
- Temperature sensors that can be used: Pt1000, Ni1000.




To use the analog input module configured using P3821, “LSB input1” to “LSB input4” must be set as the desired analog input in P572 (582, 592, 602). This enables asynchronous balanced mode with integrated analog inputs and LSB inputs, which is necessary with the LAMBDA TRANSMITTER E , since input 4 is assigned entirely to temperature measurement. If the module or LSB fails, the analog values will fall to 0 after approximately 3 seconds. The address to be set is stored in parameter 3821.





**NOTE**

Make sure that the address you set is not the same as another LSB module address!

The conversion factor is always 20 mA<->10 V.









**NOTE for current input:**

0 - 3 mA → 0 - 1.5V, 3 - 4 mA → 1.5 - 2 V, 4 - 20 mA → 2 - 10 V

### 10.2.2 Setting the Parameters for analog input module (with Software Version 4V24 or More Recent)

Activation of analog input module	Analog input 1	Analog input 2	Analog input 3	Analog input 4
P3821 P3895 on LSB	P572	P582	P592	P602

## Optional Accessories - LSB-Module with 4 Analog Inputs

---

### 10.2.3 Technical Specifications

---

#### Input Module

---

- Rated voltage UN 24 V DC
- Current consumption 50 mA
- Power consumption 1.2 W
- Operating voltage range 0.8 - 1.1 x UN
- Operating temp. range 0 °C to +55 °C (-4 °F to 130 °F)
- Storage temp. range -25 °C to +70 °C (-13 °F to 158 °F)
- Suppressor circuit Polarity reversal protection for operating voltage
- Function display Green LED for BUS activity and supply voltage
- Operation display Red LED for BUS error messages
- Input/BUS test voltage no disconnection
- Article number 663R4026S (with connection cable)
- Article number of external power pack 663R4024

#### Analog Inputs

---

- Connectable temperature sensor
  - Pt1000,
  - Ni1000
- Temperature meas. range
  - -50 °C to +150 °C (-50 to 300 °F)
- Resolution
  - -50 °C to +150 °C 10 bit (appr. 0.2 °C)
- Tolerance
  - -50 °C to +150 °C approx. ±0.2 °C
- Additional meas. Range
  - Pt1000 0 °C to +400 °C (32 to 750 °F)
- Resolution
  - 0 °C to +400 °C 10 bit (approx 0.5 °C)
- Tolerance
  - 0 °C to +400 °C approx. ±0.5 °C
- Voltage measurement range
  - 0 - 10 V DC
- Resolution
  - 10 bit (10 mV/bit)
- Tolerance
  - Approx. ±20 mV
- Input resistance
  - 200 kΩ
- Response time (from receiving to sending)
  - 15 ms (msec)
- Analog value updates
  - at least every 3 s
- Recovery time
  - 550 ms (msec)

#### Housing

---

- Degree of protection (EN 60529)
  - Housing: IP50, terminals: IP20
- Range of relative humidity acc. to IEC60721-3-3
  - Environment class 3k3
- Connection cross-chapter of device terminals
  - 2.5 mm<sup>2</sup> (0.038 in<sup>2</sup>)
- Connection cross-chapter of screwable plug-in terminals (BUS, power supply)
  - 1.5 mm<sup>2</sup> (0.023 in<sup>2</sup>)
- Weight
  - 95 g (0.2 lb)
- Housing dimensions (W x H x D)
  - 35 x 68 x 60 mm (1.4 x 2.7 x 2.4 in)

## 10.3 LSB-Moduel with 4 Digital Outputs

### 10.3.1 Functional Description

- 4 relay outputs of 250 V, 6 A
- Jumper plugs enable rapid wiring of several modules
- Manual emergency operation level
- Can be used without programming


The LSB-modules are digital output modules with a wide range of applications. They are controlled by LSB (setting P3895) for installation on a DIN rail (see section 4.5). **These modules cannot be controlled by CAN.** The module is triggered by a variable address (1 - 99) and the databits are informed whether data is required or commands are to be carried out.

The 7 relay outputs can be output to 2 LSB relay modules, output 1 to 4 on the module set in P3822, and output 5 to 7 on the modules selected in P3823. You can find the address to be set in parameter 3822 and P3823.



#### NOTE

Make sure that the address you set is not the same as another LSB module address!



#### Manual emergency operation level

Position "1" → output contact always closed

Position "A" → output contact switched via LSB bus

Position "0" → output contact always open

## Optional Accessories - LSB-Moduel with 4 Digital Outputs

### 10.3.2 Setting the Parameters for digital output module (with Software Version 4V24 or More Recent)

Activation of digital output module 1	Relay output 1	Relay output 2	Relay output 3	Relay output 4
P3822 P3895 on LSB	P1030-P1039	P1040-P1049	P1050-P1059	P1060-P1069

Activation of digital output module 2	Relay output 5	Relay output 6	Relay output 7	
P3823 P3895 on LSB	P1070-P1079	P1080-P1089	P1090-P1099	

```
***          ***  
LSB digital output module 1  
(relay output 1 4)  
P.3822: *1.Def.(Adr.3)
```

### 10.3.3 Parameters for Digital Outputs

Up to 7 digital outputs can be configured freely on the LAMBDA TRANSMITTER E . The same parameters are available for the configuration of each digital output. These are:

- Off position
- Four functions (ORed) that trigger a switching operation
- Display of the current relay position

Factory assignment of digital outputs:

- Output 1: general fault
- Output 2: general warning and/or maintenance
- Output 3: calibration
- Output 4: limit value 1
- Output 5: not configured
- Output 6: not configured
- Output 7: not configured

#### Parameter 1030 / 1040 / 1050 / 1060

Set the idle setting here. This setting is used when none of the four functions triggers a switching operation. The "diagnostics mode" setting allows the idle setting to be changed by means of the "position" parameter.

- Low (open-circuit current principle)
- High (closed-circuit current principle)
- Diagnostics mode



## Optional Accessories - LSB-Moduel with 4 Digital Outputs

---

Parameters 1031-1034 / 1041-1044 / 1051-1054 / 1061-1064

---

The four functions are more or less identical and an operating status can act as a switching criterion. If a "limit value" (Li 1-4) is selected as a switching criterion, the output will switch when the limit value output is set. If "calibration" is selected as a switching criterion, for example, the output is not set to the off position during calibration.

Each function (A, B, C, D) can have all of the operating statuses as switching criteria, although limit values Li1-4 or measuring gases are only allocated to individual functions. "Limit value 1" and "measuring gas 1" can only be allocated to "function A"; similarly "limit value 2" and "measuring gas 2" can only be assigned to "function B" etc. However, the OR operation used for the four functions allows all combinations to be varied.

The following operating statuses can be selected as switching criteria:

Warning, fault, calibration, check, cold start, measurement, maintenance, limit values 1 – 4, measuring gas 1 - 2

Parameter 1039 / 1049 / 1059 / 1069

---

This parameter displays the current switching state. If the parameter is changed in diagnostics mode, the output can be switched manually.

```
*** Relay 1 ***
P.1030: Relay active
P.1031: Malfunction
P.1032: Off
P.1033: Off
P.1034: Off
P.1039: De activated
```

## Optional Accessories - LSB-Moduel with 4 Digital Outputs

---

### 10.3.4 Limit Value Monitoring (Li)

---

#### Exceeding/Undershooting the Limit Value Display

---

See section 5.5

#### Parameter 930 / 940 / 950 / 960

---

Selection of the variable to be monitored for limit value 1 (2, 3, 4)

0 = off, 1 = measured O<sub>2</sub> value, 2-7 = configurable measurement value 1-7, 8 = temperature probe, 9 = absolute pressure probe, 10 = probe current, 11 = probe voltage

#### Parameter 931/932 / 941/942 / 951/952 / 961/962

---

Form for maximum comparison value for Li 1 (2, 3, 4)

0 = off, 1 = constant value, 2-13 = calculated analog value 1-12

Form for minimum comparison value for Li 1 (2, 3, 4)

0 = off, 1 = constant value, 2-13 = calculated analog value 1-12

#### Parameter 933 / 943 / 953 / 963

---

Constant for maximum comparison value for Li 1 (2, 3, 4)

(only when 931, 941, 951, 961 = constant value)

#### Parameter 934 / 944 / 954 / 964

---

Constant for minimum comparison value for Li 1 (2, 3, 4)

(only when 932, 942, 952, 962 = constant value)

#### Parameter 935 / 945 / 955 / 965

---

Reset mode for limit value 1 (2, 3, 4)

0 = automatic, 1 = manual, 2 = acknowledge

#### Parameter 936 / 946 / 956 / 966

---

Trigger delay for limit value 1 (2, 3, 4)

```
*** Limit value config. ***
P. 930: 02 measuring value
P. 931: Calc. analog val. 1
P. 932: Const. value
P. 933: 2
P. 934: 1
P. 935: Automatical
P. 936: 15 s
P. 940: Conf. meas. value 1
```

## Optional Accessories - LSB-Module with 4 Digital Outputs

---

### 10.3.5 Technical Specifications

---

#### Output Module

---

- Rated voltage  $U_N$
  - Current consumption
  - Power consumption
  - Operating voltage range
  - Response time (from receiving to relay switching)
  - Release time (from receiving to relay switching)
  - Recovery time
  - Operating temperature range
  - Storage temperature range
  - Suppressor circuit
  - Relay status display
  - Function display
  - Operation display
  - Special features
  - Article number
  - Article number of external power pack
- 24 V DC
  - 100 mA
  - 2.4 W
  - $0.8 - 1.1 \times U_N$
  - 15 ms (msec)
  - 15 ms (msec)
  - 200 ms (msec)
  - $0\text{ }^\circ\text{C}$  to  $+55\text{ }^\circ\text{C}$  ( $-4\text{ }^\circ\text{F}$  to  $130\text{ }^\circ\text{F}$ )
  - $-25\text{ }^\circ\text{C}$  to  $+70\text{ }^\circ\text{C}$  ( $-13\text{ }^\circ\text{F}$  to  $158\text{ }^\circ\text{F}$ )
  - Polarity reversal protection for operating voltage
  - LED
  - Green LED for BUS activity and supply voltage
  - Red LED for BUS error messages
  - Manual operation level with confirmation via BUS
  - 663R4027S (with connection cable)
  - 663R4024

#### Digital Outputs

---

- Output contact/material
  - Switching voltage
  - Max. making/breaking current
  - Continuous current
  - Protection of contacts
  - Mechanical durability
  - Contact life
  - Permissible number of operations (cycles) per hour
  - Insulation in accordance with VDE 0110
  - Rated voltage
  - Overvoltage category
  - Contamination level
  - Coil/contact test voltage
  - Contact/contact test voltage
- 4 NO contacts / AgNI
  - max. 250 V
  - 12 A / 4 s at 10 % on period
  - 6 A/relay, but max. 12 A/module
  - 6 A
  - 1x10<sup>7</sup> operating cycles
  - 1x10<sup>5</sup> operating cycles
  - 360 at nominal load
  - C
  - 250 V
  - II
  - 2
  - 4,000 V AC 50 Hz 1 min
  - 1,000 V AC 50 Hz 1 min

#### Housing

---

- Degree of protection (EN60529)
  - Connection cross-chapterof device terminals
  - Connection cross-chapterof screwable plug-in terminals (BUS, power supply)
  - Weight
  - Housing dimensions (W x H x D)
- Housing: IP50, terminals: IP20
  - 2.5 mm<sup>2</sup> (0.038 in<sup>2</sup>)
  - 1.5 mm<sup>2</sup> (0.023 in<sup>2</sup>)
  - 95 g (0.2 lb)
  - 35 x 68 x 60 mm (1.4 x 2.7 x 2.4 in)


10.4 LSB-Module with 4 Digital Inputs




**IMPORTANT!**

The module 663R4228 can not be used, without re-wiring, as a spare part for the module 663R4028.

Pin assignment of the module **663R4028 (deliverable till December 2007)**



Pin assignment of the module **663R4228 (deliverable from January 2008)**



## Optional Accessories - LSB-Module with 4 Digital Inputs

### 10.4.1 Functional Description 663R4028/663R4228

- 4x 24 V DC digital inputs  
Inputs are made as 24 V DC voltage inputs with electrically isolation (663R4028) / without electrically isolation (663R4228).
- Jumper plugs enable rapid wiring of several modules
- Manual emergency operation level
- Can be used without programming

The LSB modules are input modules with a wide range of applications. They are controlled by LSB (setting P3895) for installation on a DIN rail (see section 4.5).


**These modules cannot be controlled by CAN.** The module is triggered by a variable address (1 - 99) and the status of inputs is transferred to the data bits. If the input status changes, a message is immediately sent to the BUS.

Digital inputs can be specified via 2 LSB modules: the module set in P3824 specifies inputs 1 to 4, the module set in P3825 specifies 5 to 8. If communication fails or a module is missing, the input signals change to 0 and timeout occurs after 3 seconds. The address to be set is stored in parameter 3824 and P3825.



#### NOTE

Make sure that the address you set is not the same as another LSB module address!



Manual emergency operation level

Position "1" → input always on HIGH

Position "A" → input switched extraneously via contact

Position "0" → input always on LOW

## Optional Accessories - LSB-Module with 4 Digital Inputs

---

### 10.4.2 Setting the Parameters for digital input module (with Software Version 4V24 or More Recent)

---

Activation of digital input module 1	Digital input 1	Digital input 2	Digital input 3	Digital input 4
P3824 P3895 on LSB	P1170-P1175	P1180-P1185	P1190-P1195	P1200-P1205

Activation of digital input module 2	Digital input 5	Digital input 6	Digital input 7	Digital input 8
P3825 P3895 on LSB	P1210-P1215	P1220-P1225	P1230-P1235	P1240-P1245

### 10.4.3 Parameters for Digital Inputs

---

Eight digital inputs can be configured for the LAMBDA TRANSMITTER E . All 8 digital inputs are identical in structure and function. They are configured using the parameters listed below.

Factory assignment of digital inputs:

- Input 1 – pump on
- Input 2 – triggers calibration
- Input 3 – triggers check
- Input 4 – triggers cyclical calibration
- Input 5 – resets faults
- Input 6 – fuel 2
- Input 7 – fuel 3
- Input 8 – fuel 4

### Idle Level Parameters 1170/1180/1190/1200/1210/1220/1230/1240

---

Here you can set the idle setting for digital inputs. If the setting deviates from the one that is set, the actions specified in the functions (A,B,C,D) will be carried out. If set here, the parameter can be used to trigger the functions (A,B,C,D) for the corresponding digital input.

- Low (open-circuit current principle), i.e. the corresponding digital input is only set when a voltage of +24 V is flowing.
- High (closed-circuit current principle), i.e. the corresponding digital input is only set when the voltage is 0 V or the input is open.
- Diagnostics mode, i.e. the input status can be changed manually (see 10.4.3.3).

## Optional Accessories - LSB-Module with 4 Digital Inputs

---

Function A, B, C, D; Parameters 1171 – 1174 / 1181 – 1184 / 1191 – 1194 / 1201 – 1204 / 1211 – 1214 / 1221 – 1224 / 1231 – 1234 / 1241 - 1244

---

The four functions are the same in structure; however, limit values LV 1 - 4 and fuels are only assigned to individual functions (A, B, C, D). Limit value 1 and fuel 1 can only be reset in function A; similarly limit value 2 and measuring gas 2 can only be reset in function B and so on. The following actions are possible:

- None
- Pump on                      Activates the measuring gas pump.
- Calibration                      Triggers automatic calibration.
- Check                              Triggers an automatic check.
- Cycl. calibration                  An internal counter counts up, automatically triggering calibration when it reaches a certain value (parameter 272). The counter is then reset to zero.
- Fault reset                      Acknowledges faults present.
- Warning reset                      Acknowledges warnings present.
- Li 1-4 reset                      Function A resets limit value 1, functions B, C, D reset limit values 2, 3, 4.
- Fuel 1                              Function A only selects fuel 1, function B, C, D select fuels 2, 3, 4.
- No cal.                              If there is a signal at this input, the device cannot carry out calibration. If calibration is still ongoing, it is stopped immediately.
- PID controller ON/OFF          Switches off PID controller.

Status Parameter 1175 / 1185 / 1195 / 1205 / 1215 / 1225 / 1235 / 245

---

This parameter displays the digital input status. The two possible statuses are “set” (the set functions will be triggered) and “not set”. The digital input status can be set manually with this parameter, as long as the “idle level” parameter is set to “Diagnostics mode”.

## Optional Accessories - LSB-Module with 4 Digital Inputs

---

### 10.4.4 Technical Specifications

---

#### Input Module

---

- Rated voltage UN
- Current consumption
- Power consumption
- Operating voltage range
- Operating temp. range
- Storage temp. range
- Suppressor circuit
- Function display
- Operation display
- Special features
- Input/BUS test voltage
- Article number
- Article number of external power pack
- 24 V/DC
- 50 mA
- 1.2 W
- $0.8 - 1.1 \times U_N$
- 0 °C to +55 °C (-4 °F to 130 °F)
- -25 °C to +70 °C (-13 °F to 158 °F)
- Polarity reversal protection for operating voltage
- Green LED for BUS activity and supply voltage
- Red LED for BUS error messages
- Manual operation level with confirmation via BUS
- 2,500 V/AC 50 Hz 1 min
- 663R4028S (till December 2007)  
663R4228S (from January 2008)  
with connecting cable
- 663R4024

#### Digital inputs

---

- Input voltage (control input)
- Input current (24 V DC) (control input)
- High-signal detection
- Low-signal detection
- Response time (from receiving to sending)
- Recovery time
- 30 V/DC
- 6 mA
- >7 V/DC
- <3 V/DC
- 15 ms (msec)
- 550 ms (msec)

#### Housing

---

- Degree of protection (EN60529)
- Range of relative humidity acc. to IEC60721-3-3
- Connection cross-chapter of device terminals
- Connection cross-chapter of screwable plug-in terminals (BUS, power supply)
- Weight
- Housing dimensions (W x H x D)
- Housing - IP50, terminals - IP20
- Environment class 3k3
- 2.5 mm<sup>2</sup> (0.038 in<sup>2</sup>)
- 1.5 mm<sup>2</sup> (0.023 in<sup>2</sup>)
- 95 g (0.2 lb)
- 35 x 68 x 60 mm (1.4 x 2.7 x 2.4 in)



10.5 Internal Connection of LSB Modules (Max. 2 Modules)



NOTE

LSB modules can only be installed internally and connected in sheet-steel housing. They cannot be installed internally in cast-aluminum housing.




Fig. 10-1:  
LSB module in LAMBDA  
TRANSMITTER E in sheet-  
steel housing

1. Attach the LSB module (without the terminating resistor) onto the mounting rail. If more than one module is to be installed, connect these using the jumper plugs provided.
2. Secure the cable from the LSB module using cable ties.
3. Connect the wires numbered 72 and 73 with the X12 plug to numbers 72 and 73.
4. Connect wires labeled +/- to the X206 plug (pin 3 = -, pin 9 = +) for the power supply.
5. Set the parameters in LAMBDA TRANSMITTER E (see chapter 4.5, 10.1 – 10.4)
6. Check the plug-in jumpers on the LAMBDA TRANSMITTER E base electronic

## **Optional Accessories - Internal Connection of LSB Modules (Max. 2 Modules)**

---

(see chapter12.5.1).

### 10.6 External Connection of LSB-Module



**NOTE:**

Any external LSB module must also have an external power supply. Modules can be connected in rows without any clearance. Once there are 15 modules in a row, a new external connection to the power supply must be made.

More than 15 modules would overload the jumper plugs and cause them to burn out. If an external power supply is used, ensure that sufficient protection is available since there are no mains fuses.

Install the LSB module in the required position. If more than one module is to be installed, connect these using the jumper plugs provided.

Attach the 120 ohm LSB terminating resistor to the last module.

Connect the LSB module to the external power supply (24 V DC) and the LSB. Order-Nr. Ext. power supply: 663 R 4024



**NOTE:**

The maximum cable length between the LAMBDA TRANSMITTER E and the LSB module is 500 m.

The module is connected to the LSB using the 7-pin connector on the housing. See also chapter 3.4.

7-pin LSB/CAN connection to the gas extraction device and filter heater

7-pin LSB/CAN connection to other devices with a LSB/CAN terminal



1 - NC  
2 - CAN GND  
3 - CAN low  
4 - CAN high  
5 - GND from EVU  
6 - +24 V from EVU  
7 - PE

Set the parameters in LAMBDA TRANSMITTER E (see chapter 4.5, 10.1 – 10.4)

Check the plug-in jumpers on the LAMBDA TRANSMITTER E motherboard (see chapter 12.5.1).

Recommendations for lengths and cross-sectional areas of LSB cables are listed below:

0 - 40m     1 x 2 x 0,22 mm<sup>2</sup> (0.4 x 0.8 0.01 in<sup>2</sup>), stranded in pairs, shielding, 120 Ω  
40 - 300 m   1 x 2 x 0,34 mm<sup>2</sup> (0.4 x 0.8 0.01 in<sup>2</sup>), stranded in pairs, shielding, 120 Ω  
300 - 500 m     1 x 2 x 0,5 mm<sup>2</sup> (0.4 x 0.8 0.02 in<sup>2</sup>), stranded in pairs, shielding, 120 Ω

### 10.7 Activating of LSB-Modules

---

Examination at the LSB module

- Make sure, that CAN low and CAN high, also the 24V-supply voltage are correctly connected.
- Make sure, that at the freely connection side between CAN low and CAN high a 120R-termination resistor is connected.
- Set the LSB address at the module (up 10er, down 1er), which is specified in parameter 3820...3825 in LAMBDA TRANSMITTER E.  
No address may be assigned doubly.
- With digital modules the switches of the hand control level must be set to „A“ .

#### **Examination of the parameters in LAMBDA TRANSMITTER E**

(see chapter 10.1...10.4)

- One or more parameter 3820...3825 (depending from numbers of modules) must be activated
  - P3820 – Activated a LSB module with 4 analog outputs
    - P530...539 configured analog output 1
    - P540...549 configured analog output 2
    - P550...559 configured analog output 3
    - P560...569 configured analog output 4
  - P3821 – Activated a LSB module with 4 analog inputs
    - P570...579 configured analog input 1
    - P580...589 configured analog input 2
    - P590...599 configured analog input 3
    - P600...609 configured analog input 4
  - P3822 – Activated a LSB module with digital outputs 1...4
    - P1030...1039 configured relay output 1
    - P1040...1049 configured relay output 2
    - P1050...1059 configured relay output 3
    - P1060...1069 configured relay output 4
  - P3823 – Activated a LSB module with digital outputs 5...7
    - P1070...1079 configured relay output 5
    - P1080...1089 configured relay output 6
    - P1090...1099 configured relay output 7
  - P3824 – Activated a LSB module with digital inputs 1...4
    - P1170...1175 configured digital input 1
    - P1180...1185 configured digital input 2
    - P1190...1195 configured digital input 3
    - P1200...1205 configured digital input 4
  - P3825 – Activated a LSB module with digital inputs 5...8
    - P1210...1215 configured digital input 5
    - P1220...1225 configured digital input 6
    - P1230...1235 configured digital input 7
    - P1240...1245 configured digital input 8
- Parameter 3895 in LAMBDA TRANSMITTER E must be set to „LSB“.

### **Setting of the plug-in jumpers in LAMBDA TRANSMITTER E** (see chapter 12.5)

- The jumpers BR10..14 (selection CAN/RS422) on the base electronic must be set to „CAN“.
- The jumper BR15 (termination resistor ON/OFF) on the base electronic must be set to „R“ (ON).
- The jumpers BR12 and BR13 (selection CAN/RS422) on the processor card must be set to „C“ (CAN).

### **Setting of the plug-in jumpers in connection with a optionally power pack for GED and pre-filter heater** (see chapter 12.5)

- The jumpers BR10..14 (selection CAN/RS422) on the base electronic must be set to „CAN“.
- The jumper BR15 (termination resistor ON/OFF) on the base electronic must be set to „CAN“ (OFF).
- The jumpers BR12 and BR13 (selection CAN/RS422) on the processor card must be set to „C“ (CAN).
- The jumper JP2 (termination resistor ON/OFF) on the power pack electronic board must be set to “2-3“ (ON).  
see chapter 4.6.3
- The DIP switch 1 on the power pack electronic board must be set to „ON“ (LSB operation)

### **After power on the following condition must be present**

- Red LED at LSB module is OFF
- Green LED at LSB module is blinking
- CAN Rx/Tx-LEDs am LT10P are jittering

### **If not, the following problem solutions**

- No LED at LSB module is flashing
  - No 24V supply voltage
- Green LED at LSB module steady light, red LED is blinking
  - LSB module without address
  - No or wrong parameter 3820...3825 is activated
- Green and red LED at LSB module steady light
  - Wrong adresse at LSB module is setted
  - Parameter 3895 set to „CAN“, must be set to „LSB“
  - Jumpers BR10...14 on base electronic in position „RS422“

### 10.8 Compressed Air Unit to Supply the LAMBDA TRANSMITTER E

#### 10.8.1 Compressed Air Unit on Mounting Plate




Fig. 10-2:  
dimensions in mm

- 1 Pre-pressure regulator (set to 4 bar/58 psi)
- 2 Ejector pressure regulator (set to 2 bar/29 psi)
- 3 Pressure regulator for Calibration air/housing cooling (set to 2 bar/29 psi)
- 4 Hose connection for compressed air input, nominal diameter 10 mm (0.4 in). Recommended pre-pressure: 4 - 6 bar (58 - 87 psi)
- 5 Ejector hose connection 4/6 mm (0.16/0.24 in)
- 6 Hose connection for Calibration air/housing cooling 4/6 mm (0.16/0.24 in)
- 7 Hose connection for automatic condensate drain 6/8mm (0.24/0.31 in)
- 8 Two fixing holes for alternative flange mounting
- 9 Four attachments for wall mounting

Weight: 5.7 kg (12.6 lb)

Type: 657R3005 for LAMBDA TRANSMITTER E in cast-aluminum housing

Type: 657R4015 for LAMBDA TRANSMITTER E in sheet-steel housing

## 10.8.2 Compressed Air Unit in Housing Heated to Temperatures $< 0\text{ }^{\circ}\text{C}$ ( $< 32\text{ }^{\circ}\text{F}$ )




Fig. 10-3:  
Compressed air unit in  
housing of LAMBDA  
TRANSMITTER E

- 1 Pre-pressure regulator (set to 4 bar/58 psi)
- 2 Ejectorpressure regulator (set to 2 bar/29 psi)
- 3 Pressure regulator for Calibration air/housing cooling (set to 2 bar/29 psi)
- 4 Hose connection for compressed air input, nominal diameter 10mm.  
Recommended pre-pressure: 4 - 6 bar (58 - 87 psi)
- 5 Ejectorhose connection 4/6 mm (0.16/0.24 in)
- 6 Hose connection for Calibration air/housing cooling 4/6 mm (0.16/0.24 in)  
**In points 4, 5 and 6, feed the hose through the cable connection and secure it to the hose connection.**
- 7 Hose connection for automatic condensate drain 6/8mm
- 10 Fuse terminal (T2 fuse, 5 A)
- 11 Housing heater, 320 W 230 V

Weight: 11 kg (24.2 lb)

Type: 657R3006

Dimensions (W x H x D): 300 x 400 x 150 mm (12 x 15.7 x 6 in)




Fig. 10-4:  
Dimensions

## 10.9 Gas Extraction Kit with Heater for Gas Extraction Device

The gas extraction device heater must be used in the following cases:

- Test gas temperatures below the water/acid dew point
- Penetration of brick stacks with very thick walls where there is a risk of the temperature in the capillary falling below the dew point.




Fig. 10-5:  
Protective pipe for gas extraction device with heater and protective pipe support on the LAMBDA TRANSMITTER E

Insertion depth	Type (order no.)	Connection cable length	Material
800 mm (31.5 in)	6 57 R 3051	2 m (6.6 ft)	1.4571
1,000 mm (39.4 in)	6 57 R 3052	2 m (6.6 ft)	1.4571
1,400 mm (55.1 in)	6 57 R 3053A	2 m (6.6 ft)	1.4571
1,800 mm (70,9 in)	6 57 R 3054A	2 m (6.6 ft)	1.4571
Type corrosion-resistant-steel (REA) on request			1.4539
Additional protective pipe for Type REA-steel on request			Polyester
Cable connectors for extending the gas extraction device and filter heater type 6 57 R 3168			

## 10.10 Gas Extraction Kit with Gas Extraction Device and Filter Heater

The heater for the sintered metal filter attachment must be used when measuring gas temperatures fall below the dew point.




Fig. 10-6:  
Heater for sintered metal filter attachment

Insertion depth	Type (order no.)	Connection cable length
800 mm (31.5 in)	6 57 R 3061	2 m (6.6 ft)
1,000 mm (39.4 in)	6 57 R 3062A	2 m (6.6 ft)
1,400 mm (55.1 in)	6 57 R 3063A	2 m (6.6 ft)
1,800 mm (70,9 in)	6 57 R 3064A	2 m (6.6 ft)
Cable connectors for extending the GED and filter heater (type 6 57 R 3168)		



### 10.11 Protective Pipe for High-Dust Applications




Fig. 10-7:  
Protective pipe for high-dust applications

No.	Component	Type (order no.)
<b>1</b>	Connection flange for protective pipe for high-dust applications	657R3511/R3512
<b>2</b>	Counterflange	657R3506/R3507
<b>3</b>	Pressure disks with disk springs and graphite seal	657P3531/R3532/R3530
<b>4</b>	Protective pipe for high-dust applications (standard 1.4571) External diameter 60mm Internal diameter 55mm	657 R 3560 (500mm) 657 R 3561 (800mm) 657 R 3562 (1000mm) 657 R 3563 (1400mm) 657 R 3564 (1800mm)
<b>5</b>	Gas extraction kit (standard 1.4571)	657 R 3010 (500mm) 657 R 3011 (800mm) 657 R 3012 (1000mm) 657 R 3013 (1400mm) 657 R 3014 (1800mm)



Pressure disks with disk springs and graphite seals are supplied with the counterflange.  
For installation instructions, see chapter 4.7.

## 10.12 Ceramic Gas Extraction Device

For measuring gas temperatures of between 950 °C (1,740 °F) and 1,400 °C (2,552 °F), a ceramic gas extraction device must be used in conjunction with a ceramic protective pipe.




Fig. 10-8:  
Ceramic gas extraction  
device with ceramic  
protective pipe

- |  |                       |
|--|-----------------------|
| 1 Gas extraction tube                      | 5 Cladding/insulation |
| 2 Ceramic filter (filter mesh: 50 μm)      | 6 Boiler wall         |
| 3 Ceramic protective pipe with filter      | 7 Insulation          |
| 4 Protective pipe to prevent heat transfer | 8 Flange              |

Insertion depth	Type (order no.)
500 mm (19.7 in)	6 57 R 3030
800 mm (31.5 in)	6 57 R 3031
1,000 mm (39.4 in)	6 57 R 3032
1,400 mm (55.1 in)	6 57 R 3033A
1,800 mm (70,9 in)	6 57 R 3034A

## 10.13 Counterflange




Fig. 10-9:  
Counterflange

Type	Material
657 R 3506	Steel (cataphoretically painted)
657 R 3507	Stainless steel 1.4571 (V4A)

### 10.14 Optional Second RS422 Interface, Type K6029318

An RS422 module, a connection cable, an adapter board and a holding plate must be used for this option. Two holding plates are always supplied to cover both housing types (sheet steel and cast aluminum).

See also chapter 4.5.




Fig. 10-10:  
Components of the 2nd  
RS422 interface

The second RS422 interface is required if a GM31 analyzer is to be connected and the CAN or LSB interface is already assigned to an Evaluation unit or gas extraction device and filter heater, or an LSB module. If the CAN or LSB interface is not assigned, the RS422 interface provided (X12 on board) can be used. It must first be set via plug-in jumpers, however (see chapter 12.5.1).

10.14.1 Installing the Second RS422 Interface in Sheet-Steel Housing




Fig. 10-11:  
Installing the Second  
RS422 Interface in Sheet-  
Steel Housin




Fig. 10-12:  
Installing the adapter board  
on the processor board




Fig. 10-13:  
Connecting and laying the  
connection cable





**IMPORTANT!**

Never connect the RS422 module when it is energized. It may be destroyed!!

Switch off the power supply to the LAMBDA TRANSMITTER E .

Open the LAMBDA TRANSMITTER E housing and front plate.

Secure the holding plate (3), with the RS422 module (1) attached, to the cable connection (a). See Fig. 10-10.

Plug the connection cable (5) into the RS422 module and route it under the front plate to the front side of the LAMBDA TRANSMITTER E . Then close the front plate.

Remove the Perspex disk protecting the processor board. To do this, you must loosen three 3 screws.

Remove the jumpers (x 9) from the processor board (b). See Fig. 10-11.

Unscrew the three plastic screws (c) from the spacer on the processor board.

Plug the adaptor board (2) into the processor board (d) (e).

Screw the adaptor board (2) back together with the spacer (f).

Snap off and remove the small lugs on the jumpers (g).

Connect the RS422-module connection cable (5) to the adapter board (2)(h). See Fig. 10-12.

The ribbon cable can be trimmed as needed since this will also be used in the LAMBDA TRANSMITTER E in cast-aluminum housing.

Affix the cable run (i) and secure the connection cable to it.

Screw the Perspex disk back on to the processor board (j).

Close the LAMBDA TRANSMITTER E housing and reconnect the power supply.

10.14.2 Installing the Second RS422 Interface in Cast-Aluminum Housing




Fig. 10-14:  
Securing the RS422  
modules on the side of the  
cast housing




Fig. 10-15:  
Installing the adapter board  
on the processor board



Fig. 10-16:  
Connecting and laying the  
connection cable



**IMPORTANT!**

Never connect the RS422 module when it is energized. It may be destroyed!!

1. Switch off the power supply to the LAMBDA TRANSMITTER E .
2. Open the LAMBDA TRANSMITTER E housing.
3. Attach the RS422 module on the side wall of the housing using double-sided adhesive tape (a). See Fig. 10-14.
4. Plug the connection cable (5) into the RS422 module and route it over the front plate to the front side of the LAMBDA TRANSMITTER E . Then close the front plate. See Fig. 10-14.
5. Remove the jumpers (x 9) from the processor board (b). See Fig. 10-14.
6. Unscrew the three plastic screws (c) from the spacer bolts on the processor board.
7. Plug the adaptor board (2) in to the processor board (d) (e).
8. Screw the adaptor board (2) back together with the plastic screws (f).
9. Connect the RS422-module connection cable (5) to the adapter board (2)(g). See Fig. 10-15; 10-16
10. Close the LAMBDA TRANSMITTER E housing and reconnect the power supply.
11. The second RS422 interface is now ready for operation. No further settings need to be made.



### 11 Spare Parts and Consumables



#### NOTE

- \* Recommendation: place spare parts in storage
- (1) The operator must decide upon suitable storage measures.
- (2) Spare part for optional components.
- (3) Available in other lengths (specifications in the price lists or available on request)

#### 11.1 Consumables:

---

- \* 1 ZrO<sub>2</sub> measuring cell with contact  
Average service life: 2 to 4 years (depending on fuel)  
Type 6 57 R 3201
- \* 1 heater measuring cell  
Average service life: 2 to 4 years  
Type 6 57 R 3203
- \* 1 mounting paste (anti-seize paste)  
(x 5)  
6 50 R 1090
- \* 1 sampling filter for gas extraction device up to 950 °C (1,740 °F)  
Type 6 55 R 0028
- \* 1 sintered metal filter insert 50 µm (x 10)  
For sampling filter type 6 55 R 0028,  
Type 6 55 R 2803
- \* 1 filter attachment for probe installation fittings,  
Type 6 55 R 0212 – filter mesh 20 µm (standard)  
Type 6 55 R 0211 – filter mesh 10 µm  
Type 6 55 R 1210 – filter mesh 40 µm  
Type 6 55 R 0208 – filter mesh 2 µm

### 11.2 Spare Parts:

---

- <sup>(1)</sup> 1 "measuring chamber" repair kit  
Type 6 57 R 3206
- <sup>(1)</sup> 1 "seal set" measuring chamber  
Type 6 57 R 3212
- <sup>(1)</sup> 1 "seal set" measuring cell  
Type 6 57 R 3213
- <sup>(1)</sup> 1 replacement Ejectorpump (complete) with heater  
Type 6 57 R 3202
- <sup>(1)</sup> 1 PT 100 temperature sensor - for probe temperature (capillary)  
Type 6 57 R 3205
- <sup>(1)</sup> 1 gas extraction device with integrated capillary  
for insertion depth of 500 mm  
Type 6 57 R 3310
  - Insertion depth 300 mm (11,8 in) Type 6 57 R 3315
  - Insertion depth 800 mm (31.5 in) Type 6 57 R 3311
  - Insertion depth 1,000 mm (39.4 in) Type 6 57 R 3312
  - Insertion depth 1,400 mm (55.1 in) Type 6 57 R 3313
  - Insertion depth 1,800 mm (70,9 in) Type 6 57 R 3314
- <sup>(1)</sup> 1 ceramic gas extraction device, insertion depth 500 mm  
Type 6 57 R 3330
  - Insertion depth 800 mm (31.5 in) Type 6 57 R 3331
  - Insertion depth 1,000 mm (39.4 in) Type 6 57 R 3332
  - Insertion depth 1,400 mm (55.1 in) (1,000 mm ceramic) Type 6 57 R 3333
  - Insertion depth 1,800 mm (70,9 in) (1,000 mm ceramic) Type 6 57 R 3334
- <sup>(1)</sup> 1 securing mechanism for protective pipe for gas extraction device  
Type 6 55 R 0630
- <sup>(1)</sup> 1 protective pipe (standard) for gas extraction device, material: 1.4571 (V4A),  
incl. sintered metal pre-filter, for measuring gas temperatures up to 700 °C (1,290 °F),  
for the following insertion depths:
  - 500 mm (19.7 in) → 6 57 R 3410
  - 800 mm (31.5 in) → 6 57 R 3411
  - 1,000 mm (39.4 in) → 6 57 R 3412
  - 1,400 mm (55.1 in) → 6 57 R 3413
  - 1,800 mm (70,9 in) → 6 57 R 3414
- <sup>(1)(2)</sup> 1 protective pipe (Inconell 600) for gas extraction device,  
incl. sintered metal pre-filter, for measuring gas temperatures up to 950 °C (1,740 °F),  
for the following insertion depths:
  - 500 mm (19.7 in) → 6 57 R 3420
  - 800 mm (31.5 in) → 6 57 R 3421
  - 1,000 mm (39.4 in) → 6 57 R 3422
  - 1,400 mm (55.1 in) → 6 57 R 3423
  - 1,800 mm (70,9 in) → 6 57 R 3424
- <sup>(1)(2)</sup> 1 protective pipe (ceramic/metal-ceramic version) for gas extraction device for  
measuring gas temperatures up to 1,400 °C (2,552 °F), incl. pre-filter  
for the following gas extraction device insertion depths:
  - 500 mm (19.7 in) → 6 57 R 3430
  - 800 mm (31.5 in) → 6 57 R 3431
  - 1,000 mm (39.4 in) → 6 57 R 3432
  - 1,400 mm (55.1 in) → 6 57 R 3433
  - 1,800 mm (70,9 in) → 6 57 R 3434
- <sup>(1)(2)</sup> 1 support for gas extraction device (standard) with flange and seal  
Material: stainless steel 1.4571 (V4A)  
Type 6 57 R 3510

## Spare Parts and Consumables - Spare Parts:

---

- <sup>(1)(2)</sup> 1 support for gas extraction device without flange; only in connection with gas extraction device heater  
Material: stainless steel 1.4571 (V4A)  
Type 6 57 R 3520
- <sup>(1)(2)</sup> 1 replacement measuring gas sampling heater (complete), with protective pipe, without sintered metal pre-filter for the following insertion depths:  
Material stainless steel 1.4571 (V4A)  
500 mm (19.7 in) → 6 57 P 3450  
800 mm (31.5 in) → 6 57 P 3451  
1,000 mm (39.4 in) → 6 57 P 3452  
1,400 mm (55.1 in) → 6 57 P 3453  
1,800 mm (70,9 in) → 6 57 P 3454  
Type corrosion-resistant steel 1.4539 on request  
Additional protective pipe polyester on request
- <sup>(1)(2)</sup> 1 replacement heater for sintered metal filter attachment for the following insertion depths:  
800 mm (31.5 in) → 6 57 R 3471  
1,000 mm (39.4 in) → 6 57 R 3472  
1,400 mm (55.1 in) → 6 57 R 3473  
1,800 mm (70,9 in) → 6 57 R 3474
- <sup>(1)(2)</sup> 1 replacement electronics for gas extraction device and filter heater (complete)  
6 57 R 3165
- <sup>(1)(2)</sup> 1 replacement transformer for gas extraction device and filter heater  
Type 6 57 R 3166
- <sup>(1)</sup> 1 replacement computer electronics  
Type 6 57 R 1874
- <sup>(1)</sup> 1 replacement base electronics without pressure sensors for LAMBDA TRANSMITTER E in cast-aluminum housing  
Type 6 57 P 3000
- <sup>(1)</sup> 1 replacement base electronics without pressure sensors for LAMBDA TRANSMITTER E in sheet-steel housing  
Type 6 57 P 4000
- <sup>(1)</sup> 1 replacement power pack (transformer)  
Type 6 57 R 3874
- <sup>(1)</sup> 1 replacement display/control unit for LAMBDA TRANSMITTER E in sheet-steel housing  
Type 6 57 R 4130
- <sup>(1)</sup> 1 differential pressure sensor for LAMBDA TRANSMITTER E in cast-aluminum housing  
Type 6 57 R 0537
- <sup>(1)</sup> 1 differential pressure sensor for LAMBDA TRANSMITTER E in sheet-steel housing  
Type 6 57 R 4001
- <sup>(1)</sup> 1 absolute pressure sensor  
Type 6 57 P 0549
- <sup>(1)</sup> 1 analog output module 0/4-20 mA / 0/2-10 V (floating)  
max. difference in potential +/-20 V  
Type 6 57 R 0051
- <sup>(1)</sup> 1 replacement fuse box  
Type 6 57 R 3102
- <sup>(1)</sup> 1 small accessories kit  
Type 6 57 R 3250
- <sup>(1)</sup> 1 proportional valve  
Type 6 57 P 3102
- <sup>(1)</sup> 1 solenoid valve baseplate  
Type 6 57 R 0402

## Spare Parts and Consumables - Spare Parts:

---

- <sup>(1)(2)</sup> 1 replacement external power supply for LSB-module  
Type 6 57 R 4024
- <sup>(1)(2)</sup> 1 replacement LSB-module analog output (voltage), without connection cable  
Type 6 57 R 4025
- <sup>(1)(2)</sup> 1 replacement LSB-module analog output (current), without connection cable  
Type 6 57 R 4029
- <sup>(1)(2)</sup> 1 replacement LSB-module analog input, without connection cable  
Type 6 57 R 4026
- <sup>(1)(2)</sup> 1 replacement LSB-module digital output, without connection cable  
Type 6 57 R 4027
- <sup>(1)(2)</sup> 1 replacement LSB-module digital input, without connection cable  
Type 6 57 R 4028  
Type 6 57 R 4228 (from January 2008)
- <sup>(1)(2)</sup> 1 replacement RS422 module, without connection cable  
Type 6 63 P 0503
- <sup>(1)</sup> 1 PUN hose, 6x1 mm, black  
Type 6 57 P 0547, running meter
- <sup>(1)</sup> 1 low-pressure PTFE hose 6 x 4 mm, natural  
Type 6 50 P 0707, running meter
- <sup>(1)</sup> 1 PTFE hose 3 x 0.5 mm  
Type 6 50 P0228, running meter
- <sup>(1)</sup> 1 pre-pressure reducer for 0 to 10 bar, with integrated water separator and drain valve for fully-automatic condensate drainage (complete)  
Type 6 57 R 3150
- <sup>(1)</sup> 1 pressure reducer for Ejectorpump and Calibration (complete)  
Type 6 57 R 3151
- <sup>(1)</sup> 1 serial connection cable, 9-pin Sub D, socket / socket 10 m long (optional)  
Type 6 63 R 0100

# 12 Appendix

## 12.1 Technical Specifications

---

Sheet-steel housing:	<ul style="list-style-type: none"><li>• Painted, stainless steel probe chapter1,4571 (V4A)</li><li>• Degree of protection in accordance with DIN 40050: IP 65; NEMA 4X</li><li>• Dimensions (H x W x D): 395 x 330 x 300 mm (15.6 x 13 x 11.8 in)</li><li>• Color: orange</li><li>• Weight: 27 kg (24.3 lb) (with 1 m<sup>3</sup>/3.3 ft gas extraction device)</li><li>• With GED-Heating 500mm/1000mm additional 4kg/6kg</li></ul>									
Cast-aluminum housing:	<ul style="list-style-type: none"><li>• Painted, stainless steel probe chapter1,4571 (V4A)</li><li>• Degree of protection in accordance with DIN 40050: IP 65; NEMA 4X</li><li>• Dimensions (H x W x D): 370 x 260 x 280 mm (14.6 x 10.2 x 11 in)</li><li>• Color: orange</li><li>• Weight: 22 kg (48.5 lb) (with 1 m<sup>3</sup>/3.3 ft gas extraction device)</li><li>• With GED-Heating 500mm/1000mm additional 4kg/6kg</li></ul>									
Ambient temperature:	<ul style="list-style-type: none"><li>• Operation: -20 °C to +55 °C (-4 °F to 130 °F).</li><li>• Transport and storage: -40 °C to +85 °C (-40 to 185 °F)</li></ul>									
Auxiliary voltage:	<ul style="list-style-type: none"><li>• 230 V AC and 115 V AC, +10% / -15%, 48 Hz to 62 Hz</li></ul> <p><b>!! To be used only in grounded power line networks !!</b></p>									
Power consumption: (without heater for gas extraction device and filter)	<ul style="list-style-type: none"><li>• Typical: 160 VA</li><li>• Max: 250 VA</li></ul>									
Measuring principle:	<ul style="list-style-type: none"><li>• Zirconium dioxide current probe</li></ul>									
Operating temperature of measuring cell:	<ul style="list-style-type: none"><li>• 800 to 1,000 °C (1,470 to 1,830 °F)</li></ul>									
Sample gas flow rate:	<ul style="list-style-type: none"><li>• 0.3 to 0.6 l/h (0.8 to 1.6 gal/hr), typ.: 0.5 l/h (0.13 gal/hr) – equal to 500 mA probe current</li></ul>									
Resolution:	<ul style="list-style-type: none"><li>• 0.1 vol. % O<sub>2</sub></li></ul>									
Measurement accuracy:	<ul style="list-style-type: none"><li>• Better than 0.2 vol. % O<sub>2</sub> across the entire range (0 to 25 vol. % O<sub>2</sub>) after previous calibration</li></ul>									
Detection limit:	<ul style="list-style-type: none"><li>• 0.1 vol. % O<sub>2</sub></li></ul>									
Cross-sensitivity:	<ul style="list-style-type: none"><li>• None vis-à-vis H<sub>2</sub>O, CO<sub>2</sub>, SO<sub>2</sub>, or HCl</li></ul>									
Signal interference from combustible gases:	<table><tr><td>At concentrations:</td><td>≤ 1,000 ppm CO</td><td>≤ -0.05 vol. % O<sub>2</sub></td></tr><tr><td></td><td>≤ 1,000 ppm NO</td><td>≤ -0.05 vol. % O<sub>2</sub></td></tr><tr><td></td><td>≤ 1,000 ppm CH<sub>4</sub></td><td>≤ -0.2 vol. % O<sub>2</sub></td></tr></table>	At concentrations:	≤ 1,000 ppm CO	≤ -0.05 vol. % O <sub>2</sub>		≤ 1,000 ppm NO	≤ -0.05 vol. % O <sub>2</sub>		≤ 1,000 ppm CH <sub>4</sub>	≤ -0.2 vol. % O <sub>2</sub>
At concentrations:	≤ 1,000 ppm CO	≤ -0.05 vol. % O <sub>2</sub>								
	≤ 1,000 ppm NO	≤ -0.05 vol. % O <sub>2</sub>								
	≤ 1,000 ppm CH <sub>4</sub>	≤ -0.2 vol. % O <sub>2</sub>								
Interference of all gases:	<ul style="list-style-type: none"><li>• ≤ +0.2 vol.% O<sub>2</sub></li></ul>									
Probe current:	<ul style="list-style-type: none"><li>• 0 to 1,000 mA, typical value for air: 300 to 600 mA, depending on flow rate</li></ul>									
Maximum permissible duration of flue gas temperature:	<table><tr><td>• Standard gas extraction device</td><td>700 °C (1,290 °F)</td></tr><tr><td>• Inconell gas extraction device</td><td>950 °C (1,740 °F)</td></tr><tr><td>• Ceramic gas extraction device</td><td>1,400 °C (2,552 °F)</td></tr><tr><td>• On request</td><td>1,600 °C (2,910 °F)</td></tr></table>	• Standard gas extraction device	700 °C (1,290 °F)	• Inconell gas extraction device	950 °C (1,740 °F)	• Ceramic gas extraction device	1,400 °C (2,552 °F)	• On request	1,600 °C (2,910 °F)	
• Standard gas extraction device	700 °C (1,290 °F)									
• Inconell gas extraction device	950 °C (1,740 °F)									
• Ceramic gas extraction device	1,400 °C (2,552 °F)									
• On request	1,600 °C (2,910 °F)									
Time-related drift of zero and reference point:	<ul style="list-style-type: none"><li>• &lt; 0.2 vol. % O<sub>2</sub> per maintenance interval</li></ul>									
Response time (90% time):	<ul style="list-style-type: none"><li>• &lt; 20 sec (with standard gas extraction device, 1 m<sup>3</sup>/3.3 ft long)</li></ul>									

## Appendix - Technical Specifications

---


Time for ready status: • < 2 hours

## Appendix - Technical Specifications

---

- Analog outputs:
- Analog output 0/4 to 20 mA, 0 to 10 V, (floating) max. diff. in potential  $\pm 20$  V
    - Resolution: 0.01 mA
    - Accuracy: 0.01 mA
    - Load: 800  $\Omega$
    - Factory setting: 4 to 20mA  $\rightarrow$  0 to 21 vol. % O<sub>2</sub>
  - Monitor output
    - Output: 0 to 2.55 V DC, load >10 kW, <100 nF
    - Accuracy: 2% from meas. value, not better than 0.1vol.% O<sub>2</sub>
    - Resolution: 10 mV
    - Factory setting: 0 to 2.55 V DC  $\rightarrow$  0 to 25.5 vol. % O<sub>2</sub>
    - Monitor function: Can be switched by means of DIP switch to:
      - Probe voltage U<sub>S</sub> 0 to 255 mV DC (= 0 to 2.55 V)
      - Int. probe (cell) resist. R<sub>I</sub> 0-255  $\Omega$ , equal to 0 to 2.55 V
  - Other analog outputs 0 to 20 mA, 0 to 10 V (via LSB module (see 10.1))
- Analog inputs:
- Analog inputs 0 to 20 mA, 0 to 10V , PT1000 possible via LSB module (see 10.2)
- Digital outputs:
- Digital outputs possible via LSB module (see 10.3)
- Digital inputs:
- Digital inputs possible via LSB module (see 10.4)
- Controls:
- Display/control unit, multi-function key, maintenance switch and 2 rows of 6 LEDs
  - Display/control unit (optional)
  - Remote control unit (optional)
  - Remote display software
- Interfaces:
- LSB bus for connection with other devices with LSB bus (alternative: RS422)
  - Additional 2<sup>nd</sup> RS422 (optional)
  - Field bus interfaces (optional):
    - Profibus DP
    - Modbus
    - Ethernet
    - CANopen
    - Interbus S
  - RS 232 for connecting a PC with remote display software
- Conformity with following European guidelines:
- 89 / 336 / EEC – electromagnetic compatibility
  - 73 / 23 / EEC – electrical equipment designed for use within certain voltage limits
- TÜV qualification test:
- TÜV qualification tested for emissions measuring devices to Federal German Pollution Control Act (13<sup>th</sup> and 17<sup>th</sup> Implementing Ordinance).  
Proof no.1: 205 155 98 N2-EP GM302  
Proof no.2: 936 21203535 / B

## 12.2 Connection Diagram



\*= to be set via parameter 3895



12.3 Dimensions




Fig. 12-1:  
Dimensions of the LAMBDA  
TRANSMITTER E

Insertion depth Dim. X in	Gas extraction kit		
	Standard up to 700 °C (1,290 °F) Type (order no.)	Up to 950 °C (1,740 °F) Type (order no.)	Ceramic 950 °C to 1,400 °C (1,740 to 2,550 °F) Type (order no.)
300 mm	657R3015	On request	On request
500 mm	657R3010	657R3020	657R3030
800 mm	657R3041	657R3021	657R3031
1,000 mm	657R3042	657R3022	657R3032
1,400 mm	657R3043A	657R3023A	657R3033A
1,800 mm	657R3044A	657R3024A	657R3034A



**IMPORTANT!**

When ordering replacement gas extraction devices, bear in mind that the insertion depth is measured from the flange, not across the entire length of the device.

12.4 Base Electronics





Fig. 12-2:  
Base electronics

Fuses and LED's

Fuse	Value	Monitoring	Function
F1	T2.5A T5A	- -	Primary line fuse at 230 V AC Primary line fuse at 115 V AC
F10	T4A	LED1 green	Operating voltage +12 V DC heater extract.
F11	T2A	LED2 green	Operating voltage +12 V DC solenoid valve
F12	T0.8A	LED3 green	Operating voltage +12 V DC proportional valves
F13	T1.6A	LED4 green	Operating voltage +6 V DC probe
F14	T0.8A	LED5 green	Operating voltage +24 V DC analog section
F15	T1.6A	LED6 green LED7 green	Operating voltage +5 V DC digital section Operating voltage -5 V DC digital section
F16	T4A	LED8 green	Operating voltage 36 V AC probe heater
F17	T4A	LED9 green	Operating voltage 29 V AC emergency probe heater
F18	T375mA	LED10 green	Operating voltage +5 V DC interface LSB/RS422
-		LED11 green	RxD LSB interface
-		LED12 yellow	TxD LSB interface
-		LED13 yellow	TxD0 RS232 interface (9-pin Sub D)
-		LED14 yellow	RxD0 RS232 interface (9-pin Sub D)

## Appendix - Base Electronics

Plugs and terminals

Designation	Function	Assignment	
X11	Power connection 115/230 V, 50/60 Hz	1 - L 2 - N 3 - PE	
X12	LSB/RS422 interface Can be set with BR10 - BR15 (Base electronics) and BR12 - BR13 (processor board) See 12.5.1	<b>LSB</b> 71 - GND 72 - CAN high 73 - CAN low 74 - CAN high 75 - CAN low 76 - GND	<b>RS422</b> 71 - GND 72 - RxD- 73 - RxD+ 74 - TxD+ 75 - TxD- - GND
	Analog output 0/4-20 mA 0/2-10 V	42- 43+	
X14	Monitor output 0-2.55 V, for connecting a multi-meter for servicing purposes	31- 32+	
X15	PT100 connection, temperature sensor for capillary temperature 0 - 820 °C (32 - 1,500 °F)		
X16	Probe connection and extraction device heater	82 - Heater for extraction device 83 - Heater for extraction device 92 - Probe heater 93 - Probe heater 94 - Measured current + 95 - Measured voltage + 96 - Measured voltage - 97 - Measured current -	
X202	Connection of solenoid and proportional valves	1 - MV1 + (Calibration) 2 - MV1 - (Calibration) 3 - PV1 + (Calibration) 4 - MV2 + (cooling) 5 - MV2 - (cooling) 6 - PV1 - (Calibration) 9 - PV2 + (eductor) 12 - PV2 - (eductor)	
X203	Transformer connection (primary side) for 230 V AC F1 - T2.5A		
X204	Transformer connection (primary side) for 115 V AC F1 - T5A		
X205	Transformer connection (secondary side)		
X206	For LT10P only		
DS1	Absolute pressure sensor		
DS2	Differential pressure sensor		

### 12.4.1 Switching over the line voltage from AC230V to AC115V (if required)

- 1.) Changing main fuse F1  
New value 5A slow-blow
- 2.) Switch over trafo connector from X203 to X204

12.5 Plug-in Jumpers

12.5.1 LSB bus / RS422




Fig. 12-3:  
Plug-in jumpers on the  
LAMBDA  
TRANSMITTER E base  
electronic

Connector X12 for  
LSB / CAN / RS422




Fig. 12-4:  
Plug-in jumpers on the  
LAMBDA  
TRANSMITTER E  
processor board

Function	Board	Plug-in jumper	Position
Activate LSB bus / RS422	base electronic Processor board	10 to 14 12 and 13	CAN * C *
Activate RS422 interface	base electronic Processor board	10 to 14 12 and 13	RS422 S
Test RS422 interface	Connect terminal 73 with 74 and 72 with 75. Switch on LAMBDA TRANSMITTER E . LEDs 11 and 12 for RS422 communication begin to pulse at the same speed (approx. 10 ms (msec) pulse).		
<b>IMPORTANT!</b> This RS422 interface can only be used if it is connected directly to the motherboard at the X12 connector. If you use devices that are connected at the LSB/CAN bus, you cannot use the RS422 interface in this way and must use the optional second RS422 interface (see 10.14) instead.			
Terminating resistor not activated	base electronic	15	CAN *
Terminating resistor activated	base electronic	15	R

\* = factory setting

## 12.5.2 Analog Output card




Fig. 12-5:  
Analog output card on base electronic




Fig. 12-6:  
Plug-in jumpers on analog output card

Type	657 R 0051 (floating)
Parameter group	530 - 539
Factory setting	4 - 20 mA => 0-21% O <sub>2</sub>
Output terminals	42- / 43+

For exchange the analog output card see chapter 8.13.

## Appendix - Plug-in Jumpers

---

### Parameter 530 / 540 / 550 / 560

---

Here, enter the measured value that is to be output at the analog output. The following settings are possible for each output:

- Off
- Measured O<sub>2</sub> value
- Configurable measured value 1 - 6
- Probe temperature
- Probe absolute pressure
- Probe current
- Probe voltage
- Internal O<sub>2</sub> value

### Parameter 531 / 541 / 551 / 561

---

Here, set the measurement range for each analog output. The following settings are possible:

- 0-20 mA / 0-10 V (for voltage output)
- 4-20 mA
- 4-20 mA / error 0 mA
- 4-20 mA / error + maintenance 0 mA

### Parameter 532 / 542 / 552 / 562

---

Here, set the start of the measurement range for each analog output.

- E.g. "0" for 0% O<sub>2</sub>

### Parameter 533 / 543 / 553 / 563

---

Here, set the end of the measurement range for each analog output.

- E.g. "210" for 21% O<sub>2</sub>


### Parameter 534 / 544 / 554 / 564

---

- Output value for each analog output in "mA"

```
*** Analog output 1 ***
P. 530: 02 Measuring value
P. 531: 4-20mA
P. 532: 0
P. 533: 210
P. 534: 20.000 mA
```

12.6 Probe Record Pass (Front)

 <p>Sensoren und Systeme für die Feuerungstechnik</p>		<h3>Sondenpass/Probe Record Card</h3>	
Lambda-Transmitter E Serien-Nr. Lambda Transmitter E Serial No.:	0100		
Messzelle-Nr./Probe No.:	12345		
Kunde/Customer:	Fa. Mustermann		
Büro/Niederlassung/Address:			
Anlage/Plant:	Musteranlage		
Inbetriebnahme/Start of operation on:	01.02.03		
Brennstoff/Fuel:	Kohle		
Einbauort/Installation location:	Kamin		
Rauchgastemperatur am Einbauort Flue gas temperature at installation location:	250	°C	
MEV-Eintauchtiefe / MEV-Submergence:	500	mm	
MEV-Heizung/MEV-Heater:	ja / nein		
Filter-Heizung/Filter-Heater:	ja / nein		
Sondenstrom unkompensiert an Luft beim Abgleich probe current without compensation on air, when cal: (Parameter 51)	500	mA	
Differenzdruck Difference pressure: (Display)	22	mbar	
Druckerhöhung beim Abgleich Pressure increase by "cal" : (Parameter 50)	2	mbar	
Temperatur Kapillare Temperature capillary: (Display)	380	°C	
RI - Messzelle / RI - probe: (Parameter 53)	0,95	Ω	







# ZIRKOR302 E

801027/2012-09 Subject to change without notice

## SICK worldwide

You will find our local subsidiary  
or agency at:  
**[www.sick.com](http://www.sick.com)**



**Your local sales and service partner**