



Level



Pressure



Flow



Temperature



Liquid  
Analysis



Registration



Systems  
Components



Services



Solutions

Operating instructions

# iTEMP<sup>®</sup> HART<sup>®</sup> TMT162

Temperature field transmitter



BA132R/24/ae/12.06

Device software  
01.03.03

## Brief overview

Using the following short form instructions you can commission your system easily and swiftly:

|  |         |
|--|---------|
| <b>Safety notes</b>  | Page 4  |
| ▼  |         |
| <b>Installation</b>  | Page 7  |
| ▼  |         |
| <b>Wiring</b>  | Page 10 |
| ▼  |         |
| <b>Display and operating elements</b>  | Page 14 |
| ▼  |         |
| <b>Commissioning</b>   | Page 20 |
| Quick Setup - fast entry into the unit configuration for standard measurements |         |

## Safety message

Instructions and procedures in the operating instructions may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by safety pictograms and symbols. Please refer to the safety messages before performing an operation preceded by pictograms and symbols, see chapter 1.5.

Though the information provided herein is believed to be accurate, be advised that the information contained herein is NOT a guarantee of satisfactory results. Specifically, this information is neither a warranty nor guarantee, expressed or implied, regarding performance; merchantability, fitness or other matter with respect to the products; and recommendation for the use of the product / process information in conflict with any patent. Please note that the manufacturer reserves the right to change and / or improve the product design and specifications without notice.



Warning!

**Failure to follow these installation guidelines could result in death or serious injury.**

– Make sure only qualified personnel perform the installation.

**Explosions could result in death or serious injury.**

- Do not remove the housing cover in explosive atmospheres when the circuit is live.
- Before connecting a Model 275/375 HART® Communicator in an explosive atmosphere, make sure the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.
- All housing covers must be fully engaged to meet explosion-proof requirements.

**Process leaks could result in death or serious injury.**

- Do not remove the thermowell while in operation.
- Install and tighten thermowells and sensors before applying pressure.

**Electrical shock could cause death or serious injury.**

- Use extreme caution when making contact with the leads and terminals.

# Table of contents

|          |   |           |                    |  |           |
|----------|---|-----------|--------------------|--|-----------|
| <b>1</b> | <b>Safety notes</b> .....                       | <b>4</b>  | 9.7                | Software history .....                 | 40        |
| 1.1      | Designated use .....                            | 4         | <b>10</b>          | <b>Technical data</b> .....            | <b>42</b> |
| 1.2      | Installation, commissioning and operation ..... | 4         | <b>11</b>          | <b>Appendix</b> .....                  | <b>51</b> |
| 1.3      | Operational safety .....                        | 5         | 11.1               | The Callendar - van Dusen Method ..... | 51        |
| 1.4      | Returns .....                                   | 5         | 11.2               | Polynomial RTD .....                   | 53        |
| 1.5      | Safety pictograms and symbols .....             | 5         | <b>Index</b> ..... | <b>54</b>                              |           |
| <b>2</b> | <b>Identification</b> .....                     | <b>6</b>  |                    |  |           |
| 2.1      | Unit identification .....                       | 6         |                    |  |           |
| 2.2      | Delivery contents .....                         | 6         |                    |  |           |
| 2.3      | Registered trademarks .....                     | 7         |                    |  |           |
| <b>3</b> | <b>Installation</b> .....                       | <b>7</b>  |                    |  |           |
| 3.1      | Quick installation guide .....                  | 7         |                    |  |           |
| 3.2      | Installation conditions .....                   | 8         |                    |  |           |
| 3.3      | Installation .....                              | 8         |                    |  |           |
| 3.4      | Installation check .....                        | 9         |                    |  |           |
| <b>4</b> | <b>Wiring</b> .....                             | <b>10</b> |                    |  |           |
| 4.1      | Quick wiring guide .....                        | 10        |                    |  |           |
| 4.2      | Connecting the sensor .....                     | 11        |                    |  |           |
| 4.3      | Connecting the measuring unit .....             | 11        |                    |  |           |
| 4.4      | Shielding and potential equalization .....      | 12        |                    |  |           |
| 4.5      | Degree of protection .....                      | 13        |                    |  |           |
| 4.6      | Connection check .....                          | 13        |                    |  |           |
| <b>5</b> | <b>Operation</b> .....                          | <b>14</b> |                    |  |           |
| 5.1      | Display and operating elements .....            | 14        |                    |  |           |
| 5.2      | Local operation .....                           | 15        |                    |  |           |
| 5.3      | Communication using the HART® protocol .....    | 16        |                    |  |           |
| <b>6</b> | <b>Commissioning</b> .....                      | <b>20</b> |                    |  |           |
| 6.1      | Installation check .....                        | 20        |                    |  |           |
| 6.2      | Switch on the device .....                      | 20        |                    |  |           |
| 6.3      | Quick Setup .....                               | 20        |                    |  |           |
| 6.4      | Device configuration .....                      | 21        |                    |  |           |
| <b>7</b> | <b>Maintenance</b> .....                        | <b>32</b> |                    |  |           |
| <b>8</b> | <b>Accessories</b> .....                        | <b>32</b> |                    |  |           |
| <b>9</b> | <b>Trouble-shooting</b> .....                   | <b>33</b> |                    |  |           |
| 9.1      | Trouble-shooting instructions .....             | 33        |                    |  |           |
| 9.2      | Error messages .....                            | 33        |                    |  |           |
| 9.3      | Application errors without messages .....       | 35        |                    |  |           |
| 9.4      | Spare parts .....                               | 38        |                    |  |           |
| 9.5      | Returns .....                                   | 40        |                    |  |           |
| 9.6      | Disposal .....                                  | 40        |                    |  |           |

# 1 Safety notes

Safe and secure operation of the field transmitter can only be guaranteed if the operating instructions and all safety notes are read, understood and followed.

## 1.1 Designated use

- The unit is a universal, presettable temperature field transmitter for resistance temperature detectors (RTD), thermocouple (TC) as well as resistance and voltage sensors. The unit is constructed for mounting in field applications.
- The manufacturer cannot be held responsible for damage caused by misuse of the unit.
- Separate Ex documentation is part of this operating manual, for measurement systems in hazardous areas. The installation conditions and connection values indicated in these instructions must be followed!

## 1.2 Installation, commissioning and operation

The unit is constructed using the most up-to-date production equipment and complies with the safety requirements of the local guidelines. The temperature transmitter is fully factory tested according to the specifications indicated on the order. However, if it is installed incorrectly or is misused, certain application dangers can occur. Installation, wiring and maintenance of the unit must only be done by trained, skilled personnel who are authorized to do so by the plant operator. This skilled staff must have read and understood these instructions and must follow them to the letter. The plant operator must make sure that the measurement system has been correctly wired to the connection schematics.

Electrical temperature sensors such as RTD's and thermocouples produce low-level signals proportional to their sensed temperature. The temperature transmitter converts the low-level sensor signal to a standard 4 to 20 mA DC signal that is relatively insensitive to lead length and electrical noise. This current signal is then transmitted to the control room via two wires.

The transmitter can be commissioned before or after installation. It may be useful to commission it on the bench, before installation, to ensure proper operation and to become familiar with its functionality. Make sure the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices before connecting a HART® communicator in an explosive atmosphere.

The transmitter electronics module is permanently sealed within the housing, resisting moisture and corrosive damage. Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.



**Warning!**

Electrical shock could cause death or serious injury. If the sensor is installed in a high voltage environment and a fault or installation error occurs, high voltage may be present on the transmitter leads and terminals.

### **Safety Instrumented Systems (SIS)**

Third party validated metrics are available for the temperature field transmitter. Testing is done per IEC 61508 for Safety Instrumented Systems. The safety manual can be separately ordered under order code: **SD005R09EN**.

For more details and download see:

**[www.us.endress.com](http://www.us.endress.com)**

### **Temperature Effects**

The transmitter will operate within specifications for ambient temperatures between -40 and +185 °F (-40 and +85 °C) without display. Heat from the process is transferred from the thermowell to the transmitter housing. If the expected process temperature is near or beyond

specification limits, consider the use of additional thermowell lagging, and extension nipple, or a remote mounting configuration to isolate the transmitter from the process.

### 1.3 Operational safety

#### Hazardous areas

When installing the unit in a hazardous area, the national safety requirements must be met. Make sure that all personnel are trained in these areas. Strict compliance with installation instructions and ratings as stated in this documentation is mandatory.

The measurement system fulfils the safety requirements according to EN 61010 and the EMC requirements according to EN 61326 as well as NAMUR NE 21, NE 43 and NE 89 recommendations.



Warning!

The TMT162 must be powered by a 11 to 40 V DC power supply with a limited power according to NEC Class 02 (low voltage, low current) limited to 8 A and 150 VA in case of a short circuit.

#### Technical advancement

The manufacturer reserves the right to modify technical data without prior notice. Your distributor can supply you with current information and updates to these Operating Instructions.

### 1.4 Returns

Please follow the Return Authorization Policy.

### 1.5 Safety pictograms and symbols

Safe and reliable operation of this unit can only be guaranteed if the safety notes and warnings in these operating instructions are followed. The safety notes in these instructions are highlighted using the following symbols.



Note!

This icon indicates activities and actions that, if not followed correctly, could have an indirect influence on the unit operation or could lead to an unforeseen unit reaction.



Caution!

This icon indicates activities and actions that, if not followed correctly, could lead to faulty device operation or even damage to the unit.



Warning!

This icon indicates activities and actions that, if not followed correctly, could lead to personal injury, a safety risk or even total damage to the unit.



Explosion protected, type examined operating equipment!

If one of these icons is on the device's nameplate, the device can be used in hazardous areas.



Hazardous area!

This symbol identifies the hazardous area in the diagrams in these Operating Instructions.

– Devices that are used in hazardous areas or cables for such devices must have the corresponding type of protection.



Safe area (non-hazardous areas)!


This symbol identifies the non-hazardous area in the diagrams in these Operating Instructions.

– Devices in non-hazardous areas must also be certified if connection cables run through a hazardous area.

## 2 Identification

### 2.1 Unit identification

#### 2.1.1 Legend plate



- 1 Order code and series number of the device
- 2 Protection and approvals
- 3 Power supply and output signal
- 4 Ambient temperature; for Ex area, see Ex-certification or Control Drawing
- 5 Approvals with symbols

Fig. 1: Example: Field transmitter legend plate

#### CE Mark, declaration of conformity

The device is designed to meet state-of-the-art safety requirements, has been tested and left the factory in a condition in which they are safe to operate. The device complies with the applicable standards and regulations in accordance with IEC 61010 "Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures" and with the EMC requirements of IEC 61326. The measuring system described in these Operating Instructions complies with the statutory requirements of the EC Directives. The manufacturer confirms successful testing of the device by affixing the CE mark.

#### UL recognized component to UL 3111-1

#### CSA GP approved

#### GL German Lloyd marine approval

GL Type Approval for temperature measurements in hazardous locations on GL Classed Vessels, Marine and Offshore Installations.

## 2.2 Delivery contents

The scope of delivery of the field transmitter is as follows:

- Temperature field transmitter
- Entry blank
- Multilanguage Brief Operating Instructions as hard copy
- Operating instructions on CD-ROM
- Control drawing for use in hazardous areas



Note!

Please take note of the field transmitter accessories in chapter 8 "Accessories".

## 2.3 Registered trademarks

- HART®  
Registered trademarks of HART® Communication Foundation, Austin, TX, USA
- Microsoft® Windows NT®, Windows® 2000 and Windows® XP  
Registered trademarks of Microsoft Corporation, Redmond, USA
- iTEMP® and ReadWin® 2000  
Registered trademarks of Endress+Hauser Wetzler GmbH + Co. KG, Nesselwang, Germany

## 3 Installation

### 3.1 Quick installation guide

If the sensor is fixed then the unit can be fitted directly to the sensor. For remote mounting to a wall or stand pipe, two mounting kits are available (→ Fig. 4). The illuminated display can be mounted in four different positions (→ Fig. 2):




Fig. 2: Temperature field transmitter with sensor, 4 display positions, can be plugged-in in 90° steps

- Pos. A: Sensor  
 Pos. 1: Cover clamp  
 Pos. 2: Housing cover with O-ring  
 Pos. 3: Display with retainer  
 Pos. 4: Electronics compartment

1. Remove the cover clamp (Pos. 1).
2. Unscrew the housing cover together with the O-ring (Pos. 2).

3. Remove the display with retainer (Pos. 3) from the electronics compartment (Pos. 4). Adjust the display with retainer in 90°-stages to the desired position and rearrange it on the particular slot in the electronics compartment.
4. Screw on the housing cover together with the O-ring. Mount the cover clamp.

## 3.2 Installation conditions

### 3.2.1 Dimensions

The dimensions of the device can be found in chapter 10 "Technical data".

### 3.2.2 Installation point

Information on installation conditions, such as ambient temperature, protection classification, climatic class, etc., can be found in chapter 10 "Technical data".

## 3.3 Installation

### 3.3.1 Direct installation to a sensor

If the sensor is fixed to the process installation, the transmitter can be fitted directly to the sensor.




Fig. 3: Installation of the field transmitter directly to a sensor

- Pos. 1 Thermowell
- Pos. 2 Measuring inset
- Pos. 3 Extension nipples and adapters
- Pos. 4 Sensor leads
- Pos. 5 Field wiring leads
- Pos. 6 Field wiring conduit

For installation proceed as follows:

1. Install and tighten thermowell (Pos. 1). Screw the measuring inset (Pos. 2) into the thermowell.
2. Attach necessary extension nipples and adapters (Pos. 3) to the thermowell. Seal the nipple and adapter threads with silicone tape.
3. Pull sensor leads (Pos. 4) through the extensions and adapters into the terminal side of the transmitter housing.
4. Install field wiring conduit (Pos. 6) to the remaining transmitter conduit entry.
5. Pull field wiring leads (Pos. 5) into the terminal side of the transmitter housing.
6. Attach and tighten both transmitter covers. Both transmitter covers must be fully engaged to meet explosion-proof requirements.

### 3.3.2 Remote installation




Fig. 4: Installation of the field transmitter using the mounting kit, see chapter 'Accessories' (dimensions in inches; mm)

Pos. A, B Mounting with combined wall/pipe mounting kit

Pos. C Mounting with pipe mounting kit 2\"/>

### 3.4 Installation check

After installing the device, always run the following final checks:

| Device condition and specification   | Hint                            |
|--|---------------------------------|
| Is the device visibly damaged (visual check)?  | -                               |
| Does the device comply with the measurement point specifications, such as ambient temperature, measurement range, etc.?              | See chapter 10 "Technical data" |
| Make sure that the transmitter covers are tight. Both transmitter covers must be fully engaged to meet explosion-proof requirements. | -                               |

## 4 Wiring



### Caution!

When installing Ex-approved devices in a hazardous area, please take special note of the instructions and connection schematics in the respective Ex documentation added to this operating manual. The local Endress+Hauser representative is available for assistance if required.

For wiring the device proceed as follows:

1. Open the conduit entry of the device.
2. Feed the leads through the opening in the cable gland or through the conduit entry.
3. Connect the leads as shown in Fig. 5.
4. Ensure the terminal screws are tight. Re-seal the cable gland or conduit by screwing the cover back on.
5. In order to avoid connection errors, always take note of the hints given in the section 'Connection check'!

### 4.1 Quick wiring guide

#### Terminal layout




Fig. 5: Wiring the field transmitter



### Caution!

Protect the terminals from electrostatic discharge. Failure to observe this may result in destruction of parts of the electronics.

## 4.2 Connecting the sensor



Note!

For sensor connection terminal layout please see Fig. 5. On two sensor inputs the following connection combinations are possible:

|                            | Sensor 1:<br>RTD 2-wire | Sensor 1:<br>RTD 3-wire | Sensor 1:<br>RTD 4-wire | Sensor 1:<br>TC connection |
|----------------------------|-------------------------|-------------------------|-------------------------|----------------------------|
| Sensor 2:<br>RTD 2-wire    | Yes                     | Yes                     | No                      | Yes                        |
| Sensor 2:<br>RTD 3-wire    | Yes                     | Yes                     | No                      | Yes                        |
| Sensor 2:<br>RTD 4-wire    | No                      | No                      | No                      | No                         |
| Sensor 2:<br>TC connection | Yes                     | Yes                     | Yes                     | Yes                        |

There are special cable entries available as accessories when connecting 2 sensors (not for XP instrumentation). These can be found in chapter 9.4.



Caution!

When connecting 2 sensors ensure that there is no galvanic connection between the sensors (e.g. grounded duplex thermocouples). The resulting equalizing currents distort the measurements considerably. In this situation, the sensors have to be galvanically isolated from one another by connecting each sensor separately to a field transmitter. The device provides sufficient galvanic isolation (> 2 kV AC) between the input and output.

## 4.3 Connecting the measuring unit



Caution!

- Switch off power supply before installing or connecting the device. Failure to observe this may result in destruction of parts of the electronics.
- If the device has not been grounded as a result of the housing being installed, grounding it via one of the ground screws is recommended.

### 4.3.1 HART® connection



Note!

If the HART® communication resistance is not built into the power supply, a 250 Ω communication resistor must be fitted into the 2-wire supply lines.

For connection hints, please take special notice of the documentation supplied by the HART® Communication Foundation, specifically HCF LIT 20: “HART, a technical overview”.

### Connection using the Endress+Hauser power supply RN221N




Fig. 6: HART® connection with the Endress+Hauser power supply RN221N

### Connection using other power supplies




Fig. 7: HART® connection using other power supplies

## 4.4 Shielding and potential equalization

Please take note when installing the device:

If screened (shielded) cables are used then the shielding connected to the output (output signal 4 to 20mA) must be at the same potential as the shielding at the sensor connection!

When operating in plants with high electromagnetic fields, it is recommended that all cables be shielded using a low ohm ground connection. Due to the possible danger of lightning strikes, shielding is also recommended for cables that are run outside buildings!

## 4.5 Degree of protection

The device conforms to the requirements to NEMA 4X (IP 67) ingress protection. In order to fulfil an NEMA 4X (IP 67) degree of protection after installation or service, the following points must be taken into consideration (also see Fig. 8):

- The housing seals must be clean and undamaged before they are replaced in the sealing rebate. If they are found to be too dry, they should be cleaned or even replaced.
- All housing screws and covers must be tightened.
- The cables used for connection must be of the correct specified outside diameter (e.g. M20 x 1.5, cable diameter from 0.315 to 0.47 in; 8 to 12 mm).
- Tighten cable gland or NPT fitting.
- Loop the cable or conduit before placing into the entry ("Water sack"). This means that any moisture that may form cannot enter the gland. Install the device so that the cable or conduit entries are not facing upwards.
- Entries not used are to be blanked off using the blanking plates provided.
- The protective cable gland must not be removed from the NPT fitting.




Fig. 8: Connection hints to retain NEMA 4X (IP 67) protection

## 4.6 Connection check

After the electrical installation of the device, always perform the following final checks:

| Device condition and specification   | Hint                                    |
|--|---|
| Are the device or the cables damaged (visual check)?   | -                                       |
| Electrical connection  | Hint                                    |
| Is the cable/conduit installation correctly separated, with no loops or crossovers?                                | -                                       |
| Are the cables' load relieved?   | -                                       |
| Have the cables been correctly connected? Compare with the connection schematic on the terminals or see Fig. 5.    | See connection schematic on the housing |
| Are all terminal screws tightened?<br>Is the cable or conduit entry sealed?<br>Is the housing cover screwed tight? | Visual check                            |

## 5 Operation

### 5.1 Display and operating elements

#### 5.1.1 Display indication




Fig. 9: LC display in the field transmitter (illuminated, can be plugged-in in 90° steps)

#### 5.1.2 Display icons

| Pos. no. | Function  | Description   |
|----------|---|---|
| 1        | Bargraph display  | In 10% steps with overrange and underrange marks. The bargraph display flashes when an error occurs.  |
| 2        | Display 'Warning'                                       | This display mode appears when an error occurs or a warning is given  |
| 3        | Engineering unit display K, °F, °C or %                 | Engineering unit for the measured value being displayed   |
| 4        | Measured value display (0.81" / 20.5 mm character size) | Measured value display. If a warning is present this display alternates between the measured value and the warning code. In the event of an error, the error code is displayed instead of the measured value.   |
| 5        | Status and information display                          | Display of which value is being indicated on the display. On PV a customer specific text can be entered. On warning, the display shows the warning code as well as "WARN". On faults the display shows "ALARM". |
| 6        | Display "Communication"                                 | The communication icon appears on read or write access using the HART® protocol   |
| 7        | Display "Configuration locked"                          | If the software or hardware setup/configuration is locked, the "Configuration locked" icon appears.   |

## 5.2 Local operation

### 5.2.1 Setup of the hardware




Fig. 10: Hardware setup using jumpers J1, J2 and J3



Caution!



Protect the terminals from electrostatic discharge. Failure to observe this may result in destruction of parts of the electronics.

Jumpers J1, J2 and J3 for the hardware setup can be found in the electronic chamber. In order to set the jumper, open the electronics chamber screwed cover (opposite the connection chamber cover) and if necessary pull off the display.

#### Setup or configuration hardware lock using jumper J1

| TRANSMITTER SECURITY |                              |
|----------------------|------------------------------|
| ON                   | Setup/configuration locked   |
| OFF                  | Setup/configuration unlocked |

The hardware setup/configuration lock has priority over the software setup.

### Setup hardware fault conditioning using jumper J2

| FAILURE MODE |                        |
|--------------|------------------------|
| LO           | $\leq 3.6 \text{ mA}$  |
| HI           | $\geq 21.0 \text{ mA}$ |

The failure mode conditioning setup using the jumper is only active when the microcontroller fails.



Note!

Please check that the hardware and software failure mode conditioning correspond with each other.

### Hardware setup using jumper J3 (only for units without display)

Using jumper 3 the minimum operating voltage can be reduced from 11 V to 8 V.

## 5.3 Communication using the HART<sup>®</sup> protocol

The setup and measured value read out of the measuring device is done using the HART<sup>®</sup> protocol. The digital communication is done using the 4 to 20 mA current output HART<sup>®</sup> (see Figs. 5 and 6). There are a number of possible setup methods available to the user:

- Operation using the universal handheld module "HART<sup>®</sup> Communicator DXR275/375".
- Operation using a PC combined with Endress+Hauser operating software, e.g. 'FieldCare' or 'ReadWin<sup>®</sup> 2000' as well as a HART<sup>®</sup> modem, e.g. 'Commubox FXA191'.
- Operating programs of other manufacturers ('AMS', Fisher Rosemount; 'SIMATIC PDM', Siemens).



Note!

If communication errors occur in the Microsoft<sup>®</sup> Windows NT<sup>®</sup> Version 4.0 and Windows<sup>®</sup> 2000 operating systems the following measure is to be taken:

Switch off setting "FIFO active".

In order to do this follow these steps.

1. On Windows NT<sup>®</sup> Version 4.0:  
Select the menu point "COM-Port" following using the menu "START" → "SETTINGS" → "SYSTEM CONTROL" → "CONNECTIONS". Using the menu string "SETTINGS" → "EXPANDED" switch the command "FIFO active" off. Now restart the PC.
2. For Windows<sup>®</sup> 2000 and Windows<sup>®</sup> XP (classic category view):  
Select "Expanded settings for COM1" using the menu "START" → "SETTINGS" → "SYSTEM CONTROL" → "SYSTEM" → "HARDWARE" → "UNIT MANAGER" → "CONNECTIONS (COM and LPT)" → "COMMUNICATION CONNECTION(COM1)" → "CONNECTION SETTINGS" → "EXPANDED". Deactivate the "Use FIFO buffer". Now restart the PC.






Fig. 12: HART® function matrix

### 5.3.2 FieldCare

FieldCare is a universally applicable service and configuration software based on FDT/DTM technology. Connection is established by means of a HART® modem, e.g. Commubox FXA191. Detailed information is provided in the installation instructions of the FieldCare configuration software (see chapter 'Documentation'). The DTMs available for the device also allow operation by means of operating programs of other manufacturers that support FDT/DTM technology.

### 5.3.3 ReadWin® 2000

ReadWin® 2000 is a universally applicable service and configuration software. Connection is made using a HART® modem, e.g. Commubox FXA191. The operating software offers the user the following possibilities:

- Setup device functions
- Measured value visualization
- Device parameter data storage
- Measuring point documentation



Caution!

The analog output is undefined when downloading the device function parameters from ReadWin® 2000 to the device.

Further in-depth information on operation via ReadWin® 2000 can be found in the online documentation of the software. ReadWin® 2000 can be downloaded free of charge from the following address:

- [www.endress.com/Readwin](http://www.endress.com/Readwin)

### 5.3.4 Command classification in the HART® protocol

The HART® protocol makes it possible for configuration and diagnostic purposes to transmit measured and device data between the HART® master and the respective field device. HART® masters such as the handheld module or PC-based operating programs (e.g. FieldCare) require so-called device description files (DD = device descriptions, DTM), these make it possible to access all information in a HART® device. Transmission of such information is done exclusively using "commands".

**There are three command classifications:**

- Universal commands
  - Universal commands are supported and used by all HART® devices. Combined are for example the following functionality:
    - Recognizing HART® devices
    - Readout of digital measured values
- Common practice commands:
  - These general commands offer functions that are supported or used by some but not all field devices.
- Device specific commands
  - These commands enable access to device specific functions that are not HART® standardized. Such commands access, among other things, individual field device information.



Note!

Chapter 6.4.2 contains a list of all HART® commands supported.

## 6 Commissioning

### 6.1 Installation check

Before commissioning the measurement point make sure that all final checks have been carried out:



- Checklist "Installation check"
- "Connection check"

### 6.2 Switch on the device

Once the power has been connected, the field transmitter is operational.

### 6.3 Quick Setup

Using the Quick Setup the operator is led through all the most important unit functions, which must be set up for standard measurement operation of the unit.

| <b>Standard setup</b>  |               |  |              |
|--|---------------|--|--------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) , Commuwin II with Matrix address | ReadWin® 2000 |  /FieldCare | CW II-Matrix |
| Function mode  | +             | +  | V1H1         |
| PV mode  | +             | +  | V1H2         |
| PV unit  | +             | +  | V1H3         |
| <b>Sensor 1</b>  |               |  |              |
| Sensor type  | +             | +  | V3H0         |
| Sensor connection  | +             | +  | V3H1         |
| Measuring unit   | +             | +  | V3H6         |
| <b>Sensor 2</b>  |               |  |              |
| Sensor type  | +             | +  | V4H0         |
| Sensor connection  | +             | +  | V4H1         |
| Measuring unit   | +             | +  | V4H6         |
| <b>Output</b>  |               |  |              |
| PV lower range value   | +             | +  | V1H4         |
| PV upper range value   | +             | +  | V1H5         |
| <b>Safety settings</b>   |               |  |              |
| Fault condition  | +             | +  | V1H8         |
| Ambient alert  | +             | +  | V2H2         |

## 6.4 Device configuration







### 6.4.1 Description of device functions

All parameters that can be read out and setup for the configuration of the temperature transmitter are listed and described in the following tables. The menu structures in the ReadWin® 2000 PC configuration software and in the HART® handheld module DXR275/375 are shown in the following tables.



Note!





Factory default setup is shown in bold text.







| Function group STANDARD SETTINGS  |  |  |  |                                 |
|---|--|--|--|---------------------------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |  | ReadWin® 2000  |  /FieldCare | CW II-<br>Matrix                |
| <b>Function mode</b>  | Selection of device function <ul style="list-style-type: none"> <li>■ One sensor input</li> <li>■ Two sensor inputs</li> </ul>  Note!<br>Selection only active on two sensor input device.  | +  | +  | V1H1                            |
| <b>PV mode</b>  | For selecting the calculation function of the PV (PV = primary value). The PV is shown linear at the analog output. <ul style="list-style-type: none"> <li>■ <b>PV = Sens1</b><br/>Sensor 1 is the primary value (PV)</li> <li>■ PV = Sens2<br/>Sensor 2 is the primary value (PV)</li> <li>■ PV = Sens1-Sens2<br/>Difference</li> <li>■ PV = (Sens1 + Sens2)/2<br/>Average of sensor 1 and 2</li> <li>■ PV = Sens1 (or Sens2) backup<br/>Sensor 2 becomes PV if sensor 1 fails. An error signal is not output. If the active backup = switch to redundant sensor, the display shows the "Caution" icon, the corresponding error number (see chapter 9) and the text 'back'.</li> <li>■ PV = Sens2 (or Sens1) backup<br/>Sensor 1 becomes PV if sensor 2 fails.</li> <li>■ PV = Sens1 (Sens2, if Sens1 &gt; T)<br/>If temperature T is overshoot at sensor 1, the measuring temperature of sensor 2 becomes the PV. The system switches back to sensor 1 if the measuring temperature at sensor 1 is at least 3.6 °F (2 °C) below T. S1 or S2 appears on the display to indicate which sensor is currently active. The temperature-dependent switchover means that 2 sensors can be combined, which each have certain advantages in different temperature ranges.</li> </ul>  Note!<br>Selection only active on "Function - Two sensor inputs". | +<br><br>≥ SW 01.03.00<br><br>≥ SW 01.03.00<br><br>≥ SW 01.03.00 | +<br><br>≥ SW 01.03.00<br><br>≥ SW 01.03.00<br><br>≥ SW 01.03.00                               | V1H2<br><br>-<br><br>-<br><br>- |
| <b>Temperature T</b>  | Switch to sensor 2<br>Entry only relevant if PV mode is 'PV = Sens1 (Sens2, if Sens1 > T)'<br><br> Note!<br>Selection only active on "Function - Two sensor inputs".  | ≥ SW 01.03.00  | ≥ SW 01.03.00  | -                               |
| <b>PV unit</b>  | Input for PV unit<br>Input: °C, F, K, R, mV or Ω<br><br> Note!<br>The setting PV unit has priority, the selection list of the sensor type is shown independently from the PV unit.  | +  | +  | V1H3                            |








Note!




The sensor inputs ( $\geq$  SW 01.03.00) are no longer available in the Commuwin II PC configuration software.




| Function group SENSOR 1   |                               |                          |                          |                   |                    |  |              |
|---|-------------------------------|--------------------------|--------------------------|-------------------|--------------------|--|--------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address   |                               |                          |                          |                   | ReadWin® 2000      |  /FieldCare | CW II-Matrix |
| <b>Sensor type</b>  | <b>Sensor type</b>            | <b>Lower range value</b> | <b>Upper range value</b> | <b>min. range</b> | +                  | +  | V3H0         |
| IEC 751   | <b>Pt100</b>                  | -328°F (-200 °C)         | 1562 °F (850 °C)         | 18 °F (10 °C)     | $\geq$ SW 01.03.00 | $\geq$ SW 01.03.00   | -            |
|   | Pt200                         | -328°F (-200 °C)         | 1562 °F (850 °C)         | 18 °F (10 °C)     |                    |  |              |
| JIS   | Pt100                         | -328°F (-200 °C)         | 1200 °F (649 °C)         | 18 °F (10 °C)     |                    |  |              |
| IEC 751   | Pt500                         | -328°F (-200 °C)         | 482 °F (250 °C)          | 18 °F (10 °C)     |                    |  |              |
|   | Pt1000                        | -328°F (-200 °C)         | 482 °F (250 °C)          | 18 °F (10 °C)     |                    |  |              |
|   | Ni100                         | -76 °F (-60 °C)          | 482 °F (250 °C)          | 18 °F (10 °C)     |                    |  |              |
|   | Ni1000                        | -76 °F (-60 °C)          | 302 °F (150 °C)          | 18 °F (10 °C)     |                    |  |              |
| Edison Copper Winding No. 15  | Cu10                          | -148 °F (-100 °C)        | 500 °F (260 °C)          | 18 °F (10 °C)     | $\geq$ SW 01.03.00 | $\geq$ SW 01.03.00   | -            |
| SAMA  | Pt100                         | -148 °F (-100 °C)        | 1292 °F (700 °C)         | 18 °F (10 °C)     | $\geq$ SW 01.03.00 | $\geq$ SW 01.03.00   | -            |
| Edison Curve No. 7  | Ni120                         | -94 °F (-70 °C)          | 518 °F (270 °C)          | 18 °F (10 °C)     | $\geq$ SW 01.03.00 | $\geq$ SW 01.03.00   | -            |
| GOST  | Pt50                          | -328°F (-200 °C)         | 2012 °F (1100 °C)        | 18 °F (10 °C)     | $\geq$ SW 01.03.00 | $\geq$ SW 01.03.00   | -            |
|   | Pt100                         | -328°F (-200 °C)         | 1562 °F (850 °C)         | 18 °F (10 °C)     |                    |  |              |
|   | Cu50                          | -328°F (-200 °C)         | 392 °F (200 °C)          | 18 °F (10 °C)     |                    |  |              |
|   | Cu100                         | -328°F (-200 °C)         | 392 °F (200 °C)          | 18 °F (10 °C)     |                    |  |              |
|   | Polynomial RTD                | -328°F (-200 °C)         | 1562 °F (850 °C)         | 18 °F (10 °C)     | $\geq$ SW 01.03.00 | $\geq$ SW 01.03.00   | -            |
|   | Callendar - van Dusen (Pt100) | -328°F (-200 °C)         | 1562 °F (850 °C)         | 18 °F (10 °C)     |                    |  |              |
|   | TC Type B                     | 32 °F (0 °C)             | 3308 °F (1820 °C)        | 900 °F (500 °C)   |                    |  |              |
|   | TC Type C                     | 32 °F (0 °C)             | 4208 °F (2320 °C)        | 900 °F (500 °C)   |                    |  |              |
|   | TC Type D                     | 32 °F (0 °C)             | 4523 °F (2495 °C)        | 900 °F (500 °C)   |                    |  |              |
|   | TC Type E                     | -454 °F (-270 °C)        | 1832 °F (1000 °C)        | 90 °F (50 °C)     |                    |  |              |
|   | TC Type J                     | -346 °F (-210 °C)        | 2192 °F (1200 °C)        | 90 °F (50 °C)     |                    |  |              |
|   | TC Type K                     | -454 °F (-270 °C)        | 2501 °F (1372 °C)        | 90 °F (50 °C)     |                    |  |              |
|   | TC Type L                     | -328°F (-200 °C)         | 1652 °F (900 °C)         | 90 °F (50 °C)     |                    |  |              |
|   | TC Type N                     | -454 °F (-270 °C)        | 2372 °F (1300 °C)        | 90 °F (50 °C)     |                    |  |              |
|   | TC Type R                     | -58 °F (-50 °C)          | 3214 °F (1768 °C)        | 900 °F (500 °C)   |                    |  |              |
|   | TC Type S                     | -58 °F (-50 °C)          | 3214 °F (1768 °C)        | 900 °F (500 °C)   |                    |  |              |
|   | TC Type T                     | -454 °F (-270 °C)        | 752 °F (400 °C)          | 90 °F (50 °C)     |                    |  |              |
|   | TC Type U                     | -328°F (-200 °C)         | 1112 °F (600 °C)         | 90 °F (50 °C)     |                    |  |              |
|   | 10 to 400 $\Omega$            | 10 $\Omega$              | 400 $\Omega$             | 10 $\Omega$       |                    |  |              |
|   | 10 to 2000 $\Omega$           | 10 $\Omega$              | 2000 $\Omega$            | 100 $\Omega$      |                    |  |              |
|   | -20 to 100 mV                 | -20 mV                   | 100 mV                   | 5 mV              |                    |  |              |
| <p><b>Specific linearization and sensor matching</b></p> <p>Selecting the sensor types 'Callendar-van-Dusen' or 'Polynomial RTD' improves the accuracy of the system or defines user-specific linearization of resistance thermometers. A detailed description of the 'Callendar-van-Dusen' method and 'Polynomial RTD' linearization is provided in the Appendix to these Operating Instructions.</p>  |                               |                          |                          |                   |                    |  |              |
| <p> Note!<br/>The selection list of the sensor type is displayed depending on the PV unit. Example:<br/>When selecting a resistance thermometer the PV unit must first be set to <math>\Omega</math>.</p> <p> Note!<br/>Sensor 1 has priority, sensor 2 setup is matched to the setup of sensor 1.<br/><b>Example:</b> Sensor 1 is set up for a 4-wire connection, sensor 2 is set up for a 3-wire connection; there is an automatic change of sensor 2 to a type K thermocouple.</p> |                               |                          |                          |                   |                    |  |              |

| Function group SENSOR 1   |   |               |  |              |
|---|---|---------------|--|--------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |   | ReadWin® 2000 |  /FieldCare | CW II-Matrix |
| <b>Sensor connection</b>  | Input of RTD connection mode.<br>Input:<br><ul style="list-style-type: none"> <li>■ 2-wire</li> <li>■ <b>3-wire</b></li> <li>■ 4-wire</li> </ul>  Note!<br>Function is only active on selection of a resistance thermometers (RTD) in the device function SENSOR TYPE (V3H0).                        | +             | +  | V3H1         |
| <b>Cold junction</b>  | Selection of the internal (Pt100) or an external comparison measurement point.<br>Input:<br><ul style="list-style-type: none"> <li>■ <b>internal</b></li> <li>■ external</li> </ul>  Note!<br>Function is only active on selection of a thermocouple (TC) in the device function SENSOR TYPE (V3H0). | +             | +  | V3H2         |
| <b>External temperature</b>   | Input of the external comparison point measurement value.<br>Input: -40.0 to 185.0 °F / -40.00 to 85.00 °C (°C, F, K)<br>32 °F ( <b>0 °C</b> )<br> Note!<br>Function is only active when "external" has been selected in the device function COLD JUNCTION (V3H2).                                   | +             | +  | V3H3         |
| <b>2-wire compensation</b>  | Input of cable resistance compensation on a 2-wire RTD connection.<br>Input: <b>0.00</b> to 30.00 Ω<br> Note!<br>Function is only active when a 2-wire connection has been selected in the device function SENSOR CONNECTION (V3H1).   | +             | +  | V3H4         |
| <b>Offset</b>   | Input of the zero point correction (offset).<br>Input: -18.00 to 18.00 °F (-10.00 to 10.00 °C)<br>32.0 °F ( <b>0.00 °C</b> )  | +             | +  | V3H5         |
| <b>Measurement unit</b>   | Display of measurement unit.<br>Sensor 1 unit = PV unit   | +             | +  | V3H6         |
| <b>Serial no. sensor</b>  | Input of the serial number of the sensor connected to this sensor input.  | +             | +  | V3H7         |




| Function group SENSOR 2 (only on a device with 2 sensor inputs)   |  |               |  |              |
|---|--|---------------|--|--------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |  | ReadWin® 2000 |  /FieldCare | CW II-Matrix |
| <b>Sensor type</b>  | See Function group SENSOR 1<br> Note!<br>Sensor 1 has priority, sensor 2 setup is matched to the setup of sensor 1.<br><b>Example:</b> Sensor 1 is set up for a 4-wire connection, sensor 2 is set up for a 3-wire connection; there is an automatic change of sensor 2 to a type K thermocouple. | +             | +  | V4H0         |




| Function group SENSOR 2 (only on a device with 2 sensor inputs)   |                             |               |  |              |
|---|-----------------------------|---------------|--|--------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |                             | ReadWin® 2000 |  /FieldCare | CW II-Matrix |
| <b>Sensor connection</b>  | See Function group SENSOR 1 | +             | +  | V4H1         |
| <b>Cold junction</b>  | See Function group SENSOR 1 | +             | +  | V4H2         |
| <b>External temperature</b>   | See Function group SENSOR 1 | +             | +  | V4H3         |
| <b>2-wire compensation</b>  | See Function group SENSOR 1 | +             | +  | V4H4         |
| <b>Offset</b>   | See Function group SENSOR 1 | +             | +  | V4H5         |
| <b>Measurement unit</b>   | See Function group SENSOR 1 | +             | +  | V4H6         |
| <b>Serial no. sensor</b>  | See Function group SENSOR 1 | +             | +  | V4H7         |



| Function group OUTPUT  |   |   |   |              |             |
|--|---|---|---|--------------|-------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |   | ReadWin® 2000   |  /FieldCare | CW II-Matrix |             |
| <b>PV lower range value</b>  | Input of 4 mA value.<br>Input: Limitation values see device function SENSOR TYPE 1/2.<br>32 °F (0 °C)   | +   | +   | V1H4         |             |
| <b>PV upper range value</b>  | Input of 20 mA value.<br>Input: Limitation values see device function SENSOR TYPE 1/2.<br>212 °F (100 °C)   | +   | +   | V1H5         |             |
| <b>Analog output</b>   | Input of the standard (4 to 20 mA) or inverse (20 to 4 mA) current output signal.<br>Input:<br><ul style="list-style-type: none"> <li>■ 4 to 20 mA</li> <li>■ 20 to 4 mA</li> </ul> | +   | +   | V1H6         |             |
| <b>Filter</b>  | Selection of the digital filter 1. order (filter time constant).<br>Input: 0 to 60 s  | +   | +   | V1H7         |             |
| <b>HART Output/<br/>Multidrop</b>  | Preamble  | Input: Number of response preambles: 0 to 15<br><b>5</b>  | -   | +            | HART Server |
|  | Device address  | Input: HART address of the temperature transmitters:<br><b>0</b> to 15<br><br> <b>Note!</b><br>If addresses > 0, the temperature transmitter is in Multidrop mode and the analog output is set to 4 mA. Device address is shown on the display in the Multidrop mode |   |              |             |



| Function group SAFETY SETTINGS  |   |               |  |                  |
|---|---|---------------|--|------------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |   | ReadWin® 2000 |  /FieldCare | CW II-<br>Matrix |
| <b>Drift alert mode</b>   | Definition of the behavior if measured values for sensors 1 and 2 deviate from one another.<br>Input:<br><ul style="list-style-type: none"> <li>■ off</li> <li>■ Warning</li> <li>■ Alarm</li> </ul> Warning:<br>The 'Caution' icon becomes active on the display. A warning is transmitted via the HART® protocol.<br>Alarm:<br>The 'Caution' icon becomes active on the display. The device switches to error signal.   | +             | +  | V2H0             |
| <b>Drift mode</b>   | Drift. No input necessary if the drift alert mode = off.<br>Input:<br><ul style="list-style-type: none"> <li>■ Larger<br/>Alarm/warning if absolute amount for difference between sensor 1 - sensor 2 overshoots a defined limit value (see drift alert value). Larger is the standard value for device versions &lt; SW 01.03.00 in which the parameter is not available.</li> <li>■ Smaller<br/>Alarm/warning if absolute amount for difference between sensor 1 - sensor 2 undershoots a defined limit value (see drift alert value).</li> </ul> | ≥ SW 01.03.00 | ≥ SW 01.03.00  | -                |
| <b>Drift alert value</b>  | No input necessary if the drift alert mode = off.<br>Input of the limit value for the drift alert or warning. Depending on the 'Drift mode' function, the drift alert or warning is active in the event of overshoot or undershoot.<br>Input: 0 to 999<br>1830.2 °F ( <b>999 °C</b> )   | +             | +  | V2H1             |
| <b>Fault condition</b>  | Input of the output signal on sensor rupture or short circuit.<br>Input:<br><ul style="list-style-type: none"> <li>■ max (≥ 21.0 mA)</li> <li>■ min (≤ 3.6 mA)</li> </ul>   | +             | +  | V1H8             |
| <b>Error current specification</b>  | Input only possible if fault condition = max<br>Input: 21.6 to 23 mA<br><b>21.7 mA</b>  | ≥ SW 01.03.00 | ≥ SW 01.03.00  | -                |
| <b>Alarm hysteresis</b>   | Transient alarms are suppressed at the analog output (e.g. caused by electrostatic discharge).<br>Input:<br><ul style="list-style-type: none"> <li>■ 0 s</li> <li>■ 2 s</li> <li>■ 5 s</li> </ul>  Note!<br>In the time entered, the last measured value before the alarm is output. If the error is still present after this period, an alarm is signalled.   | ≥ SW 01.03.00 | ≥ SW 01.03.00  | -                |







| Function group DISPLAY  |   |  |  |                         |
|---|---|--|--|-------------------------|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |   | ReadWin® 2000                                |  /FieldCare | CW II-<br>Matrix        |
|   | <p> Note!<br/>In order to activate the values to be shown in the device display using Commuwin II and HART® handheld module DXR275/375: Add (DXR,CW=x) of the values to be displayed and enter the sum.</p> <ul style="list-style-type: none"> <li>■ Display: time (2s, 4s, 6s, 8s)</li> <li>■ Display: figures after decimal point (0,1,2)</li> <li>■ Display PV text (customer specific text, 8 characters)</li> </ul> | <p>≥ SW 01.03.00<br/>≥ SW 01.03.00<br/>+</p> | <p>≥ SW 01.03.00<br/>≥ SW 01.03.00<br/>+</p>   | <p>-<br/>-<br/>V6H1</p> |



| Function group DIAGNOSTICS  |  |  |  |  |
|---|--|--|--|--|
| Available in ReadWin® 2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |  | ReadWin® 2000                                |  /FieldCare | CW II-<br>Matrix   |
| <b>Diagnostics</b>  | <p>Display of information required for device diagnostics.</p> <ul style="list-style-type: none"> <li>■ Device status or error code<br/>(See chapter 9.2 "Error messages")</li> <li>■ Last error code (status) or previous error code<br/>(See chapter 9.2 "Error messages")</li> <li>■ Status sensor 1 (0 = no error; 0 ≠ error)</li> <li>■ Status sensor 2 (0 = no error; 0 ≠ error)</li> <li>■ Configuration changed</li> </ul>   | <p>+<br/>+<br/>-<br/>-<br/>+</p>             | <p>+<br/>+<br/>+<br/>+<br/>+</p>   | <ul style="list-style-type: none"> <li>■ V9H0</li> <li>■ V9H1</li> <li>■ V0H4</li> <li>■ V0H6</li> <li>■ V9H2</li> </ul>                                 |
| <b>Diagnostics</b>  | <ul style="list-style-type: none"> <li>■ Static revision<br/>The "Static revision" is increased on every parameter change. This is for compliance to 21 CFR Part 11, showing that no further parameter changes have been made.</li> <li>■ Sensor 1 max. value</li> <li>■ Sensor 1 min. value</li> <li>■ Sensor 2 max. value</li> <li>■ Sensor 2 min. value</li> <li>■ RJ max. value</li> <li>■ RJ min. value</li> </ul> <p>Display of the maximum process value. The process value will be accepted after starting the measurement.<br/>Display of the minimum process value. The process value will be accepted after starting the measurement.<br/>Display of the maximum and minimum measured temperatures of the internal Pt100 DIN B comparison measurement point.</p> <p> Note!<br/>Maximum process value is changed to the actual process value on write access. On reset to factory default value the default value is entered <b>-10000</b>.<br/>Minimum process value is changed to the actual process value on write access. On reset to factory default value the default value is entered <b>+10000</b>.</p> | <p>-<br/>+<br/>+<br/>+<br/>+<br/>+<br/>+</p> | <p>-<br/>+<br/>+<br/>+<br/>+<br/>+</p>   | <ul style="list-style-type: none"> <li>■ V9H3</li> <li>■ V8H0</li> <li>■ V8H1</li> <li>■ V8H2</li> <li>■ V8H3</li> <li>■ V8H4</li> <li>■ V8H5</li> </ul> |

| Function group IDENTIFICATION  |  |                  |  |                  |
|--|--|------------------|--|------------------|
| Available in ReadWin®2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |  | ReadWin®<br>2000 |  /FieldCare | CW II-<br>Matrix |
| <b>Measuring point</b><br>Input and display of the information relating to the measuring point identification  |  |                  |  |                  |

| Function group IDENTIFICATION  |  |                  |  |                  |
|--|--|------------------|--|------------------|
| Available in ReadWin®2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |  | ReadWin®<br>2000 |  /FieldCare | CW II-<br>Matrix |
| <b>Measuring point TAG</b>   | Input: 8 characters  | +                | +  | VAH0             |
| <b>Description</b>   | Input: 16 characters   | +                | +  | VAH1             |
| <b>Message</b>   | Input: 32 characters   | -                | +  |                  |
| <b>Device information</b><br>Display of the information relating to the device identification  |  |                  |  |                  |
| <b>Commuwin device version</b>   | Special Commuwin device version, e.g.: 8010 means Version 1.0                                    | -                | -  | VAH3             |
| <b>Device release</b>  | Display of device release  | -                | +  | VAH2             |
| <b>Serial number</b>   | 11 digit display of the Endress+Hauser device serial number (equal to that on the legend plate). | +                | +  | VAH4             |
| <b>Software version</b>  | Display of the software version  | +                | +  | VAH6             |
| <b>Hardware version</b>  | Display of the hardware version  | +                | +  | VAH7             |
| <b>Certificates</b>  | Display of device approvals  | -                | +  |                  |
| <b>Device</b><br>Display of the information relating to the HART® device identification  |  |                  |  |                  |
| <b>Manufacturer</b>  | Manufacturer's identification character: Endress+Hauser (=17)                                    | -                | +  | -                |
| <b>Device type</b>   | Device type identification: TMT162   | -                | +  | -                |
| <b>Date</b>  | Individual use of this parameter   | -                | +  | -                |
| <b>Hardware revision</b>   | Revisions of the device's electronic components  | -                | +  | -                |

| Function group SERVICE FUNCTIONS  |   |               |  |                  |
|---|---|---------------|--|------------------|
| Available in ReadWin®2000, HART® handheld module DXR 275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |   | ReadWin® 2000 |  /FieldCare | CW II-<br>Matrix |
| <b>Security locking</b>   | Set-up release code.<br>Input:<br><ul style="list-style-type: none"> <li>■ Lock = 0</li> <li>■ Release (unlock) = <b>261</b></li> </ul> | +             | +  | V9H6             |
| <b>Reset to default</b>   | Reset to factory default values.<br>Input: 162<br><b>0</b>  | +             | +  | V9H5             |

| Function group SERVICE FUNCTIONS  |  |               |  |                  |
|---|--|---------------|--|------------------|
| Available in ReadWin®2000, HART® handheld module DXR 275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |  | ReadWin® 2000 |  /FieldCare | CW II-<br>Matrix |
| <b>Output simulation</b>  | Activate simulation mode.<br>Input:<br><ul style="list-style-type: none"> <li>■ OFF</li> <li>■ ON</li> </ul>                                   | +             | +  | V9H7             |
| <b>Simulation value</b>   | Input of the simulation value (current).<br>Input: 3.58 to 23 mA as of SW version 01.03.00.<br>To SW version 01.03.00 21.7 mA.                 | +             | +  | V9H8             |
| <b>User calibration (trim) analog output</b>  | For changing the 4 or 20 mA value by ± 0.150 mA<br><ul style="list-style-type: none"> <li>■ Trimming 4 mA</li> <li>■ Trimming 20 mA</li> </ul> | ≥ SW 01.03.00 | ≥ SW 01.03.00  | -                |

| Function group MEASURED VALUES   |   |               |  |                  |
|--|---|---------------|--|------------------|
| Available in ReadWin®2000, HART® handheld module DXR275/375 (Symbol  ) ,<br>Commuwin II with Matrix address |   | ReadWin® 2000 |  /FieldCare | CW II-<br>Matrix |
| <b>PV</b>  | PV value                                      | +             | +  | VOH0             |
| <b>AO</b>  | PV value in mA                                | -             | +  | VOH1             |
| <b>PV %</b>  | PV value in %                                 | -             | +  | VOH2             |
| <b>Sensor 1</b>  | Sensor 1 process value                        | -             | +  | VOH3             |
| <b>Sensor 2</b>  | Sensor 2 process value                        | -             | +  | VOH5             |
| <b>Internal temperature (RJ value)</b>   | Internal temperature of the device (RJ value) | -             | +  | VOH7             |

## 6.4.2 Supported HART® commands

r = read access, w = write access

| No.                       | Description                                | Access |
|---------------------------|--|--------|
| <b>Universal Commands</b> |  |        |
| 00                        | Read unique identifier                     | r      |
| 01                        | Read primary variable                      | r      |
| 02                        | Read p.v. current and percent of range     | r      |
| 03                        | Read dynamic variables and p.v. current    | r      |
| 06                        | Write polling address                      | w      |
| 11                        | Read unique identifier associated with tag | r      |
| 12                        | Read message                               | r      |

| No.                          | Description                                    | Access |
|------------------------------|--|--------|
| 13                           | Read tag, descriptor, date                     | r      |
| 14                           | Read primary variable sensor information       | r      |
| 15                           | Read primary variable output information       | r      |
| 16                           | Read final assembly number                     | r      |
| 17                           | Write message                                  | w      |
| 18                           | Write tag, descriptor, date                    | w      |
| 19                           | Write final assembly number                    | w      |
| <b>Common practice</b>       |  |        |
| 34                           | Write primary variable damping value           | w      |
| 35                           | Write primary variable range values            | w      |
| 38                           | Reset configuration changed flag               | w      |
| 40                           | Enter/exit fixed primary variable current mode | w      |
| 42                           | Perform master reset                           | w      |
| 44                           | Write primary variable units                   | w      |
| 48                           | Read additional device status                  | r      |
| 59                           | Write number of response preambles             | w      |
| <b>Device / E+H specific</b> |  |        |
| 144                          | Read matrix parameter                          | r      |
| 145                          | Write matrix parameter                         | w      |
| 231                          | Check Device Status                            | r      |

■ HART® command No. 48 (HART-Cmd #48)

Apart from the response code and the device status byte, the field transmitter calls up a detailed diagnosis by means of Cmd #48. This diagnosis is 8 bytes long.

| Byte | Contents               | Meaning  |
|------|------------------------|--|
| 1    | Overall device status  | 0 x 01 error: EEPROM<br>0 x 02 error: ADC<br>0 x 04 error: channel 1<br>0 x 08 error: channel 2<br>0 x 10 error: comparison measurement point<br>0 x 20 error: HART ASIC<br>0 x 40 warning: measured value range undershoot<br>0 x 80 warning: measured value range overshoot  |
| 2    |                        | 0 x 01 warning: backup switched on<br>0 x 02 information: maintenance necessary<br>0 x 04 information: drift too small/large<br>0 x 08 information: corrosion at terminals<br>0 x 10 information: ambient temperature too high/low<br>0 x 20 information: output current at fixed value<br>0 x 40 information: no LCD connected or LCD error<br>0 x 80 information: upload/download active |
| 3    |                        | 0 x 01 information: device starting<br>0 x 02 error: supply voltage too low  |
| 4    |                        | 0 x 40 global bit for a warning<br>0 x 80 global bit for an error  |
| 5    | Status channel 1       | 0 x 01 warning corrosion<br>0 x 02 corrosion<br>0 x 04 sensor rupture<br>0 x 08 sensor short circuit<br>0 x 10 range undershoot<br>0 x 20 range overshoot<br>0 x 40 channel not operational<br>0 x 80 error A/D conversion   |
| 6    | Status channel 2       | See channel 1  |
| 7    | Extended device status | 0 x 01 maintenance necessary<br>0 x 02 warnings / error present  |
| 8    | Device operating mode  | Always 0   |



Note!

The Fieldgate FXA520 system components from Endress+Hauser allow the remote interrogation, remote diagnosis and remote configuration of connected HART® devices, e.g. user is automatically notified by e-mail or text message. The device evaluates the first 4 bytes of HART-Cmd #48 for diagnosis purposes.

■ HART® command No. 231 (HART-Cmd #231)

The classified diagnosis of the device can be checked by means of this command. Fault classes according to GMA VDE NAMUR 2650 guidelines:

| Byte | Contents                               | Meaning   |
|------|--|---|
| 1    | Information acc. to GMA VDE NAMUR 2650 | 0x01 -F- Fault<br>0x02 -C- Device in service mode<br>0x03 -M- Maintenance required<br>0x04 -S- Out of specification |
| 2+3  | Device error messages, see section 9.2 |   |

Fault classification see Chapter Error messages.



Note!

The intelligent active barrier RN221N with HART® diagnosis from Endress+Hauser communicates cyclically with connected HART® devices and signals diagnosis information via a switching contact.

## 7 Maintenance

In general, no specific maintenance is required for this device.

## 8 Accessories

If ordering accessories, please specify the serial number of the unit!

| Type   | Description   | Order code (International) | Order code (North American region) |
|--|---|----------------------------|------------------------------------|
| <b>Cable glands for connecting 2 sensors</b> | <ul style="list-style-type: none"> <li>■ NPT ½" cable gland 2 x D0.5 cable for 2 sensors</li> <li>■ M20x1.5 cable gland 2 x D0.5 cable for 2 sensors</li> </ul> | Order no. 51004654         | Order no. TMT162A-MB               |
|  |   | Order no. 51004653         | Order no. TMT162A-MC               |
| <b>Wall and stand pipe mounting kit</b>      | <ul style="list-style-type: none"> <li>■ Stainless steel wall/2" pipe mounting kit</li> <li>■ Mounting bracket 2" tube V4A</li> </ul>                           | Order no. 51004823         | Order no. TMT162A-MA               |
|  |   | Order no. 51006412         | Order no. TMT162A-MD               |
| <b>Cable entries and adapter</b>             | <ul style="list-style-type: none"> <li>■ Cable entry M20x1.5</li> <li>■ Adapter M20x1.5/NPT ½" cable entry</li> </ul>   | Order no. 51004949         | -                                  |
|  |   | Order no. 51004387         | -                                  |

## 9 Trouble-shooting

### 9.1 Trouble-shooting instructions

If faults occur after commissioning or during measurement always start any fault-finding sequence using the following checklists. The user is guided to the possible fault cause and its removal by question and answer.

### 9.2 Error messages

| Fault code | Cause                                       | Action/Remedy   | Mode <sup>1)</sup> |
|------------|---|---|--------------------|
| 0          | No fault, warning                           | -   | -                  |
| 10         | Hardware fault (device defective)           | Replace device  | F                  |
| 13         | Reference measurement point defective       | Replace device  | F                  |
| 15         | EEPROM defective                            | Replace device  | F                  |
| 16         | A/D convertor defective                     | Replace device  | F                  |
| 17         | Ambient temperature limit exceeded          | Electronics possibly damaged due to exceeding the ambient temperature range, return electronics to manufacturer for check | 0, F               |
| 19         | Supply voltage too low                      | Check supply voltage; check connection wires for corrosion  | F                  |
| 50         | Sensor 1 open circuit                       | Monitor sensor 1  | *                  |
| 51         | Sensor 1 short circuit                      | Monitor sensor 1  | *                  |
| 52         | Sensor 1 corrosion                          | Monitor sensor 1  | *                  |
| 53         | Outside sensor range                        | Incorrect sensor type 1 for application   | *                  |
| 60         | Sensor 2 open circuit                       | Monitor sensor 2  | *                  |
| 61         | Sensor 2 short circuit                      | Monitor sensor 2  | *                  |
| 62         | Sensor 2 corrosion                          | Monitor sensor 2  | *                  |
| 63         | Outside sensor range                        | Incorrect sensor type 2 for application   | *                  |
| 70         | Drift alarm                                 | Drift limit exceeded, check sensor  | F                  |
| 81         | Alarm: measuring range undershoot           | Measuring range poss. set too small   | F                  |
| 82         | Alarm: measuring range overshoot            | Measuring range poss. set too small   | F                  |
| 106        | Warning: Up/download active                 | -   | C                  |
| 107        | Warning: Output simulation active           | Deactivate output simulation  | C                  |
| 201        | Warning: Measured value too small           | PV change lower range starting point  | M                  |
| 202        | Warning: Measured value too high            | PV change upper range end point   | M                  |
| 203        | Warning: Ambient temperature limit exceeded | Electronics possibly damaged due to exceeding the ambient temperature range, return electronics to manufacturer for check | 0                  |
| 204        | Drift warning                               | Drift limit exceeded, check sensor  | M                  |
| 205        | Warning: Sensor backup activated            | Monitor sensor  | M                  |

| Fault code | Cause                                | Action/Remedy           | Mode <sup>1)</sup> |
|------------|--------------------------------------|-------------------------|--------------------|
| 206        | Warning:<br>Sensor 1 corrosion       | Monitor sensor 1        | M                  |
| 207        | Warning:<br>Sensor 2 corrosion       | Monitor sensor 2        | M                  |
| 208        | Unit reset to factory default values | -                       | 0                  |
| 209        | Device initialization                | -                       | 0                  |
| +1000      | Other faults active                  | Remove displayed faults |                    |

1) The modes have the following meaning: F: Fault, C: Device in service mode, M: Maintenance required, S: Out of specification, \*: depends on mode (F or M). See also section 6.4.2 Supported HART® commands.



**Note!**

If more than one fault is active, then the fault with the highest priority will be displayed. Once this fault has been remedied the next fault is displayed! Multiple fault occurrences can be recognized by an "Offset" of 1000.

**Unit reaction to sensor faults**

|   | PV = SV1<br>(2 Sensor inputs) | PV = SV1 - SV2<br>(Differential) | PV = (SV1+SV2)/2<br>(Average value) | PV = SV1 (or SV2)<br>(Sensor back-up) |
|---|-------------------------------|----------------------------------|-------------------------------------|---------------------------------------|
| <b>S1 defective</b>                                 | Fault                         | Fault                            | Fault                               | Warning                               |
| <b>S2 defective</b>                                 | Warning                       | Fault                            | Fault                               | Warning                               |
| <b>S1 and S2 defective</b>                          | Fault                         | Fault                            | Fault                               | Fault                                 |
| <b>Drift alarm<br/>(IS1-S2I &gt; limit value)</b>   | -                             | Fault                            | Fault                               | Fault                                 |
| <b>Drift warning<br/>(IS1-S2I &gt; limit value)</b> | -                             | Warning                          | Warning                             | Warning                               |

The icon "Warning" and error code appear in the display on warnings and errors. On error, the bargraph in the display also flashes - instead of the measured value only the error code is displayed. (See also chapter 5.2).

**9.2.1 Corrosion detection**

Sensor connection cable corrosion can lead to false measured value readings. Therefore our unit offers the possibility to recognize any corrosion before the measured values are affected.

There are 2 different steps selectable dependent on the application requirements:

- **off** (warning output just before reaching the alarm set point. This allows preventative maintenance/trouble-shooting to be done).
- **on** (no warning. immediate alarm)

The following table shows the reaction of the device on sensor cable connection resistance change. These also indicate the reaction dependent on the parameter selection on/off.



**Note!**

Corrosion detection only for RTD 4-wire connection

| RTD <sup>1)</sup> | $< \approx 2 \text{ k}\Omega$ | $2 \text{ k}\Omega \approx x < \approx 3 \text{ k}\Omega$ | $> \approx 3 \text{ k}\Omega$ |
|-------------------|-------------------------------|---|-------------------------------|
| off               | —                             | WARNING   | ALARM                         |
| on                | —                             | ALARM   | ALARM                         |

1) Pt100 = 100  $\Omega$  at 0 °C (32 °F), Pt1000 = 1000  $\Omega$  at 0 °C (32 °F)

| TC  | $< \approx 10 \text{ k}\Omega$ | $10 \text{ k}\Omega \approx x < \approx 15 \text{ k}\Omega$ | $> \approx 15 \text{ k}\Omega$ |
|-----|--------------------------------|---|--------------------------------|
| off | —                              | WARNING <sup>1)</sup>                                       | ALARM                          |
| on  | —                              | ALARM   | ALARM                          |

1) On very high ambient temperatures a 3 x measured value deviation from the specification is possible.

The sensor resistance can influence the resistance shown in the tables. On simultaneous increase of all sensor connection cable resistances the values indicated in the tables can be divided by two. In corrosion detection it has been assumed that this is a slow process with a continuous increase in resistance.

## 9.2.2 Monitoring the supply voltage

If the required supply voltage is undershot, the analog output value drops  $\leq 3.6 \text{ mA}$  for approx. 3 s. Error code 19 appears on the display. Afterwards, the device tries to output the normal analog output value again. If the supply voltage remains too low, the analog output value drops again to  $\leq 3.6 \text{ mA}$ . This prevents the device from continuously outputting an incorrect analog output value.

## 9.3 Application errors without messages

### 9.3.1 General application errors

| Error            | Cause  | Action/Remedy   |
|------------------|--|---|
| No communication | No power supply on the 2-wire circuit                                | Connect the cables correctly according to the connection schematic (polarity) |
|                  | 250 $\Omega$ communication resistor is missing                       | See chapter 4.3.1 "HART® connection"  |
|                  | Power supply too low (<10.5 V or 8 V without display with jumper J3) | Check power supply  |
|                  | Defective interface cable  | Check interface cable   |
|                  | Defective interface  | Check PC interface  |
|                  | Defective device   | Replace device  |

### 9.3.2 Application errors for RTD connection

Pt100/Pt500/Pt1000/Ni100

| Error   | Cause   | Action/Remedy  |
|---|---|--|
| Fault current<br>( $\leq 3.6$ mA or $\geq 21$ mA) | Defective sensor  | Check sensor   |
|   | Incorrect connection of RTD                             | Connect cables correctly to terminal schematic   |
|   | Incorrect connection of the 2-wire cable                | Connect cables correctly to terminal schematic (polarity)  |
|   | Faulty setup of the device (number of wire connections) | Change device function SENSOR CONNECTION   |
|   | Setup   | Incorrect sensor type set up under device function SENSOR TYPE;<br>correct setup to correct type |
|   | Defective device  | Replace device   |

| Error                                   | Cause  | Action/Remedy                            |
|---|--|--|
| Measured value incorrect/<br>inaccurate | Faulty sensor installation                       | Install sensor correctly                 |
|   | Heat conducted by sensor                         | Take note of sensor installation point   |
|   | Transmitter setup faulty (number of wires)       | Change device function SENSOR CONNECTION |
|   | Transmitter setup faulty (scale)                 | Change scale                             |
|   | Incorrect RTD set up                             | Change device function SENSOR TYPE       |
|   | Sensor connection (2-wire)                       | Check sensor connection                  |
|   | Sensor cable resistance (2-wire) not compensated | Compensate cable resistance              |
|   | Offset incorrectly set                           | Check offset                             |


### 9.3.3 Application errors for TC connection

| Error   | Cause                          | Action/Remedy   |
|---|--------------------------------|---|
| Fault current<br>( $\leq 3.6$ mA or $\geq 21$ mA) | Incorrect connection of sensor | Connect cables correctly to terminal schematic (polarity)                                   |
|   | Defective sensor               | Check sensor  |
|   | Setup                          | Incorrect sensor type set up under device function SENSOR TYPE; set up correct thermocouple |
|   | Defective device               | Replace device  |

| Error                                   | Cause                            | Action/Remedy                                 |
|---|----------------------------------|---|
| Measured value incorrect/<br>inaccurate | Faulty sensor installation       | Install sensor correctly                      |
|   | Heat conducted by sensor         | Take note of sensor installation point        |
|   | Transmitter setup faulty (scale) | Change scale                                  |
|   | Incorrect TC setup               | Change device function SENSOR TYPE            |
|   | Incorrect cold junction setup    | See chapter "Description of device functions" |
|   | Incorrect offset setup           | Check offset                                  |

## 9.4 Spare parts

Parts list on following page. If ordering accessories, please specify the serial number of the unit!



| Elektronics |   |
|-------------|---|
|             | <b>Certification:</b><br><b>A</b> Non hazardous areas<br><b>B</b> ATEX Ex ia, FM IS, CSA IS                               |
|             | <b>Sensor input; communication:</b><br><b>A</b> 1x; HART<br><b>B</b> 2x; config. output sensor 1; HART<br><b>C</b> 2x; FF |
|             | <b>Configuration:</b><br><b>A</b> Standard factory default<br><b>K</b> Standard model, North American region              |
| TMT162E-    | ← Order code  |

| Housing  |  |
|----------|--|
|          | <b>Certification:</b><br><b>A</b> Non hazardous areas + ATEX Ex ia<br><b>B</b> ATEX Ex d   |
|          | <b>Material:</b><br><b>A</b> Aluminum, HART<br><b>B</b> Stainless steel 316L, HART<br><b>C</b> T17, HART<br><b>F</b> Aluminum, FF<br><b>G</b> Stainless steel 316L, FF<br><b>H</b> T17, FF                               |
|          | <b>Cable entry:</b><br><b>1</b> 2 x thread NPT 1/2" + terminal block + 1 blanking plug<br><b>2</b> 2 x thread M20x1.5 + terminal block + 1 blanking plug<br><b>4</b> 2 x thread G1/2" + terminal block + 1 blanking plug |
|          | <b>Model:</b><br><b>A</b> Standard<br><b>K</b> Standard model, North American region   |
| TMT162G- | ← Order code   |

| Pos. no.  | Order code (International) | Order code (North American region) | Spare part   |
|-----------|----------------------------|------------------------------------|--|
| 1         | 51004472                   | TMT162U-BA                         | Housing cover blind Alu Exd ATEX Ex d, FM XP, without o-ring, CSA XP only as cover of terminal part              |
| 1         | TMT162X-HA                 |                                    | Housing cover blind stainless steel 316L Exd ATEX Ex d, FM XP without o-ring, CSA only as cover of terminal part |
| 1         | 51004920                   | TMT162U-AA                         | Housing cover blind Alu without o-ring   |
| 1         | TMT162X-HB                 |                                    | Housing cover blind stainless steel 316L without seal  |
| 2         | 51004450                   | TMT162U-BA                         | Housing cover display Alu Ex d ATEX Ex d, FM XP, CSA XP without o-ring   |
| 2         | TMT162X-HC                 |                                    | Housing cover cpl. Ex d display stainless steel 316L Ex d ATEX Ex d, FM XP, CSA XP without o-ring                |
| 2         | 51004913                   | TMT162U-AB                         | Housing cover display Alu without o-ring   |
| 2         | TMT162X-HD                 |                                    | Housing cover cpl. display Exd stainless steel 316L, ATEX Ex d, FM XP, CSA XP, without o-ring                    |
| 3         | 51004555                   | TMT162U-CA                         | O-ring 88x3 NBR70 PTFE coating   |
| 4         | 51004948                   | TMT162U-CB                         | Cover clamp spare kit<br>Screw, washer, spring washer  |
| 5         | TMT162X-DA                 | TMT162U-DA                         | Display + display fitting kit  |
| 6         | 51004454                   | TMT162U-CD                         | Display fitting kit  |
| 7         | 51004949                   |                                    | M20x1.5 cable entry  |
| 8         | 51004653                   | TMT162U-CF                         | M20x1.5 cable gland 2xD0.5 cable for 2 sensors   |
| 9         | 51007474                   | TMT162U-CG                         | M20x1.5 cable gland 2xD0.5 cable for 2 sensors (Y-Form)  |
| 10        | 51004654                   | TMT162U-CE                         | NPT 1/2" cable gland 2xD0.5 cable for 2 sensors  |
| No number | 51004915                   | TMT162U-CH                         | Adapter M20x1.5 outside/ M24x1.5 inside VA   |
| No number | 51004823                   | TMT162U-CI                         | Stainless steel wall/2" pipe mounting kit  |
| No number | 51006412                   | TMT162A-MD                         | Mounting bracket 2" tube V4A   |
| No number | TMT162X-HE                 | -                                  | Housing cover blind for T17 housing, stainless steel 316L  |

| Pos. no.  | Order code (International) | Order code (North American region) | Spare part   |
|-----------|----------------------------|------------------------------------|--|
| No number | TMT162X-HF                 | -                                  | Housing cover complete display, polycarbonate for T17housing, stainless steel 316L |
| No number | TMT162X-HG                 | -                                  | Housing cover complete display, glass für T17 housing, stainless steel 316L        |

## 9.5 Returns

The unit should be well packed, preferably in the original packaging when storing the unit for further use or returning it for repair. Repairs must only be done by the service organization of your supplier or by trained skilled personnel.

When returning the device for repair, please add a description of both the fault and the application. For USA and Canada please follow the Return Authorization Policy.

## 9.6 Disposal

The device contains electronic components and when being disposed of should be placed in the electronic waste. Please take note of any local waste disposal legislation when disposing of the device.

## 9.7 Software history

### Release

The release number on the nameplate and in the Operating Instructions indicates the device release history: XX.YY.ZZ (example 01.02.01).

- XX Change in the main version.  
No longer compatible. Changes to device and Operating Instructions.
- YY Change in the functionality and operation.  
Compatible. Changes to Operating Instructions.
- ZZ Debugging and internal modifications.  
No changes to Operating Instructions.

| Release No., date | Operation, documentation  | Modifications                          |
|-------------------|---|--|
| 01.01.00, 09/2002 | Compatible with: <ul style="list-style-type: none"> <li>■ HART Communicator DXR275 (as of OS4.6) with DevRev1, DDRev 1</li> <li>■ Readwin® 2000 version 1.9.1.1</li> <li>■ Commuwin II (as of version 2.07.01-4)</li> <li>■ AMS (as of version 5.0)</li> <li>■ PDM (as of version 5.1)</li> </ul> | Original firmware                      |
| 01.02.00, 12/2002 | Compatible with: <ul style="list-style-type: none"> <li>■ Readwin® 2000 version 1.10.1.1</li> </ul>   | Parameter for trimming 4 to 20 mA loop |

| Release No., date | Operation, documentation   | Modifications  |
|-------------------|--|--|
| 01.03.00, 09/2004 | Compatible with: <ul style="list-style-type: none"> <li>■ HART Communicator DXR275 (from OS4.6) with DevRev 2, DDRev 1</li> <li>■ HART Communicator DXR375 (from OS1.6) with DevRev 2, DDRev 1</li> <li>■ Readwin® 2000 (as of version 1.16.2.0)</li> <li>■ AMS (as of version 5.0)</li> <li>■ PDM (as of version 5.1)</li> <li>■ Fieldcare version as of 2.01.00</li> </ul> | <ul style="list-style-type: none"> <li>■ Customer-specific linearization, sensor matching f. RTD sensors</li> <li>■ Callendar Van-Dusen coefficients for Pt100</li> <li>■ New sensors:               <ul style="list-style-type: none"> <li>Pt100 SAMA (<math>\alpha = 0.003923</math>)</li> <li>Cu10 (<math>\alpha = 0.00427</math>)</li> <li>Pt200 IEC 751 (<math>\alpha = 0.00385</math>)</li> <li>Ni120 (<math>\alpha = 0.00672</math>)</li> <li>Pt50/100 GOST (<math>\alpha = 0.003911</math>)</li> <li>Cu50/100 GOST (<math>\alpha = 0.004278</math>)</li> </ul> </li> <li>■ Adjustable error current value (between 21.6 and 23 mA)</li> <li>■ Measured value shown on display with unit %</li> <li>■ Adjustable number of figures after decimal point</li> </ul> |
| 01.03.01, 04/2005 |  | New HART® command 231 and minor bugfixes   |
| 01.03.03, 12/2006 |  | Internal SW modifications  |

# 10 Technical data

## 10.0.1 Input

|                   |   |
|-------------------|---|
| Measured variable | Temperature (temperature linear transmission behavior), resistance and voltage.                           |
| Measuring range   | The transmitter monitors different measuring ranges depending on the sensor connection and input signals. |

### Type of input

| Input  | Designation  | Measuring range limits            | Min. span     |
|--|--|-----------------------------------|---------------|
| <b>Resistance thermometer (RTD)</b><br>to IEC 60751<br>( $\alpha = 0.00385$ )<br><br>to JIS C1604-81<br>( $\alpha = 0.003916$ )<br>to DIN 43760<br>( $\alpha = 0.006180$ )<br><br>to Edison Copper Winding No. 15<br>( $\alpha = 0.004274$ )<br>to SAMA<br>( $\alpha = 0.003923$ )<br>to Edison Curve<br>( $\alpha = 0.006720$ )<br>to GOST<br>( $\alpha = 0.003911$ )<br><br>to GOST<br>( $\alpha = 0.004278$ ) | Pt100  | -328 to 1562 °F (-200 to 850 °C)  | 18 °F (10 °C) |
|  | Pt200  | -328 to 1562 °F (-200 to 850 °C)  | 18 °F (10 °C) |
|  | Pt500  | -328 to 482 °F (-200 to 250 °C)   | 18 °F (10 °C) |
|  | Pt1000   | -328 to 482 °F (-200 to 250 °C)   | 18 °F (10 °C) |
|  | Pt100  | -328 to 1200 °F (-200 to 649 °C)  | 18 °F (10 °C) |
|  | Ni100  | -76 to 482 °F (-60 to 250 °C)     | 18 °F (10 °C) |
|  | Ni1000   | -76 to 302 °F (-60 to 150 °C)     | 18 °F (10 °C) |
|  | Cu10   | -148 to 500 °F (-100 to 260 °C)   | 18 °F (10 °C) |
|  | Pt100  | -148 to 1292 °F (-100 to 700 °C)  | 18 °F (10 °C) |
|  | Ni120  | -94 to 518 °F (-70 to 270 °C)     | 18 °F (10 °C) |
|  | Pt50   | -328 to 2012 °F (-200 to 1100 °C) | 18 °F (10 °C) |
|  | Pt100  | -328 to 1562 °F (-200 to 850 °C)  | 18 °F (10 °C) |
|  | Cu50, Cu100  | -328 to 392 °F (-200 to 200 °C)   | 18 °F (10 °C) |
| Polynomial RTD<br>Pt100 (Callendar - van Dusen)  | -328 to 1562 °F (-200 to 850 °C)<br>-328 to 1562 °F (-200 to 850 °C) | 18 °F (10 °C)<br>18 °F (10 °C)    |               |
| <ul style="list-style-type: none"> <li>■ Type of connection: 2-wire, 3-wire or 4-wire connection</li> <li>■ With 2-wire circuit, compensation of wire resistance possible (0 to 30 Ω)</li> <li>■ With 3-wire and 4-wire connection, sensor wire resistance to max. 50 Ω per wire</li> <li>■ Sensor current: ≤ 0.3 mA</li> </ul>  |  |                                   |               |
| <b>Resistance transmitter</b>  | Resistance Ω   | 10 to 400 Ω<br>10 to 2000 Ω       | 10 Ω<br>100 Ω |

| Input  | Designation  | Measuring range limits  | Min. span  |
|--|--|---|--|
| <b>Thermocouples (TC)</b><br>to NIST Monograph 175,<br>IEC 60584<br><br>to ASTM E988<br><br>to DIN 43710   | Type B (PtRh30-PtRh6) <sup>1) 2)</sup><br>Type E (NiCr-CuNi)<br>Type J (Fe-CuNi)<br>Type K (NiCr-Ni)<br>Type N (NiCrSi-NiSi)<br>Type R (PtRh13-Pt)<br>Type S (PtRh10-Pt)<br>Type T (Cu-CuNi) | 32 to 3308 °F (0 to +1820 °C)<br>-454 to 1832 °F (-270 to +1000 °C)<br>-346 to 2192 °F (-210 to +1200 °C)<br>-454 to 2501 °F (-270 to +1372 °C)<br>-454 to 2372 °F (-270 to +1300 °C)<br>-58 to 3214 °F (-50 to +1768 °C)<br>-58 to 3214 °F (-50 to +1768 °C)<br>-454 to 752 °F (-270 to +400 °C) | 900 °F (500 °C)<br>90 °F (50 °C)<br>90 °F (50 °C)<br>90 °F (50 °C)<br>90 °F (50 °C)<br>900 °F (500 °C)<br>900 °F (500 °C)<br>90 °F (50 °C) |
|  | Type C (W5Re-W26Re)<br>Type D (W3Re-W25Re)   | 32 to 4208 °F (0 to +2320 °C)<br>32 to 4523 °F (0 to +2495 °C)  | 900 °F (500 °C)<br>900 °F (500 °C)   |
|  | Type L (Fe-CuNi)<br>Type U (Cu-CuNi)   | -328 to 1652 °F (-200 to +900 °C)<br>-328 to 1112 °F (-200 to +600 °C)  | 90 °F (50 °C)<br>90 °F (50 °C)   |
| <ul style="list-style-type: none"> <li>■ Internal cold junction (Pt100)</li> <li>■ Accuracy of cold junction: ± 1.8 °F (± 1 °C)</li> <li>■ Max. sensor resistance 10 kΩ (if sensor resistance is greater than 10 kΩ, error message as per NAMUR NE 89)<sup>3)</sup></li> </ul> |  |   |  |
| <b>Voltage transmitter (mV)</b>  | Millivolt transmitter (mV)   | -20 to 100 mV   | 5 mV   |

- 1) High measuring error increase for temperature lower than 572 °F (300 °C).
- 2) When operating conditions are based over a large temperature range, the TMT162 offers you the ability to do a split range. For example a Type S or R thermocouple can be used for the low range and a Type B can be used for the upper range. The TMT162 is then programmed by the end user to switch at a predetermined temperature. This allows for utilization of the best performance from each individual thermocouple and provides 1 output that represents the process temperature. Note the dual sensor option must be requested when placing an order.
- 3) Basic requirements NE 89:  
 Detection of increased wire resistance (e.g. corrosion of contacts or wires) of TC or RTD/4-wire. Warning - exceeding ambient temperature.

## 10.0.2 Output

Output signal                      Analog 4 to 20 mA, 20 to 4 mA

Signal on alarm

### Breakdown information to NAMUR NE 43

Breakdown information is created when the measuring information is invalid or not present anymore and gives a complete listing of all errors occurring in the measuring system.

|   |                | Signal (mA) |
|---|----------------|-------------|
| Under ranging                           | Standard       | 3.8         |
| Over ranging                            | Standard       | 20.5        |
| Sensor break; sensor short circuit low  | To NAMUR NE 43 | ≤ 3.6       |
| Sensor break; sensor short circuit high | To NAMUR NE 43 | ≥ 21        |


The high alarm is adjustable between 21.6 mA and 23 mA allowing for flexibility when working with the requirements of most control systems.

Load                                      Max.  $(V_{\text{power supply}} - 11 \text{ V}) / 0.022 \text{ A}$  (current output)

Linearization/  
 transmission behavior                      Temperature linear, resistance linear, voltage linear

|                          |  |
|--------------------------|--|
| Filter                   | 1st order digital filter: 0 to 60 s                |
| Galvanic isolation       | U = 2 kV AC (input/output and input/housing)       |
| Min. current consumption | ≤ 3.5 mA   |
| Current limit            | ≤ 23 mA  |
| Switch on delay          | 4 s (during switch-on operation $I_a \leq 3.8$ mA) |

### 10.0.3 Power supply

|                 |  |
|-----------------|--|
| Supply voltage  |  <p> <math>U_b = 11</math> to 40 V (8 to 40 V without display), reverse polarity protection<br/>           Note!<br/>           (according to IEC 61010-1 (EN 61010-1, CSA 1010.1-92)<br/>           The TMT162 must be powered by a 11 to 40 VDC power supply with a limited power according to NEC Class 02 (low voltage, low current) limited to 8 A and 150 VA in case of a short circuit.         </p> |
| Cable entry     | For overview see chapter 8 "Accessories"   |
| Residual ripple | Perm. residual ripple $U_{ss} \leq 3$ V at $U_b \geq 13.5$ V, $f_{max.} = 1$ kHz   |

### 10.0.4 Performance characteristics

|                                |   |
|--------------------------------|---|
| Response time                  | 1 s per channel   |
| Reference operating conditions | Calibration temperature: $73.4$ °F ± 9°F ( $+23$ °C ± 5 °C) |

## Maximum measured error

|                                     | Designation                | Accuracy               |                   |
|-------------------------------------|----------------------------|------------------------|-------------------|
|                                     |                            | Digital                | D/A <sup>1)</sup> |
| <b>Resistance thermometer (RTD)</b> | Cu100, Pt100, Ni100, Ni120 | 0.18 °F (0.1 °C)       | 0.02%             |
|                                     | Pt500,                     | 0.54 °F (0.3 °C)       | 0.02%             |
|                                     | Cu50, Pt50, Pt1000, Ni1000 | 0.36 °F (0.2 °C)       | 0.02%             |
|                                     | Cu10, Pt200                | 1.8 °F (1 °C)          | 0.02%             |
| <b>Thermocouples (TC)</b>           | K, J, T, E, L, U           | typ. 0.45 °F (0.25 °C) | 0.02%             |
|                                     | N, C, D                    | typ. 0.9 °F (0.5 °C)   | 0.02%             |
|                                     | S, B, R                    | typ. 1.8 °F (1.0 °C)   | 0.02%             |

1) % relates to the set span. Accuracy = digital + D/A accuracy

|                                   | Measuring range | Accuracy |                   |
|-----------------------------------|-----------------|----------|-------------------|
|                                   |                 | Digital  | D/A <sup>1)</sup> |
| <b>Resistance transmitter (Ω)</b> | 10 to 400 Ω     | ± 0.04 Ω | 0.02%             |
|                                   | 10 to 2000 Ω    | ± 0.8 Ω  | 0.02%             |
| <b>Voltage transmitter (mV)</b>   | -20 to 100 mV   | ± 10 μV  | 0.02%             |

1) % relates to the set span. Accuracy = digital + D/A accuracy

| Physical input range of the sensors |  |
|-------------------------------------|--|
| 10 to 400 Ω                         | Cu10, Cu50, Cu100, Polynomial RTD, Pt50, Pt100, Ni100, Ni120 |
| 10 to 2000 Ω                        | Pt200, Pt500, Pt1000, Ni1000                                 |
| -20 to 100 mV                       | Thermocouple type: C, D, E, J, K, L, N                       |
| -5 to 30 mV                         | Thermocouple type: B, R, S, T, U                             |

**Sensor transmitter matching**

RTD sensors are one of the most linear temperature elements for measurement. However, the output still needs to be linearized. To significantly improve temperature measurement accuracy, the TMT162 allows you to utilize two methods to achieve that:

- Customer specific linearization  
Using the E+H Readwin<sup>®</sup> 2000 software or the HART<sup>®</sup> handheld the TMT162 can be programmed with sensor specific curve data. Once the sensor-specific data has been entered, the TMT162 utilizes this to generate a custom curve.
- Callendar - Van Dusen coefficients  
The Callendar - Van Dusen equation is described as:

$$R_T = R_0[1 + AT + BT^2 + C(T - 100)T^3]$$

where A, B and C are constants, commonly referred to as Callendar - Van Dusen coefficients. The precise values of A, B and C are derived from the calibration data for the RTD, and are specific to each RTD sensor.

The process involves programming the TMT162 with curve data for a specific RTD, instead of using the standard curve.

Sensor transmitter matching using any of the above methods substantially improves the temperature measurement accuracy of the entire system. This is as a result of the transmitter using the sensor's actual resistance vs. temperature curve data instead of the ideal curve data.

Repeatability 0.0015% of the physical input range (16 Bit)  
Resolution A/D conversion: 18 Bit

Influence of the supply voltage  $\leq \pm 0.005\%/V$  deviation from 24 V, related to the full scale value

Long-term stability  $\leq 0.18$  °F/year ( $\leq 0.1$  °C/year) or  $\leq 0.05\%/year$   
Data under reference conditions. % relates to the set span. The larger value applies.

Influence of ambient temperature (temperature drift) Total temperature drift = input temperature drift + output temperature drift (see example below)

| Effect on the accuracy when ambient temperature changes by 1 °C (1.8 °F): |  |
|---|--|
| Input 10 to 400 Ω   | 0.001% of measured value                                   |
| Input 10 to 2000 Ω  | 0.001% of measured value                                   |
| Input -20 to 100 mV   | typ. 0.001% of measured value (maximum value = 1.5 x typ.) |
| Input -5 to 30 mV   | typ. 0.001% of measured value (maximum value = 1.5 x typ.) |
| Output 4 to 20 mA   | typ. 0.001% of span (maximum value = 1.5 x typ.)           |

| Typical sensor resistance change when process temperature changes by 1 °C (1.8 °F): |              |              |              |             |
|---|--------------|--------------|--------------|-------------|
| Cu10: 0.04 Ω  | Pt200: 0.8 Ω | Ni120: 0.7 Ω | Cu50: 0.2 Ω  | Pt50: 0.2 Ω |
| Cu100, Pt100: 0.4 Ω   | Pt500: 2 Ω   | Pt1000: 4 Ω  | Ni100: 0.6 Ω | Ni1000: 6 Ω |

| Typical change in thermoelectric voltage when process temperature changes by 1 °C (1.8 °F): |          |          |          |          |          |
|---|----------|----------|----------|----------|----------|
| B: 10 μV  | C: 20 μV | D: 20 μV | E: 75 μV | J: 55 μV | K: 40 μV |
| L: 55 μV  | N: 35 μV | R: 12 μV | S: 12 μV | T: 50 μV | U: 60 μV |

Examples for calculation of accuracy:

- **Example 1:** input temperature drift  $\Delta\theta = 18$  °F (10 °C), Pt100, span 32 to 212 °F (0 to 100 °C)  
 Maximum process value: 212 °F (100 °C)  
 Measured resistance value: 138.5 Ω (s. IEC751)  
 Typ. influence in Ω: (0.001% of 138.5 Ω) \* 10 = 0.01385 Ω  
 Conversion Ω to °C: 0.01385 Ω / 0.4 Ω/°C = 0.03 °C (0.054 °F)
- **Example 2:** input temperature drift  $\Delta\theta = 18$  °F (10 °C), thermocouple type K with span 32 to 1112 °F (0 to 600 °C)  
 Maximum process value: 1112 °F (600 °C)  
 Measured thermoelectric voltage: 24905 μV (s. IEC584)  
 Typ. influence in μV: (0.001% of 24905 μV) \* 10 = 2.5 μV  
 Conversion Ω to °C: 2.5 μV / 40 μV/°C = 0.06 °C (0.11 °F)
- **Example 3:** output temperature drift  $\Delta\theta = 18$  °F (10 °C), measuring range 32 to 212 °F (0 to 100 °C)  
 Span: 212 °F (100 °C)  
 Typical influence: (0.001% of 212 °F) \* 10 = 0.02 °F (0.01 °C)
- **Example 4:** max. possible measured error  $\Delta\theta = 18$  °F (10 °C), Pt100, measuring range 32 to 212 °F (0 to 100 °C)

Measured error Pt100: 0.18 °F (0.1 °C)  
 Output measured error: 0.04 °F (0.02 °C) (0.02% of 212 °F)  
 Input temperature drift: 0.054 °F (0.03 °C)  
 Output temperature drift: 0.018 °F \* 1.5 = 0.03 °F (0.015 °C)  
 Max. possible error (total of errors): 0.3 °F (0.165 °C)

$\Delta\theta$  = deviation of ambient temperature from the reference operating condition.

Total measuring point error = max. possible measured error + temperature sensor error.

Influence of the cold junction Pt100 IEC 60751 Cl. B (internal cold junction for thermocouples TC)

### 10.0.5 Environment conditions

Ambient temperature limits

- Without display: -40 to 185 °F (-40 to +85 °C)
- With display: -40 to 158 °F (-40 to +70 °C)

For use in hazardous area, see Ex certification or control drawing



Note!

At temperatures < -4 °F (-20 °C) the display may react slowly.

Storage temperature

- Without display: -40 to 212 °F (-40 to +100 °C)
- With display: -40 to 185 °F (-40 to +85 °C)

Altitude

Up to 6560 ft (2000 m) above sea level according to IEC 61010-1 (EN 61010-1), CSA 1010.1-92

Climate class

As per IEC 60 654-1, Class C

Degree of protection

- IP67, NEMA 4x
- IP69K, (T17 housing)

Shock and vibration resistance

3g / 2 to 150 Hz as per IEC 60 068-2-6

Electromagnetic compatibility (EMC)

#### CE Electromagnetic Compatibility Compliance

The device meets all requirements listed under IEC 61326 Amendment 1, 1998 and NAMUR NE 21

This recommendation is a uniform and practical way of determining whether the devices used in laboratories and process control are immune to interference with an objective to increase its functional safety.

|                               |               |  |                            |
|-------------------------------|---------------|--|----------------------------|
| ESD (Electrostatic discharge) | IEC 61000-4-2 | 6 kV cont., 8 kV air                           |                            |
| Electromagnetic fields        | IEC 61000-4-3 | 0.08 to 2 GHz<br>80 to 750 MHz<br>1.4 to 2 GHz | 10 V/m<br>30 V/m<br>30 V/m |
| Burst (fast transient)        | IEC 61000-4-4 | 2 kV   |                            |
| surge                         | IEC 61000-4-5 | 0.5 kV sym.                                    |                            |
| Conducted RF                  | IEC 61000-4-6 | 0.01 to 80 MHz                                 | 10 V                       |

Condensation

Permitted

Installation category 1 to IEC 61010

Pollution degree 2 to IEC 61010

### 10.0.6 Mechanical construction

Design, dimensions




Fig. 13: Data in inches (mm)

Die-cast aluminum housing for general purpose or as option stainless steel housing  
 \*dimensions without display = 112 mm (4.41")




Fig. 14: Data in inches (mm)

Optional T17 stainless steel housing for hygienic applications

- Separate electronics compartment and connection compartment
- Display rotatable in 90° stages

Weight

- Approx. 1.4 kg (3 lbs), with display, aluminum housing
- Approx. 4.2 kg (9.3 lbs), with display, stainless steel housing
- Approx. 1.25 kg (2.76 lbs), with display, T17 housing

## Material

| Housing  | Nameplate         |
|--|-------------------|
| Die-cast aluminum housing AlSi10Mg with powder coating on polyester basis  | 1.4301 (AISI 304) |
| Stainless steel 1.4435 (AISI 316L)   | 1.4301 (AISI 304) |
| Stainless steel 1.4435 (AISI 316L) for hygienic applications (T17 housing) | -                 |

## Terminals

Cable up to max. 12 AWG

### 10.0.7 Certificates and approvals

## CE mark

The measurement system fulfils the requirements demanded by the EU regulations. Endress+Hauser acknowledges successful unit testing by adding the CE mark.

## Ex approval

- FM IS, NI Class I, Div. 1+2, Group A, B, C, D  
Depending on location install per National Electrical Code (NEC) using wiring methods described in article 500 through article 510. For Nonincendive installation an intrinsic safety barrier is not required.  
CSA IS, NI Class I, Div. 1+2, Group A, B, C, D  
ATEX II1G EEx ia IIC T4/T5/T6
- FM XP, DIP, NI Class I, II, III, Div. 1+2, Group A, B, C, D, E, F, G  
CSA XP, DIP, NI Class I,II,III, Div. 1+2, Group A, B, C, D, E, F, G  
ATEX II2G EEx d IIC T6
- FM XP, DIP, IS, NI Class I,II,III, Div. 1+2, Group A, B, C, D, E, F, G  
CSA XP, DIP, IS, NI Class I,II,III, Div. 1+2, Group A, B, C, D, E, F, G  
ATEX EEx d, EEx ia
- FM+CSA XP, DIP, IS, NI Class I,II,III, Div. 1+2, Group A, B, C, D, E, F, G  
ATEX II3G EEx nA IIC T4/T5/T6
- ATEX II1/2D
- CSA General Purpose

## CSA GP

CSA General Purpose

## Marine approval GL

Ship building approval (Germanischer Lloyd)

## UL

Recognized component to UL 3111-1

Other standards and guidelines

- IEC 60529:  
Degrees of protection by housing (IP-Code)
- IEC 61010:  
Safety requirements for electrical measurement, control and laboratory instrumentation.
- IEC 61326:  
Electromagnetic compatibility (EMC requirements)
- NAMUR  
Standardization association for measurement and control in chemical and pharmaceutical industries. (www.namur.de)
- NEMA  
Standardization association for the electrical industry.

Functional safety according to IEC 61508/ IEC 61511

FMEDA including SFF determination and  $PFD_{AVG}$  calculation according to IEC 61508. See also Functional Safety manual in chapter 'Further documentation'.

### 10.0.8 Further documentation

- Functional safety manual (SD005R/09/en)
- Installation manual configuration software FieldCare (BA 031S/04/a4)
- Ex supplementary documentation:
  - ATEX II2(1)G: XA 020R/09/a3
  - ATEX II2G, EEx d: XA 031R/09/a3
  - ATEX II2D: XA 032R/09/a3
  - ATEX II1G: XA 033R/09/a3
- Control Drawings:
  - FM IS 51005925
  - FM XP and DIP 51005926
  - CSA IS 51005927
  - CSA XP and DIP 51005928
- Technical information 'Fieldgate FXA520' (TI369F/00/en)
- Operating manual 'Fieldgate FXA520' (BA258F/00/en)

## 11 Appendix

### 11.1 The Callendar - van Dusen Method

It is a method to match sensor and transmitter to improve the accuracy of the measurement system. According to IEC 60751, the non-linearity of the platinum thermometer can be expressed as (1):

$$R_T = R_0[1 + AT + BT^2 + C(T - 100)T^3]$$

in which C is only applicable when  $T < 0$  °C.

The coefficients A, B, and C for a standard sensor are stated in IEC 60751. If a standard sensor is not available or if a greater accuracy is required than can be obtained from the coefficients in the standard, the coefficients can be measured individually for each sensor. This can be done e.g. by determining the resistance value at a number of known temperatures and then determining the coefficients A, B, and C by regression analysis.

However, an alternative method for determination of these coefficients exists. This method is based on the measuring of 4 known temperatures:

- Measure  $R_0$  at  $T_0 = 0$  °C (the freezing point of water)
- Measure  $R_{100}$  at  $T_{100} = 100$  °C (the boiling point of water)
- Measure  $R_h$  at  $T_h =$  a high temperature (e.g. the freezing point of zink, 419.53 °C)
- Measure  $R_l$  at  $T_l =$  a low temperature (e.g. the boiling point of oxygen, -182.96 °C)

#### Calculation of $\alpha$

First the linear parameter  $\alpha$  is determined as the normalized slope between 0 and 100 °C (2):

$$\alpha = \frac{R_{100} - R_0}{100 \cdot R_0}$$

If this rough approximation is enough, the resistance at other temperatures can be calculated as (3):

$$R_T = R_0 + R_0 \alpha \cdot T$$

and the temperature as a function of the resistance value as (4):

$$T = \frac{R_T - R_0}{R_0 \cdot \alpha}$$

#### Calculation of $\delta$

Callendar has established a better approximation by introducing a term of the second order,  $\delta$ , into the function. The calculation of  $\delta$  is based on the disparity between the actual temperature,  $T_h$ , and the temperature calculated in (4) (5):

$$\delta = \frac{T_h - \frac{RT_h - R_0}{R_0 \cdot \alpha}}{\left(\frac{T_h}{100} - 1\right)\left(\frac{T_h}{100}\right)}$$

With the introduction of  $\delta$  into the equation, the resistance value for positive temperatures can be calculated with great accuracy (6):

$$R_T = R_0 + R_0 \alpha \left( T + -\delta \left( \frac{T}{100} - 1 \right) \left( \frac{T}{100} \right) \right)$$

**Calculation of  $\beta$** 

At negative temperatures (6) will still give a small deviation. Van Dusen therefore introduced a term of the fourth order,  $\beta$ , which is only applicable for  $T < 0$  °C. The calculation of  $\beta$  is based on the disparity between the actual temperature,  $t_l$ , and the temperature that would result from employing only  $\alpha$  and  $\delta$  (7):

$$\beta = \frac{T_l - \left[ \frac{RT_l - R_0}{R_0 \cdot \alpha} + \delta \left( \frac{T_l}{100} - 1 \right) \left( \frac{T_l}{100} \right) \right]}{\left( \frac{T_l}{100} - 1 \right) \left( \frac{T_l}{100} \right)^3}$$

With the introduction of both Callendar's and van Dusen's constant, the resistance value can be calculated correctly for the entire temperature range, as long as one remembers to set  $\beta = 0$  for  $T > 0$  °C (8):

$$R_T = R_0 + R_0 \alpha \left[ T - \delta \left( \frac{T}{100} - 1 \right) \left( \frac{T}{100} \right) - \beta \left( \frac{T}{100} - 1 \right) \left( \frac{T}{100} \right)^3 \right]$$

**Conversion to A, B and C**

Equation (8) is the necessary tool for accurate temperature determination. However, seeing that the IEC 751 coefficients A, B and C are more widely used, it would be natural to convert to these coefficients.

Equation (1) can be expanded to (9):

$$R_T = R_0(1 + AT + BT^2 - 100CT^3 + CT^4)$$

and by simple coefficient comparison with equation (8) the following can be determined (10):

$$A = \alpha + \left( \frac{\alpha \cdot \delta}{100} \right)$$

(11)

$$B = \frac{\alpha \cdot \delta}{100^2}$$

(12)

$$C = \frac{\alpha \cdot \beta}{100^4}$$

The device accepts the coefficients to be specified as  $\alpha$ ,  $\beta$ ,  $\delta$  and A, B, C.

Information on the coefficients can be requested from the sensor manufacturers in question.

## 11.2 Polynomial RTD

With "Polynomial RTD", the sensor is defined by a polynomial ( $X4 \cdot x^4 + X3 \cdot x^3 + X2 \cdot x^2 + X1 \cdot x^1 + X0$ ) with 5 coefficients. The physical measuring range is 10 to 400  $\Omega$ .

The 5 coefficients of the polynomial are calculated using the PC configuration software Readwin<sup>®</sup> 2000. There are two different ways of determining the polynomial:

### ■ The sensor-matching-calibration

The deviation (compared to standard RTD) of the sensor or at the complete measuring point (transmitter with connected sensor, Measured =  $\Delta T / ^\circ\text{C}$  or mA) is measured at different temperatures (sampling points). By using a "weight factor" it is possible to set special focus either on the given points (the deviation on the rest of the curve can be quite high) or on the trend compared to the reference linearization (The sampling points are only reference points of an e.g. aged sensor). These sampling points lead to a new revised linearization, which is transferred to the iTEMP<sup>®</sup> temperature transmitters.

### ■ The customer specific linearization

The linearization is made by measured resistance or current values over the target temperature range. These sampling points lead also to a new revised linearization, which is transferred to the iTEMP<sup>®</sup> temperature transmitters.

### 11.2.1 How to use with Readwin<sup>®</sup> 2000:



Note!

Please refer also to the software documentation BA137R/09/en to configure the device with the PC software ReadWin<sup>®</sup> 2000.

1. Select **POLYNOM RTD** in Choice-field "Sensor type".
2. Press button **LINEARIZATION** to open module SMC32.
3. Default setting is Sensor-matching-calibration which can be recognized by " $\Delta T / ^\circ\text{C}$ " in the groupbox "Measured". Alternative choice is "Ohm" or "mA" for customer specific linearization.
4. Default reference RTD linearization is Pt100. Check "Type of Sensor" if another RTD is required. With customer specific linearization it is not possible to select "Type of Sensor".
5. "Weighting" default is 50%. As described above 100% means full focus on the accuracy at the sampling points, 0% uses the sampling points as trend information for the complete curve.
6. The "sampling points" can be edited in the shown table, default points are the min and max temperature of the reference element. These values can be modified to a reduced range.
7. To see the results of the new linearization use menu **Calculate → Calculate Curve** and/or **Calculate → Show Coefficients** (Coefficients are shown in an extra form).
8. The red curve in the graph (scale on right) shows the deviation between calculated and reference curve. This graph easily shows the effect of changing the "weighting".
9. When files exist, data can also be loaded (**Data → Load**). Files made with older versions (SW < 2.0) do only supply sampling points, the extra information ("Measured", "Type of Sensor") has to be edited after loading data.
10. Storing all data in files use **Data → Save** or **Data → Save as....**
11. For using this functionality in the transmitter please press **OK** (data will be taken over in Readwin<sup>®</sup> 2000) and start to transmit to the device.

# Index

## Numerics

250 Ohm communication resistor . . . . . 11

## B

Brief overview . . . . . 2

## C

Callendar - van Dusen Method . . . . . 51  
 CE mark . . . . . 6  
 Communicator DXR 275/375 . . . . . 17  
 Connection using other power supplies . . . . . 12  
 Connection using the power supply RN 221N. . . . . 12  
 Corrosion detection . . . . . 26, 34  
 CSA GP approved . . . . . 6

## D

Device Descriptions . . . . . 19

## E

Error messages . . . . . 33

## F

FieldCare . . . . . 18  
 Function group  
   DIAGNOSTICS . . . . . 27  
   DISPLAY . . . . . 26  
   IDENTIFICATION . . . . . 27  
   MEASURED VALUES . . . . . 29  
   OUTPUT . . . . . 24  
   SAFETY / MAINTENANCE . . . . . 25  
   SENSOR 1 . . . . . 22  
   SENSOR 2 . . . . . 23  
   SERVICE FUNCTIONS . . . . . 28  
 Standard set-up . . . . . 21

## G

GL approval . . . . . 6

## H

Hazardous areas . . . . . 5

## I

Internet address . . . . . 19

## L

Legend plate . . . . . 6

## M

Monitoring the supply voltage . . . . . 35  
 Multidrop mode . . . . . 24

## P

Pipe installation . . . . . 8–9  
 Polynomial RTD . . . . . 53

## Q

Quick Setup . . . . . 20

## R

ReadWin® 2000 . . . . . 19

## S

Safety message . . . . . 2  
 Sensor-matching-calibration . . . . . 53  
 Set-up hardware fault conditioning using jumper J2 . . . . . 16  
 Set-up or configuration hardware lock using jumper J1 . . . . . 15  
 Supported HART® commands . . . . . 29

## T

Technical advancement . . . . . 5  
 Terminal layout . . . . . 10  
 two sensor inputs . . . . . 11

## U

UL approval . . . . . 6  
 Unit reaction to sensor faults . . . . . 34

## W

Wall mounted installation . . . . . 9



| USA   | Canada   | México  | Instruments International   |
|---|--|---|---|
| <p>Endress+Hauser, Inc.<br/>2350 Endress Place<br/>Greenwood, IN 46143<br/>USA</p> <p>Tel. 317-535-7138<br/>Fax 317-535-8498<br/>Sales 888-ENDRESS<br/>Service 800-642-8737<br/>inquiry@us.endress.com<br/>www.us.endress.com</p> | <p>Endress+Hauser Canada<br/>1075 Sutton Drive<br/>Burlington, ON L7L 5Z8<br/>Canada</p> <p>Tel. 905-681-9292<br/>800-668-3199<br/>Fax 905-681-9444<br/>www.ca.endress.com</p> | <p>Endress+Hauser, México, S.A. de C.V.<br/>Av. Gustavo Baz No. 43<br/>Fracc. Bosques de Echegaray<br/>Naucalpan de Juárez, C.P. 53310<br/>Estado de México<br/>México</p> <p>Tel. +52 55-5371-1110<br/>Fax +52 55-5371-1128<br/>eh.mexico@mx.endress.com</p> | <p>Endress+Hauser<br/>Instruments International AG<br/>Kaegenstrasse 2<br/>4153 Reinach<br/>Switzerland</p> <p>Tel. +41 61 715 81 00<br/>Fax +41 61 715 25 00<br/>www.endress.com<br/>info@ii.endress.com</p> |

**Endress+Hauser**   
People for Process Automation