


# SICK

## Sensor Intelligence.

1. Insert alignment help into the measurement area of the sensor
2. Start alignment mode via display or SOPAS
3. Adjust sensor mounting to optimize alignment
4. If high gloss material or material fluttering occurs, please angle the sensor approx. minus 8°



8024169/2019-03-18 · 1M

# Alignment help

---

